

ABB INDUSTRIAL DRIVES

ACS880+N5350 cooling tower drives

User's guide



Any trademarks used in this manual are the property of their respective owners.

Important:

Contact your local ABB office for the latest firmware and manuals for your drive product.

NOTE: Correct counter EMF data is critical for motor operation success. Please record EMF voltage and motor serial number from the motor nameplate in case you need to reference this in the future.

Counter EMF: _____

Motor Serial Number: _____

Contents

Chapter 1

Introduction

1.1 Getting Assistance from ABB	1-1
1.2 Safety Notices	1-1
1.2.1 Safety in Installation and Maintenance	1-1
1.2.2 General Safety	1-3
1.2.3 Safe Start-Up and Operation	1-4

Chapter 2

Product Familiarization

2.1 Overview	2-1
2.2 Standards	2-1
2.2.1 Applicable Standards	2-1
2.2.2 CE Marking	2-1
2.2.3 UL Marking	2-1
2.3 Usage	2-2
2.4 Enclosure	2-2
2.4.1 Layout (IP21, UL Type 1)	2-2
2.4.2 Control Panel	2-3
2.5 Connections	2-3
2.5.1 Main Circuit	2-4
2.5.2 Overview of Power and Control Connections	2-5
2.5.3 External Control Connection Terminals	2-6
2.6 Type Designation Label	2-7
2.7 Type Designation Key	2-8

Chapter 3

Ratings

3.1 Ratings	3-1
3.2 Losses, Cooling Data and Noise	3-4

Chapter 4

Terminal Specifications

4.1 Power Wire Gauge Range Specifications	4-1
4.2 Power Tightening Torque Specifications	4-4
4.3 Control Wire Gauge and Tightening Torque	4-8

Chapter 5

Power Wiring

5.1 Grounding the Control	5-1
5.2 Incoming Power	5-1
5.3 Protecting the Drive and Input Power Cable in Short-Circuits	5-2
5.4 Wire Sizing and Fuses	5-3
5.5 Motor Connections	5-6
5.5.1 Protecting the Motor Insulation and Bearings	5-8

Chapter 6

Control Wiring

6.1 Motor Thermostat	6-1
6.2 Digital Inputs	6-1
6.2.1 Vibration Switch / External Trip	6-3
6.2.2 Other Digital Inputs.	6-3
6.3 Analog Inputs	6-4
6.3.1 Analog Input 1	6-4
6.4 ACS880+N5350 Relay Outputs	6-5
6.5 ACS880+N5350 Analog Outputs	6-6

Chapter 7

Applying Power Quick Install Guide

7.1 Select the Power Cables	7-1
7.2 Ensure Proper Cooling	7-1
7.3 Protect the Drive and Input Power Cable	7-1
7.4 Check the Insulation of the Input and Motor Cables and the Motor	7-1
7.5 Connect the Power Cables.	7-2
7.6 Connect the Control Cables	7-2
7.7 Default I/O Connections	7-3
7.8 UL Checklist	7-4

Chapter 8

Keypad and Programming

8.1 Installation and Start-Up.	8-1
8.1.1 Installation	8-1
8.1.2 First Start-Up	8-2
8.2 Control Panel Overview	8-3
8.2.1 Display	8-3
8.2.2 Keys	8-4
8.2.3 Status LED	8-6
8.2.4 USB Connector	8-6
8.2.5 RJ-45 Connector	8-6
8.2.6 Type Code Label.	8-6
8.2.7 Battery Cover	8-6
8.3 Local Control vs. Remote Control	8-7
8.3.1 Local Control	8-7
8.3.2 Remote Control	8-7
8.4 Basic Operation	8-8
8.4.1 User Interface Overview	8-8
8.4.2 Control Panel Navigation	8-8
8.4.3 Home View	8-9
8.4.4 Help	8-9
8.4.5 Common User Tasks	8-9

Chapter 9

Operating Modes

9.1 2-Wire Operating Mode (Default)	9-1
9.2 3-Wire Operating Mode	9-2
9.3 Process Control (PID) Operating Mode	9-3
9.4 Fieldbus Operating Mode	9-4
9.4.1 Using Fieldbus Adapter Modules for Control of the Drive	9-8
9.4.2 Using the Embedded Fieldbus Port to Control the Drive	9-9

Chapter 10

Additional Setup

10.1 Trickle Current Heating	10-1
10.1.1 Parameter Settings	10-2
10.1.2 CTDD Assistant Access	10-2
10.2 Critical Speed Function	10-2
10.3 De-Ice Function	10-3
10.3.1 De-Ice Parameter Settings	10-3
10.3.2 CTDD Assistant Access	10-3
10.4 Advanced Drive Settings	10-4
10.4.1 Access Levels	10-4
10.4.2 Access Level Flow Diagram	10-5
10.4.3 Access Level Indication	10-5

Chapter 11

Example Connection Diagrams

11.1 ACS880+N5350 2-Wire Operating Mode Example	11-2
11.1.1 Manual Motor Disconnect Switch	11-2
11.2 ACS880+N5350 3-Wire Operating Mode Example	11-3
11.2.1 Manual Motor Disconnect Switch	11-3
11.3 Motor Contactor or Shorting Contactor Examples	11-4
11.3.1 Manual Motor Disconnect Switch	11-4
11.3.2 Shorting Contactor	11-4

Chapter 12

Startup Assistant & Parameters

12.1 Startup Assistants Guide for ACS880+N5350	12-1
12.1.1 Motor Data and ID Run	12-1
12.1.2 Drive Assistant	12-9
12.2 Level 1 Parameters (Advanced Prog, Level 1 Blocks)	12-16

Chapter 13

Troubleshooting

13.1 Warnings and Faults	13-1
13.1.1 Pure Events	13-1
13.1.2 Editable Messages	13-1
13.2 Warning/Fault History	13-1
13.2.1 Event Log	13-1
13.2.2 Auxiliary Codes	13-1
13.2.3 Parameters that Contain Warning/Fault Information	13-1
13.3 Warning Messages	13-2
13.4 Fault Messages	13-10

Appendix A

Technical Specifications

A.1 ACS880+N5350 Technical Data	A-1
A.2 Derating	A-6
A.2.1 Ambient Temperature Derating	A-6
A.2.2 Altitude Derating	A-6
A.2.3 Low Noise Control Mode Derating	A-6

Appendix B

Dimensions

B.1 Dimensions, Weights and Free Space Requirements	B-1
---	-----

Appendix C

CE Guidelines

C.1 Applicable Standards	C-1
C.2 CE Marking	C-1
C.2.1 Compliance with the European Low Voltage Directive	C-1
C.2.2 Compliance with the European EMC Directive	C-1
C.2.3 Compliance with the European RoHS Directive	C-1
C.2.4 Compliance with the European Machinery Directive	C-1
C.3 Compliance with the EN 61800-3:2004	C-4
C.3.1 Definitions	C-4
C.3.2 Category C2	C-4
C.3.3 Category C3	C-4
C.3.4 Category C4	C-5
C.4 UL Marking	C-5
C.4.1 UL Checklist	C-5
C.4.2 CSA Marking	C-6
C.4.3  "C-tick" Marking	C-6
C.5 GOST R Certificate of Conformity	C-6
C.6 Disclaimer	C-6

Appendix D

Mechanical Installation

D.1 Safety	D-1
D.2 Examining the Installation Site	D-1
D.3 Necessary Tools	D-2
D.4 Moving the Drive	D-2
D.5 Unpacking and Examining the Delivery (Frames R1 to R5)	D-2
D.5.1 Frame R5 Cable Entry Box (IP21, UL Type 1)	D-3
D.6 Unpacking and Examining the Delivery (Frames R6 to R9)	D-4
D.6.1 Frame R6 Cable Entry Box (IP21, UL Type 1)	D-5
D.6.2 Frame R7 Cable Entry Box (IP21, UL Type 1)	D-6
D.6.3 Frame R8 Cable Entry Box (IP21, UL Type 1)	D-7
D.6.4 Frame R9 Cable Entry Box (IP21, UL Type 1)	D-8
D.7 Installing the Drive	D-9
D.7.1 Frames R1 to R4	D-9
D.7.2 Frames R4 and R7 (UL Type 12)	D-10
D.7.3 Frames R5 and R9 without Vibration Dampers	D-10
D.8 Cabinet Installation	D-12

Appendix E

ModbusTCP Setup

E.1 ACS880 Cooling Tower Drive E-1
 E.1.1 Modbus TCP Setup E-1

Appendix F

Modbus RTU Setup

F.1 ACS880 Cooling Tower Drive F-1
 F.1.1 Modbus RTU Serial Communication Setup using built-in D2D (drive to drive) port. . . F-1

Appendix G

Ethernet/IP Setup

G.1 ACS880 Cooling Tower Drive G-1
 G.1.1 Ethernet/IP Setup G-1

Chapter 1

Introduction

This manual provides information needed for planning the installation, start-up, operating and servicing the ACS880+N5350 Cooling Tower Drive. The +N5350 control is designed specifically for Baldor-Reliance Interior Permanent Magnet Cooling Tower Motor Control. Control is intended for operating cooling tower fans through a 10:1 variable speed range as well as providing torque control to minimize mechanical stress on the system.

The information in this users guide supports Cooling Tower Drive Firmware V2.00.3.3 and ACS880 Drive Firmware V2.90.

This manual is a quick start guide and contains information on:

- Safety Instructions
- Installation and Wiring of the ACS880+N5350
- Programming the drive
- Reference to related manuals

The reader is expected to know the fundamentals of electricity, wiring, electrical components and electrical schematic symbols.

The information supplied in this guide is intended to provide abbreviated information commonly needed to install and commission the ACS880+N5350 for Cooling Tower Applications. For complete details please reference the full Hardware and Software Manuals on the enclosed CD and available on www.abb.com.

1.1 Getting Assistance from ABB

For technical assistance, contact your local ABB representative. Contact phone numbers are located on the back cover of this guide. Before calling, review the troubleshooting section later in this guide. You will be asked for the drive model number or catalog number that is located on the nameplate along with the drive serial number.

1.2 Safety Notices

This chapter contains the safety instructions which you must follow when installing, operating and servicing the drive. If ignored, physical injury or death may follow, or damage may occur to the drive, motor or driven equipment. Read the safety instructions before you work on the unit.

USE of WARNINGS:

Warnings caution you about conditions which can result in serious injury or death and/or damage to the equipment and advise on how to avoid the danger. The following warning symbols are used in this manual:



Electricity warning warns of hazards from electricity which can cause physical injury and/or damage to the equipment.



General warning warns about conditions, other than those caused by electricity, which can result in physical injury and/or damage to the equipment.



Electrostatic sensitive devices warning warns of electrostatic discharge which can damage the equipment.

1.2.1 Safety in Installation and Maintenance

Electrical Safety -These warnings are intended for all who work on the drive, motor cable or motor.



WARNING: Ignoring the following instructions can cause physical injury or death, or damage to the equipment:

- Only qualified electricians are allowed to install and maintain the drive.
- Never work on the drive, motor cable or motor when main power is applied. After disconnecting the input power, always wait for 5 minutes to let the intermediate circuit capacitors discharge before you start working on the drive, motor or motor cable.

Always ensure by measuring with a multimeter (impedance at least 1Mohm) that:

- voltage between drive input phases L1, L2 and L3 and the frame is close to 0V.
- voltage between terminals UDC+ and UDC- and the frame is close to 0V.
- Do not work on the control cables when power is applied to the drive or to the external control circuits. Externally supplied control circuits may cause dangerous voltages inside the drive even when the main power on the drive is switched off.

- Do not make any insulation or voltage withstand tests on the drive.
- Do not connect the drive to a voltage higher than what is marked on the type designation label. Higher voltage can activate the brake chopper and lead to brake resistor overload, or activate the overvoltage controller what can lead to motor rushing to maximum speed.

Note:

- The motor cable terminals on the drive are at a dangerously high voltage when the input power is on, regardless of whether the motor is running or not.
- The DC terminals (UDC+, UDC-) carry a dangerous DC voltage (over 500V) when internally connected to the intermediate DC circuit.
- Depending on the external wiring, dangerous voltages (115V, 220V or 230V) may be present on the terminals of relay outputs (XRO1, XRO2 and XRO3).
- The Safe torque off function does not remove the voltage from the main and auxiliary circuits. The function is ineffective against deliberate sabotage or misuse.

Grounding - These instructions are intended for all who are responsible for the grounding of the drive.



WARNING: Ignoring the following instructions can cause physical injury or death, or damage to the equipment:

- Ground the drive, motor and adjoining equipment to ensure personnel safety in all circumstances, and to reduce electromagnetic emission and interference.
- Make sure that grounding conductors are adequately sized as required by safety regulations.
- In a multiple-drive installation, connect each drive separately to protective earth (PE).
- Where EMC emissions must be minimized, make a 360° high frequency grounding of cable entries in order to suppress electromagnetic disturbances. In addition, connect the cable shields to protective earth (PE) in order to meet safety regulations.
- Do not install a drive with EMC filter option +E200 or +E202 on an ungrounded power system or a high-resistance-grounded (over 30ohms) power system.

Note:

- Power cable shields are suitable for equipment grounding conductors only when adequately sized to meet safety regulations.
- Standard EN 61800-5-1 (section 4.3.5.5.2.) requires that as the normal touch current of the drive is higher than 3.5mA AC or 10mA DC, you must use a fixed protective earth connection and
 - a cross-section of the protective earthing conductor of at least 10 mm² Cu or 16 mm² Al,
 or
 - automatic disconnection of the supply in case of discontinuity of the protective earthing conductor,
 or
 - a second protective earthing conductor of the same cross-sectional area as the original protective earthing conductor.

Permanent Magnet Motor Drives - These are additional warnings concerning permanent magnet motor drives.



WARNING: Ignoring the following instructions can cause physical injury or death, or damage to the equipment:

- Do not work on the drive when the permanent magnet motor is rotating. Also, when the supply power is switched off and the inverter is stopped, a rotating permanent magnet motor feeds power to the intermediate circuit of the drive and the supply connections become live.

Before installation and maintenance work on the drive:

- Stop the motor.
- Ensure that there is no voltage on the drive power terminals according to step 1 or 2, or if possible, according to the both steps.
 1. Disconnect the motor from the drive with a safety switch or by other means. Check by measuring that there is no voltage present on the drive input or output terminals (L1, L2, L3, U/T1, V/T2, W/T3, UDC+, UDC-).
 2. Stray wind currents can rotate the motor and generate electric potentials. Ensure that the motor is not rotating or is disconnected from the drive during work. Shorting and isolation contactors can be used to short the motor leads and isolate the drive from the motor.

1.2.2 General Safety


These instructions are intended for all who install and service the drive.



WARNING: Ignoring the following instructions can cause physical injury or death, or damage to the equipment:

- Handle the unit carefully.
- Frame sizes R6 to R9: Lift the drive using the lifting eyes of the unit. Do not tilt the drive. The drive is heavy and its center of gravity is high. An overturning unit can cause physical injury.

Figure 1-1



- Beware of hot surfaces. Some parts, such as heatsinks of power semiconductors, remain hot for a while after disconnection of the electrical supply.
- Ensure that debris from borings and grindings does not enter the drive when installing. Electrically conductive debris inside the unit may cause damage or malfunction.
- Ensure sufficient cooling.
- Do not attach the drive by riveting or welding.

Printed Circuit Boards



WARNING: Ignoring the following instructions can cause damage to the printed circuit boards.

- Wear a grounding wrist band when handling the boards. Do not touch the boards unnecessarily. The printed circuit boards contain components sensitive to electrostatic discharge.

1.2.3 Safe Start-Up and Operation

General Safety -These warnings are intended for all who plan the operation of the drive or operate the drive.



WARNING: Ignoring the following instructions can cause physical injury or death, or damage to the equipment:

- Before you connect voltage to the drive, make sure that the drive covers are on. Keep the covers on during the operation.
- Before adjusting the drive and putting it into service, make sure that the motor and all driven equipment are suitable for operation throughout the speed range provided by the drive. The drive can be adjusted to operate the motor at speeds above and below the speed provided by connecting the motor directly to the power line.
- Do not activate any automatic fault reset functions of the drive control program if dangerous situations can occur. When activated, these functions will reset the drive and resume operation after a fault.
- The maximum number of drive power-ups is five in ten minutes. Too frequent power-ups can damage the charging circuit of the DC capacitors.
- Make sure that any safety circuits (for example, emergency stop and Safe torque off) are validated in start-up. See chapter Start-up for reference of the validation instructions.

Note:

- If an external source for start command is selected and it is ON, the drive will start immediately after an input voltage break or fault reset unless the drive is configured for 3-wire (a pulse) start/stop.
- When the control location is not set to local, the stop key on the control panel will not stop the drive.

Permanent Magnet Motor Drives



WARNING: Do not run the motor over the rated speed. Motor overspeed leads to overvoltage which may damage or explode the capacitors in the intermediate circuit of the drive.

2.1 Overview

The ACS880+N5350 is designed to provide variable speed control for a cooling tower fan. This is accomplished much like traditional variable frequency drives, but with unique capabilities specific to the type motor used and the type of application for which the control is being employed.

The +N5350 control is designed specifically for Baldor Interior Permanent Magnet Cooling Tower Motor Control. Control is intended for operating cooling tower fans through a 10:1 variable speed range as well as providing torque control to minimize mechanical stress on the system. The motor drive systems are designed for direct drive applications and eliminate the need for right angle gearboxes. The ACS880 is available for Cooling Tower applications in frame sizes R1 through R9. Frame size specific information can be found in the ratings section.

2.2 Standards

ACS880+N5350 drives have been designed and tested to comply with the following standards.

2.2.1 Applicable Standards

The compliance with the European Low Voltage Directive is verified according to standard EN61800-5-1.

Table 2-1

EN 60204-1:2006 + A1 2009	Safety of machinery. Electrical equipment of machines. Part 1: General requirements. Provisions for compliance: The final assembler of the machine is responsible for installing - emergency-stop device - supply disconnecting device.
IEC/EN 60529:1991 + A1 2000	Degrees of protection provided by enclosures (IP code)
IEC 60664-1:2007	Insulation coordination for equipment within low-voltage systems. Part 1: Principles, requirements and tests.
EN 61800-3:2004	Adjustable speed electrical power drive systems. Part 3: EMC requirements and specific test methods
EN 61800-5-1:2007	Adjustable speed electrical power drive systems. Part 5-1: Safety requirements – electrical, thermal and energy
EN 61800-5-2:2007	Adjustable speed electrical power drive systems. Part 5-2: Safety requirements – Functional
UL 508C:2002	UL Standard for Safety, Power Conversion Equipment, third edition
NEMA 250:2008	Enclosures for Electrical Equipment (1000 Volts Maximum)
CSA C22.2 No. 14-10	Industrial control equipment
GOST R 51321-1:2007	Low-voltage switchgear and control gear assemblies. Part 1 - Requirements for type-tested and partially type-tested assemblies - General technical requirements and methods of tests

2.2.2 CE Marking

A CE mark is attached to the drive to verify that the drive follows the provisions of the European Low Voltage, EMC and RoHS Directives. The CE marking also verifies that the drive, in regard to its safety functions (such as Safe torque off), conforms with the Machinery Directive as a safety component.

2.2.3 UL Marking

cULus Listed UL Type 1 (IP21) drives:

- frames R1 to R3 of voltage range 208...240V
- frames R1 to R9 of voltage ranges 380...415V and 380...500V
- frames R5 to R9 of voltage range 525...600V

cULus Listed UL Type 12 (IP55) drives:

- frames R1 to R3 of voltage range 208...240V
- frames R1 to R5 of voltage ranges 380...415V and 380...500V
- frames R5 of voltage range 525...600V

The listing is pending for the other types. The approval is valid with rated voltages.

(See also Appendix C for recommendations for CE compliance and UL marking.)

2.3 Usage

The ACS880+N5350 can only be used with Baldor RPM AC Interior Permanent Magnet Cooling Tower Motors. If the motor you need to control is of any other type, contact your local ABB Office for support.

2.4 Enclosure

The ACS880+N5350 is provided in an enclosure that meets UL Type 1, IP21 ratings. This provides protection against incidental contact with live electrical circuits and from falling dirt. The drive must be mounted in a clean, dry environment and in a vertical position with at least a 2" clearance on the top, bottom, and both sides. Conductive particles or corrosive gases must not be present in the atmosphere where the drive is mounted. It is not for use outdoors and should be protected from direct sunlight. See Appendix A for complete environmental information.

2.4.1 Layout (IP21, UL Type 1)

The components of the standard IP21 drive are shown below (view of frame R5).

Figure 2-1



2.4.2 Control Panel

The control panel can be removed by pulling it forward from the top edge and reinstalled in reverse order. For the use of the control panel, see the firmware manual or ACS-AP assistant control panels user's manual (3AUA0000085685 [English]).

Figure 2-2



2.5 Connections

The connections of the ACS880+N5350 are segmented into the two groups classified as Power Connections and Control Connections. Conduit mounting holes are provided on the enclosure for each group of connections. See Appendix B for conduit hole sizes so that proper planning can be accomplished for routing conduits to the control.

Access to all connections can be gained by the removal of the front cover.

WARNING: Do not remove the control cover for at least five (5) minutes after AC power is disconnected to allow capacitors to discharge. Dangerous voltages are present inside the equipment. Electrical shock can cause serious or fatal injury.

The power connections are grouped separately from the control connections and may be separated by a protective plate depending on the size of the control. The installer must maintain separation between power connections and control connections so that electrical noise does not interfere with proper operation. This dictates separate conduits for each group of wires. See subsequent sections on power and control wiring for details of the required connections.

2.5.1 Main Circuit

The main circuit of the drive is shown below.

Figure 2-3




Table 2-2

1	Rectifier. Converts alternating current and voltage to direct current and voltage.
2	DC link. DC circuit between rectifier and inverter.
3	Inverter. Converts direct current and voltage to alternating current and voltage.
4	Brake chopper. Conducts the surplus energy from the intermediate DC circuit of the drive to the brake resistor when necessary. The chopper operates when the DC link voltage exceeds a certain maximum limit. The voltage rise is typically caused by deceleration (braking) of a high inertia motor. User obtains and installs the brake resistor when needed.

2.5.2 Overview of Power and Control Connections

The diagram shows the power connections and control interfaces of the drive.

Figure 2-4




Table 2-3

1	Option modules can be inserted into slots 1, 2 and 3 as follows:	
2	Modules	Into slots
3	Analog and digital I/O extension modules except FDIO	1, 2, 3
	Feedback interface modules	1, 2, 3
	Fieldbus communication modules and FDIO	1, 2, 3
	Safety functions modules	2
	See section Type designation key	
4	Memory unit	
5	Connector for safety functions modules (alternative to Slot 2)	
6	Default I/O connection diagram and Control unit (ZCU-12) connection data	
7	See Control panel	
8	du/dt, common mode or sine filter (optional)	

2.6 Type Designation Label

The type designation label includes an IEC and NEMA rating, appropriate markings, a type designation and a serial number, which allow identification of each unit. The type designation label is located on the front cover. An example label is shown below.

Figure 2-6




Table 2-4

No.	Description
1	Type designation
2	Frame size
3	Ratings in the supply voltage range
4	Valid markings
5	Serial number. The first digit of the serial number refers to the manufacturing plant. The next four digits refer to the unit's manufacturing year and week, respectively. The remaining digits complete the serial number so that there are no two units with the same number.

2.7 Type Designation Key

The type designation contains information on the specifications and configuration of the drive. The first digits from left express the basic configuration, eg, ACS880-01-12A6-3 The optional selections are given thereafter, separated by plus signs, eg, +L519. The main selections are described below. Not all selections are available for all types. For more information, refer to ACS880-01 Ordering Information (3AXD10000014923), available on request.

Table 2-5

Code	Description
Basic codes	
ACS880	Product series
01	When no options are selected: Wall mounted drive, IP21 (UL Type 1), ACS-AP-I assistant control panel, no EMC filter, DC choke, ACS880 primary control program, Safe torque off function, cable entry box, brake chopper in frames R1 to R4, coated boards, printed multilingual quick guides and CD containing all manuals.
Size	
xxxx	Refer to the rating tables
Voltage range	
2	208...240V
3	380...415V
5	380...500V
7	525...690V
Option codes (plus codes)	
Degree of protection	
B056	IP55 (UL Type 12)
Construction	
C131	Vibration dampers
Resistor braking	
D150	Brake chopper for frame R5 and up.
Filters	
E200	EMC filter for second environment TN (grounded) system, category C3.
E201	EMC filter for second environment IT (ungrounded) system, category C3. Available for 380...500V frames R6 to R9.
E202	EMC filter for first environment TN (grounded) system, category C2.
Cable entry box	
H358	UK cable entry box
Fieldbus adapters	
K451	FDNA-01 DeviceNet™ adapter module
K454	FPBA-01 PROFIBUS DP adapter module
K457	FCAN-01 CANopen adapter module
K458	FSCA-01 RS-485 adapter module
K462	FCNA-01 ControlNet™ adapter module
K469	FECA-01 EtherCAT adapter module
K470	FEPL-01 Ethernet POWERLINK adapter module
K490	Ethernet/IP adapter, two port
K491	Modbus/TCP adapter, two port
K492	PROFINET IO adapter, two port
K475	FENA-21 Two-Port Ethernet Adapter (EtherNet/IP™, Modbus/TCP)

Table 2-5 Continued

Code	Description
I/O extensions and feedback interfaces	
L500	FIO-11 analog I/O extension module
L501	FIO-01 digital I/O extension module
L502	FEN-31 HTL incremental encoder interface module
L503	FDCO-01 optical DDCS communication adapter module
L508	FDCO-02 optical DDCS communication adapter module
L515	FEA-03 I/O extension adapter
L516	FEN-21 resolver interface module
L517	FEN-01 TTL incremental encoder interface module
L518	FEN-11 absolute encoder interface module
L525	FAIO-01 analog I/O extension module
L526	FDIO-01 digital I/O extension module
Specialties	
P904	Extended warranty
Safety functions modules	
Q973	FSO-12 safety functions module
Full set of printed manuals in selected language.	
Note: The delivered manual set may include manuals in English if the translation is not available.	

Chapter 3

Ratings

3.1 Ratings

The ACS880+N5350 product line includes models to support each motor designed for cooling tower direct drive applications. The following table provides the electrical ratings of each of the standard available models. If your need is for a rating not listed below, contact your local ABB representative for support. (Symbols are described below the table.)

Table 3-1 Drive Ratings, Model Numbers and Frame Sizes with 50 and 60 Hz Supply

Catalog Number ACS880-01-	Frame Size	Input Rating	Max Current	Output Ratings		
				Light-Overload Use		
				I_{1N}	I_{max}	I_{LD}
A	A	A	kW	hp		
$U_N = 208...240V$						
24A3-2+N5350	R2	24.3	28.6	23.1	5.5	7.5
031A-2+N5350	R3	31	41	29.3	7.5	10
046A-2+N5350	R4	46	64	44	11	15
061A-2+N5350	R4	61	76	58	15	20
075A-2+N5350	R5	75	104	71	18.5	25
087A-2+N5350	R5	87	122	83	22	30
115A-2+N5350	R6	115	148	109	30	40
145A-2+N5350	R6	145	178	138	37	50
170A-2+N5350	R7	170	247	162	45	60
206A-2+N5350	R7	206	287	196	55	75
274A-2+N5350	R8	274	362	260	75	100
$U_N = 380...415V$						
12A6-3+N5350	R1	12.6	16	12	5.5	7.5
017A-3+N5350	R2	17	21	16	7.5	10
025A-3+N5350	R2	25	29	24	11	15
032A-3+N5350	R3	32	42	30	15	20
038A-3+N5350	R3	38	54	36	18.5	25
045A-3+N5350	R4	45	64	43	22	30
061A-3+N5350	R4	61	76	58	30	40
072A-3+N5350	R5	72	104	68	37	50
087A-3+N5350	R5	87	122	83	45	60
105A-3+N5350	R6	105	148	100	55	75
145A-3+N5350	R6	145	178	138	75	100
169A-3+N5350	R7	169	247	161	90	125
206A-3+N5350	R7	206	287	196	110	150
246A-3+N5350	R8	246	350	234	132	200
293A-3+N5350	R8	293	418	278	160	225
363A-3+N5350	R9	363	498	345	200	275
430A-3+N5350	R9	430	545	400	200	350

Table 3-1 Drive Ratings, Model Numbers and Frame Sizes with 50 and 60 Hz Supply Cont.

Catalog Number ACS880-01-	Frame Size	Input Rating	Max Current	Output Ratings		
		Light-Overload Use				
		I_{1N}	I_{max}	I_{LD}	P_{LD}	
		A	A	A	kW	hp
$U_N = 440...480V$						
11A0-5+N5350	R1	11	16	11	5.5	7.5
014A-5+N5350	R2	14	21	14	7.5	10
021A-5+N5350	R2	21	29	21	11	15
027A-5+N5350	R3	27	42	27	15	20
034A-5+N5350	R3	34	54	34	18.5	25
040A-5+N5350	R4	40	64	40	22	30
052A-5+N5350	R4	52	76	52	30	40
065A-5+N5350	R5	65	104	65	37	50
077A-5+N5350	R5	77	122	77	45	60
096A-5+N5350	R6	96	148	96	55	75
124A-5+N5350	R6	124	178	124	75	100
156A-5+N5350	R7	156	247	156	90	125
180A-5+N5350	R7	180	287	180	110	150
240A-5+N5350	R8	240	350	240	132	200
260A-5+N5350	R8	260	418	260	132	200
302A-5+N5350	R9	302	498	302	200	250
361A-5+N5350	R9	361	542	361	200	300
414A-5+N5350	R9	414	542	414	250	350
$U_N = 660...690V$						
07A3-7+N5350	R5	7.3	12.2	6.9	5.5	7.5
09A8-7+N5350	R5	9.8	18	9.3	7.5	10
14A2-7+N5350	R5	14.2	22	13.5	11	15
018A-7+N5350	R5	18	30	17	15	20
022A-7+N5350	R5	22	44	21	18.5	25
026A-7+N5350	R5	26	54	25	22	30
035A-7+N5350	R5	35	64	33	30	40
042A-7+N5350	R5	42	74	40	37	50
049A-7+N5350	R5	49	76	47	45	60
061A-7+N5350	R6	61	104	58	55	75
084A-7+N5350	R6	84	124	80	75	100
098A-7+N5350	R7	98	168	93	90	125
119A-7+N5350	R7	119	198	113	110	150
142A-7+N5350	R8	142	250	135	132	200
174A-7+N5350	R8	174	274	165	160	225
210A-7+N5350	R9	210	384	200	200	275
271A-7+N5350	R9	271	411	257	250	350

Table 3-2 Definitions

U_N	Supply voltage range
I_{1N}	Nominal rms input current
I_N	Nominal output current (available continuously with no over-loading)
P_N	Typical motor power in no-overload use
I_{LD}	Continuous rms output current allowing 10% overload for 1 minute every 5 minutes
P_{LD}	Typical motor power in light-overload use
I_{max}	Maximum output current. Available for 10 seconds at start. then as long as allowed by drive temperature.
I_{Hd}	Continuous rms output current allowing 50% overload for 1 minute every 5 minutes.
	* Continuous rms output current allowing 30% overload for 1 minute every 5 minutes.
	** Continuous rms output current allowing 25% overload for 1 minute every 5 minutes.
P_{Hd}	Typical motor power in heavy-duty use

Notes:

1. The ratings apply at an ambient temperature of 40°C (104°F).
2. To achieve the rated motor power given in the table, the rated current of the drive must be higher than or equal to the rated motor current.

The DriveSize dimensioning tool available from ABB is recommended for selecting the drive, motor and gear combination.

3.2 Losses, Cooling Data and Noise

Table 3-3

Catalog Number ACS880-01-	Frame Size	Air Flow		Heat Dissipation	Noise
		m ³ /h	ft ³ /min	(Watts)	dB(A)
$U_N = 208...240V$					
24A3-2+N5350	R2	88	52	337	51
031A-2+N5350	R3	134	79	457	57
046A-2+N5350	R4	134	79	500	62
061A-2+N5350	R4	280	165	630	62
075A-2+N5350	R5	280	165	680	62
087A-2+N5350	R5	280	165	730	62
115A-2+N5350	R6	435	256	840	67
145A-2+N5350	R6	435	256	940	67
170A-2+N5350	R7	450	265	1260	67
206A-2+N5350	R7	450	265	1500	67
274A-2+N5350	R8	550	324	2100	65
$U_N = 380...415V$					
12A6-3+N5350	R1	44	26	172	46
017A-3+N5350	R2	88	52	232	51
025A-3+N5350	R2	88	52	337	52
032A-3+N5350	R3	134	79	457	57
038A-3+N5350	R3	134	79	562	57
045A-3+N5350	R4	134	79	667	62
061A-3+N5350	R4	280	165	907	62
072A-3+N5350	R5	280	165	1117	62
087A-3+N5350	R5	280	165	1120	62
105A-3+N5350	R6	435	256	1295	67
145A-3+N5350	R6	435	256	1440	67
169A-3+N5350	R7	450	265	1940	67
206A-3+N5350	R7	450	265	2310	67
246A-3+N5350	R8	550	324	3300	65
293A-3+N5350	R8	550	324	3900	65
363A-3+N5350	R9	1150	677	4800	68
430A-3+N5350	R9	1150	677	6000	68

Table 3-3 Continued

Catalog Number ACS880-01-	Frame Size	Air Flow		Heat Dissipation	Noise
		m ³ /h	ft ³ /min	(Watts)	dB(A)
$U_N = 440...480V$					
11A0-5+N5350	R1	44	26	172	46
014A-5+N5350	R2	88	52	232	51
021A-5+N5350	R2	88	52	337	51
027A-5+N5350	R3	134	79	457	57
034A-5+N5350	R3	134	79	562	57
040A-5+N5350	R4	134	79	667	62
052A-5+N5350	R4	280	165	907	62
065A-5+N5350	R5	280	165	1117	62
077A-5+N5350	R5	280	165	1120	62
096A-5+N5350	R6	435	256	1295	67
124A-5+N5350	R6	435	256	1440	67
156A-5+N5350	R7	450	265	1940	67
180A-5+N5350	R7	450	265	2310	67
240A-5+N5350	R8	550	324	3300	65
260A-5+N5350	R8	550	324	3900	65
302A-5+N5350	R9	1150	677	4200	68
361A-5+N5350	R9	1150	677	4800	68
414A-5+N5350	R9	1150	677	6000	68
$U_N = 660...690V$					
07A3-7+N5350	R5	280	165	217	62
09A8-7+N5350	R5	280	165	284	62
14A2-7+N5350	R5	280	165	399	62
018A-7+N5350	R5	280	165	490	62
022A-7+N5350	R5	280	165	578	62
026A-7+N5350	R5	280	165	660	62
035A-7+N5350	R5	280	165	864	62
042A-7+N5350	R5	280	165	998	62
049A-7+N5350	R5	280	165	1120	62
061A-7+N5350	R6	435	256	1295	67
084A-7+N5350	R6	435	256	1440	67
098A-7+N5350	R7	450	265	1940	67
119A-7+N5350	R7	450	265	2310	67
142A-7+N5350	R8	550	324	3300	65
174A-7+N5350	R8	550	324	3900	65
210A-7+N5350	R9	1150	677	4200	68
271A-7+N5350	R9	1150	677	4800	68

Chapter 4

Terminal Specifications

Terminal specifications provided in this section should be followed during the installation of the ACS880+N5350 control. The following tables provide the wire gauge ranges and terminal tightening torques for each group of terminals within the control.

4.1 Power Wire Gauge Range Specifications

Use copper conductors only.

Table 4-1 Power Wire Gauge Specification

Catalog Number ACS880-01-	Frame Size	Metric ¹⁾		US ²⁾	
		Cu Cable Type Typical	Al Cable Type Typical	Cu Cable Type Typical	Al Cable Type Typical
		mm ²	mm ²	AWG/kcmil	AWG/kcmil
208...240V					
04A6-2+N5350	R1	3 x 1.5	-	14	-
06A6-2+N5350	R1	3 x 1.5	-	14	-
07A5-2+N5350	R1	3 x 1.5	-	14	-
10A6-2+N5350	R1	3 x 1.5	-	14	-
16A8-2+N5350	R2	3 x 6	-	10	-
24A3-2+N5350	R2	3 x 6	-	10	-
031A-2+N5350	R3	3 x 10	-	8	-
046A-2+N5350	R4	3 x 16	3 x 35	6	-
061A-2+N5350	R4	3 x 25	3 x 35	4	-
075A-2+N5350	R5	3 x 35	3 x 50	3	-
087A-2+N5350	R5	3 x 35	3 x 70	3	-
115A-2+N5350	R6	3 x 50	3 x 70	1	-
145A-2+N5350	R6	3 x 95	3 x 120	2/0	-
170A-2+N5350	R7	3 x 120	3 x 150	3/0	-
206A-2+N5350	R7	3 x 150	3 x 240	250 MCM	-
274A-2+N5350	R8	-	-	-	-
380...415V					
02A4-3+N5350	R1	3 x 1.5	-	14	-
03A3-3+N5350	R1	3 x 1.5	-	14	-
04A0-3+N5350	R1	3 x 1.5	-	14	-
05A6-3+N5350	R1	3 x 1.5	-	14	-
07A2-3+N5350	R1	3 x 1.5	-	14	-
09A4-3+N5350	R1	3 x 1.5	-	14	-
12A6-3+N5350	R1	3 x 1.5	-	14	-
017A-3+N5350	R2	3 x 6	-	10	-
025A-3+N5350	R2	3 x 6	-	10	-
032A-3+N5350	R3	3 x 10	-	8	-
038A-3+N5350	R3	3 x 10	-	8	-
045A-3+N5350	R4	3 x 16	3 x 35	6	-
061A-3+N5350	R4	3 x 25	3 x 35	4	-
072A-3+N5350	R5	3 x 35	3 x 50	3	-
087A-3+N5350	R5	3 x 35	3 x 70	3	-
105A-3+N5350	R6	3 x 50	3 x 70	1	-
145A-3+N5350	R6	3 x 95	3 x 120	2/0	-
169A-3+N5350	R7	3 x 120	3 x 150	3/0	-
206A-3+N5350	R7	3 x 150	3 x 240	250 MCM	-
246A-3+N5350	R8	2 x (3x70) ³⁾	2 x (3x95)	300 MCM	-
293A-3+N5350	R8	2 x (3x95) ³⁾	2 x (3x120)	2 x 3/0	-
363A-3+N5350	R9	2 x (3x120)	2 x (3x185)	2 x 4/0	-
430A-3+N5350	R9	2 x (3x150)	2 x (3x240)	2 x 250 MCM	-

Table 4-1 Power Wire Gauge Specification (Cont.)

Catalog Number ACS880-01-	Frame Size	Metric ¹⁾		US ²⁾	
		Cu Cable Type Typical	Al Cable Type Typical	Cu Cable Type Typical	Al Cable Type Typical
		mm ²	mm ²	AWG/kcmil	AWG/kcmil
440...480V					
02A1-5+N5350	R1	3 x 1.5	-	14	-
03A0-5+N5350	R1	3 x 1.5	-	14	-
03A4-5+N5350	R1	3 x 1.5	-	14	-
04A8-5+N5350	R1	3 x 1.5	-	14	-
05A2-5+N5350	R1	3 x 1.5	-	14	-
07A6-5+N5350	R1	3 x 1.5	-	14	-
11A0-5+N5350	R1	3 x 1.5	-	14	-
014A-5+N5350	R2	3 x 6	-	10	-
021A-5+N5350	R2	3 x 6	-	10	-
027A-5+N5350	R3	3 x 10	-	8	-
034A-5+N5350	R3	3 x 6	-	8	-
040A-5+N5350	R4	3 x 16	3 x 25	6	-
052A-5+N5350	R4	3 x 25	3 x 25	4	-
065A-5+N5350	R5	3 x 35	3 x 35	3	-
077A-5+N5350	R5	3 x 35	3 x 50	3	-
096A-5+N5350	R6	3 x 50	3 x 70	1	-
124A-5+N5350	R6	3 x 95	3 x 95	2/0	-
156A-5+N5350	R7	3 x 120	3 x 150	3/0	-
180A-5+N5350	R7	3 x 150	3 x 185	250 MCM	-
240A-5+N5350	R8	2 x (3x70) ³⁾	2 x (3x95)	300 MCM	-
260A-5+N5350	R8	2 x (3x70) ³⁾	2 x (3x95)	2 x 3/0	-
302A-5+N5350	R9	2 x (3x95)	2 x (3x120)	2 x 3/0	-
361A-5+N5350	R9	2 x (3x120)	2 x (3x185)	2 x 250 MCM	-
414A-5+N5350	R9	2 x (3x150)	2 x (3x240)	2 x 250 MCM	-
660...690V					
07A3-7+N5350	R5	3 x 1.5	-	14	12
09A8-7+N5350	R5	3 x 1.5	-	14	12
14A2-7+N5350	R5	3 x 2.5	-	14	12
018A-7+N5350	R5	3 x 4	-	12	10
022A-7+N5350	R5	3 x 6	-	10	8
026A-7+N5350	R5	3 x 10	3 x 25	8	6
035A-7+N5350	R5	3 x 10	3 x 25	8	6
042A-7+N5350	R5	3 x 16	3 x 25	6	4
049A-7+N5350	R5	3 x 16	3 x 25	6	4
061A-7+N5350	R6	3 x 25	3 x 35	4	3
084A-7+N5350	R6	3 x 35	3 x 50	3	2
098A-7+N5350	R7	3 x 50	3 x 70	2	1/0
119A-7+N5350	R7	3 x 70	3 x 95	1/0	3/0
142A-7+N5350	R8	3 x 95 ³⁾	3 x 120	2/0	4/0
174A-7+N5350	R8	3 x 120 ³⁾	2 x (3x70)	4/0	300 MCM
210A-7+N5350	R9	3 x 185	2 x (3x95)	300 MCM	2 x 3/0
271A-7+N5350	R9	3 x 240	2 x (3x120)	400 MCM	2 x 4/0

- 1) The cable sizing is based on max. 9 cables laid on a cable ladder side by side, three ladder type trays one on top of the other, ambient temperature 30°C, PVC insulation, surface temperature 70°C (EN60204-1 and IEC60364-5-52/2001). For other conditions, size the cables according to local safety regulations, appropriate input voltage and the load current of the drive. Refer to Hardware Manual 3AUA0000078093 for accepted cable sizes of the drive.
- 2) The cable sizing is based on NEC Table 310-16 for copper wires, 75°C (167°F) wire insulation at 40°C (104°F) ambient temperature. Not more than three current-carrying conductors in raceway or cable or earth (directly buried). For other conditions, size the cables according to local safety regulations, appropriate input voltage and the load current of the drive. Refer to Hardware Manual 3AUA0000078093 for accepted cable sizes of the drive.
- 3) The biggest cable size accepted by the connection terminals of frame R8 is 2 × (3×150). Biggest possible cable size is 3x240 or 400 MCM if the terminal type is changed and the cable entry box is not used.

4.2 Power Tightening Torque Specifications

Table 4-2 Power Tightening Torque Specifications


Catalog Number ACS880-01-	Frame Size	Tightening Torque													
		L1, L2, L3, T1/U, T2/V, T3/W						R-, R+/UDC+, UDC						Ground 	
		T (Wire Screw)			T (Terminal Nut)			T (Wire Screw)			T (Terminal Nut)			T	
		lbf-ft	M...	N-M	lbf-ft	M...	N-M	lbf-ft	M...	N-M	lbf-ft	M...	N-M	lbf-ft	N-M
208...240V															
24A3-2+N5350	R2	0.4		0.6				0.4		0.6				1.3	1.8
031A-2+N5350	R3	1.3		1.7				1.3		1.7				1.3	1.8
046A-2+N5350	R4	2.4		3.3				2.4		3.3				2.1	2.9
061A-2+N5350	R4	2.4		3.3				2.4		3.3				2.1	2.9
075A-2+N5350	R5	11.0		15				11.0		15				2.1	2.9
087A-2+N5350	R5	11.0		15				11.0		15				2.1	2.9
115A-2+N5350	R6	22.1	M10	30		M8	24	14.8	M8	20		M8	20	7.2	9.8
145A-2+N5350	R6	22.1	M10	30		M8	24	14.8	M8	20		M8	20	7.2	9.8
170A-2+N5350	R7	29.5 (22.1*)	M10	40 (30*)		M8	24	14.8	M10	30		M10	30	7.2	9.8
206A-2+N5350	R7	29.5 (22.1*)	M10	40 (30*)		M8	24	14.8	M10	30		M10	30	7.2	9.8
274A-2+N5350	R8	29.5	M10	40	17.7	M10	24	29.5	M10	40	17.7	M8	24	7.2	9.8
380...415V															
12A6-3+N5350	R1	0.4		0.6				0.4		0.6				1.3	1.8
017A-3+N5350	R2	0.4		0.6				0.4		0.6				1.3	1.8
025A-3+N5350	R2	0.4		0.6				0.4		0.6				1.3	1.8
032A-3+N5350	R3	1.3		1.7				1.3		1.7				1.3	1.8
038A-3+N5350	R3	1.3		1.7				1.3		1.7				1.3	1.8
045A-3+N5350	R4	2.4		3.3				2.4		3.3				2.1	2.9
061A-3+N5350	R4	2.4		3.3				2.4		3.3				2.1	2.9
072A-3+N5350	R5	11.0		15				11.0		15				2.1	2.9
087A-3+N5350	R5	11.0		15				11.0		15				2.1	2.9
105A-3+N5350	R6	22.1	M10	30		M8	24	14.8	M8	20		M8	20	7.2	9.8
145A-3+N5350	R6	22.1	M10	30		M8	24	14.8	M8	20		M8	20	7.2	9.8
169A-3+N5350	R7	29.5 (22.1*)	M10	40 (30*)		M8	24	14.8	M10	30		M10	30	7.2	9.8
206A-3+N5350	R7	29.5 (22.1*)	M10	40 (30*)		M8	24	14.8	M10	30		M10	30	7.2	9.8
246A-3+N5350	R8	29.5	M10	40	17.7	M10	24	29.5	M10	40	17.7	M8	24	7.2	9.8
293A-3+N5350	R8	29.5	M10	40	17.7	M10	24	29.5	M10	40	17.7	M8	24	7.2	9.8
363A-3+N5350	R9	51.6	M12	70	17.7	M10	24	51.6	M12	70	17.7	M8	24	7.2	9.8
430A-3+N5350	R9	51.6	M12	70	17.7	M10	24	51.6	M12	70	17.7	M8	24	7.2	9.8

Table 4-2 Power Tightening Torque Specifications (Cont.)

Catalog Number ACS880-01-	Frame Size	Tightening Torque													
		L1, L2, L3, T1/U, T2/V, T3/W						R-, R+/UDC+, UDC						Ground 	
		T (Wire Screw)			T (Terminal Nut)			T (Wire Screw)			T (Terminal Nut)			T	
		lbf-ft	M...	N-M	lbf-ft	M...	N-M	lbf-ft	M...	N-M	lbf-ft	M...	N-M	lbf-ft	N-M
440...480V															
11A0-5+N5350	R1	0.4		0.6				0.4		0.6				1.3	1.8
014A-5+N5350	R2	0.4		0.6				0.4		0.6				1.3	1.8
021A-5+N5350	R2	0.4		0.6				0.4		0.6				1.3	1.8
027A-5+N5350	R3	1.3		1.7				1.3		1.7				1.3	1.8
034A-5+N5350	R3	1.3		1.7				1.3		1.7				1.3	1.8
040A-5+N5350	R4	2.4		3.3				2.4		3.3				2.1	2.9
052A-5+N5350	R4	2.4		3.3				2.4		3.3				2.1	2.9
065A-5+N5350	R5	11.0		15				11.0		15				2.1	2.9
077A-5+N5350	R5	11.0		15				11.0		15				2.1	2.9
096A-5+N5350	R6	22.1	M10	30		M8 24		14.8	M8 20		M8 20		M8 20	7.2	9.8
124A-5+N5350	R6	22.1	M10	30		M8 24		14.8	M8 20		M8 20		M8 20	7.2	9.8
156A-5+N5350	R7	29.5 (22.1*)	M10	40 (30*)		M8 24		14.8	M10 30		M10 30		M10 30	7.2	9.8
180A-5+N5350	R7	29.5 (22.1*)	M10	40 (30*)		M8 24		14.8	M10 30		M10 30		M10 30	7.2	9.8
240A-5+N5350	R8	29.5	M10	40	17.7	M10 24		29.5	M10 40	17.7	M8 24		M8 24	7.2	9.8
302A-5+N5350	R9	51.6	M12	70	17.7	M10 24		51.6	M12 70	17.7	M8 24		M8 24	7.2	9.8
361A-5+N5350	R9	51.6	M12	70	17.7	M10 24		51.6	M12 70	17.7	M8 24		M8 24	7.2	9.8
414A-5+N5350	R9	51.6	M12	70	17.7	M10 24		51.6	M12 70	17.7	M8 24		M8 24	7.2	9.8
660...690V															
07A3-7+N5350	R5	11.0		15				11.0		15				2.1	2.9
09A8-7+N5350	R5	11.0		15				11.0		15				2.1	2.9
14A2-7+N5350	R5	11.0		15				11.0		15				2.1	2.9
018A-7+N5350	R5	11.0		15				11.0		15				2.1	2.9
022A-7+N5350	R5	11.0		15				11.0		15				2.1	2.9
026A-7+N5350	R5	11.0		15				11.0		15				2.1	2.9
035A-7+N5350	R5	11.0		15				11.0		15				2.1	2.9
042A-7+N5350	R5	11.0		15				11.0		15				2.1	2.9
049A-7+N5350	R5	11.0		15				11.0		15				2.1	2.9
061A-7+N5350	R6	22.1	M10	30		M8 24		14.8	M8 20		M8 20		M8 20	7.2	9.8
084A-7+N5350	R6	22.1	M10	30		M8 24		14.8	M8 20		M8 20		M8 20	7.2	9.8
098A-7+N5350	R7	29.5 (22.1*)	M10	40 (30*)		M8 24		14.8	M10 30		M10 30		M10 30	7.2	9.8
119A-7+N5350	R7	29.5 (22.1*)	M10	40 (30*)		M8 24		14.8	M10 30		M10 30		M10 30	7.2	9.8
142A-7+N5350	R8	29.5	M10	40	17.7	M10 24		29.5	M10 40	17.7	M8 24		M8 24	7.2	9.8
174A-7+N5350	R8	29.5	M10	40	17.7	M10 24		29.5	M10 40	17.7	M8 24		M8 24	7.2	9.8
210A-7+N5350	R9	51.6	M12	70	17.7	M10 24		51.6	M12 70	17.7	M8 24		M8 24	7.2	9.8
271A-7+N5350	R9	51.6	M12	70	17.7	M10 24		51.6	M12 70	17.7	M8 24		M8 24	7.2	9.8

* For 660...690V volt drives.

Figure 4-3 Cable Conduit Installation R6, R7, R8, R9



Chapter 5

Power Wiring

This section outlines the basics of the power wiring for the ACS880+N5350. Sample wiring diagrams are shown later in this guide.

5.1 Grounding the Control

WARNING: Be sure the system is properly grounded before applying power. Do not apply AC power before you ensure that all grounding instructions have been followed. Electrical shock can cause serious or fatal injury.

To ensure a safe and trouble-free installation, the ACS880+N5350 must be properly grounded. Symmetrical voltage on all three phases relative to ground is optimum and thus it is recommended that the control be supplied from a 4-wire wye connected source. The center tap of the supply transformer secondary should be solidly grounded per local code. A ground wire must be pulled in the same conduit with the L1, L2, and L3 connections from the source ensuring that the ground wire is terminated on the ACS880+N5350 power terminal block.

5.2 Incoming Power

The ACS880+N5350 is designed for the incoming power ratings listed below. If your installation does not meet these ratings, contact your local ABB representative for support.


Table 5-1 Incoming Power

Description	Rating
Voltage (U_1)	ACS880-01-xxxx-2 units: 208 ... 240VAC 3-phase +10%...-15%
	ACS880-01-xxxx-3 units: 380 ... 415VAC 3-phase +10%...-15%
	ACS880-01-xxxx-5 units: 380 ... 500VAC 3-phase +10%...-15%
	ACS880-01-xxxx-7 units: 525 ... 690VAC 3-phase +10%...-15%
Network type	TN (grounded) and IT (ungrounded) systems.
Rated conditional short-circuit current (IEC 61439-1)	65 kA when protected by fuses given in the fuse tables
Short-circuit current protection (UL508C, CSA C22.2 No. 14-05)	US and Canada: The drive is suitable for use on a circuit capable of delivering not more than 100 kA symmetrical amperes (rms) at 600V maximum when protected by fuses given in the fuse table
Frequency	47 to 63 Hz, maximum rate of change 17%/s
Imbalance	Max. \pm 3% of nominal phase to phase input voltage
Fundamental power factor ($\cos\phi_1$)	0.98 (at nominal load)

As stated in the grounding section, the three incoming power wires must be pulled together in a single conduit with the grounding conductor. These connections are to be made to L1, L2, and L3.

CAUTION: Do not connect AC power to the drive output terminals T1/U, T2, V and T3/W. These terminals are for supplying power to the motor. Connecting AC power to these terminals may result in damage to the control.


Figure 5-1 Incoming Power Diagram



5.3 Protecting the Drive and Input Power Cable in Short-Circuits

Protect the drive and input cable with fuses as follows:

Figure 5-2



Size the fuses at the distribution board according to Table 5-2. The fuses will protect the input cable in short-circuit situations, restrict drive damage and prevent damage to adjoining equipment in case of a short-circuit inside the drive.

Note: Circuit breakers must not be used without fuses. For more information, contact ABB.

5.4 Wire Sizing and Fuses

It is the responsibility of the installer to ensure that the ACS880+N5350 is installed in accordance with local electrical codes. This includes, but is not limited to a proper disconnect, branch circuit protection, and wire size.

The following tables can be used as a guide to select wire gauge and input fuses. Recommendations are based upon the maximum continuous current of the control. This table assumes 75°C wire.

Table 5-2 Wire Sizing

Catalog Number	Control Rating				Wire Gauge (AWG)
	Frame	kW	HP	Input Amps	
ACS880-01-24A3-2+N5350	R2	5.5	7.5	24.3	10
ACS880-01-031A-2+N5350	R3	7.5	10	31	8
ACS880-01-046A-2+N5350	R4	11	15	46	6
ACS880-01-061A-2+N5350	R4	15	20	61	4
ACS880-01-075A-2+N5350	R5	18.5	25	75	3
ACS880-01-087A-2+N5350	R5	22	30	87	3
ACS880-01-115A-2+N5350	R6	30	40	115	1
ACS880-01-145A-2+N5350	R6	37	50	145	2/0
ACS880-01-170A-2+N5350	R7	45	60	170	3/0
ACS880-01-206A-2+N5350	R7	55	75	206	250 MCM
ACS880-01-274A-2+N5350	R8	75	100	274	-
ACS880-01-12A6-3+N5350	R1	5.5	7.5	12.6	14
ACS880-01-017A-3+N5350	R2	7.5	10	17	10
ACS880-01-025A-3+N5350	R2	11	15	25	10
ACS880-01-032A-3+N5350	R3	15	20	32	8
ACS880-01-038A-3+N5350	R3	18.5	25	38	8
ACS880-01-045A-3+N5350	R4	22	30	45	6
ACS880-01-061A-3+N5350	R4	30	40	61	4
ACS880-01-072A-3+N5350	R5	37	50	72	3
ACS880-01-087A-3+N5350	R5	45	60	87	3
ACS880-01-105A-3+N5350	R6	55	75	105	1
ACS880-01-145A-3+N5350	R6	75	100	145	2/0
ACS880-01-169A-3+N5350	R7	90	125	169	3/0
ACS880-01-206A-3+N5350	R7	110	150	206	250 MCM
ACS880-01-246A-3+N5350	R8	132	200	246	300 MCM
ACS880-01-293A-3+N5350	R8	160	225	293	2 x 3/0
ACS880-01-363A-3+N5350	R9	200	275	363	2 x 4/0
ACS880-01-430A-3+N5350	R9	200	350	430	2 x 250 MCM

Table 5-2 Wire Sizing Continued

Catalog Number	Control Rating				Wire Gauge (AWG)
	Frame	HP	kW	Input Amps	
ACS880-01-11A0-5+N5350	R1	5.5	7.5	11	14
ACS880-01-014A-5+N5350	R2	7.5	10	14	10
ACS880-01-021A-5+N5350	R2	11	15	21	10
ACS880-01-027A-5+N5350	R3	15	20	27	8
ACS880-01-034A-5+N5350	R3	18.5	25	34	8
ACS880-01-040A-5+N5350	R4	22	30	40	6
ACS880-01-052A-5+N5350	R4	30	40	52	4
ACS880-01-065A-5+N5350	R5	37	50	65	3
ACS880-01-077A-5+N5350	R5	45	60	77	3
ACS880-01-096A-5+N5350	R6	55	75	96	1
ACS880-01-124A-5+N5350	R6	75	100	124	2/0
ACS880-01-156A-5+N5350	R7	90	125	156	3/0
ACS880-01-180A-5+N5350	R7	110	150	180	250 MCM
ACS880-01-240A-5+N5350	R8	132	200	240	300 MCM
ACS880-01-260A-5+N5350	R8	132	200	260	2 x 3/0
ACS880-01-302A-5+N5350	R9	200	250	302	2 x 3/0
ACS880-01-361A-5+N5350	R9	200	300	361	2 x 250 MCM
ACS880-01-414A-5+N5350	R9	250	350	414	2 x 250 MCM
ACS880-01-07A3-7+N5350	R5	5.5	7.5	7.3	14
ACS880-01-09A8-7+N5350	R5	7.5	10	9.8	14
ACS880-01-14A2-7+N5350	R5	11	15	14.2	14
ACS880-01-018A-7+N5350	R5	15	20	18	12
ACS880-01-022A-7+N5350	R5	18.5	25	22	10
ACS880-01-026A-7+N5350	R5	22	30	26	8
ACS880-01-035A-7+N5350	R5	30	40	35	8
ACS880-01-042A-7+N5350	R5	37	50	42	6
ACS880-01-049A-7+N5350	R5	45	60	49	6
ACS880-01-061A-7+N5350	R6	55	75	61	4
ACS880-01-084A-7+N5350	R6	75	100	84	3
ACS880-01-098A-7+N5350	R7	90	125	98	2
ACS880-01-119A-7+N5350	R7	110	150	119	1/0
ACS880-01-142A-7+N5350	R8	132	200	142	2/0
ACS880-01-174A-7+N5350	R8	160	225	174	4/0
ACS880-01-210A-7+N5350	R9	200	275	210	300 MCM
ACS880-01-271A-7+N5350	R9	250	350	271	400 MCM

The table below assumes 150% rated fast acting fuses.

Table 5-3 Fuses

Catalog Number	Frame	Input Current Amps	Fuse (one fuse per phase)				
			A	V	Manufacturer	Type	UL Class
ACS880-01-24A3-2+N5350	R2	24.3	40	600	Bussmann	JJS-40	T
ACS880-01-031A-2+N5350	R3	31	50	600	Bussmann	JJS-50	T
ACS880-01-046A-2+N5350	R4	46	80	600	Bussmann	JJS-80	T
ACS880-01-061A-2+N5350	R4	61	100	600	Bussmann	JJS-100	T
ACS880-01-075A-2+N5350	R5	75	125	600	Bussmann	JJS-125	T
ACS880-01-087A-2+N5350	R5	87	125	600	Bussmann	JJS-125	T
ACS880-01-115A-2+N5350	R6	115	150	600	Bussmann	JJS-150	T
ACS880-01-145A-2+N5350	R6	145	200	600	Bussmann	JJS-200	T
ACS880-01-170A-2+N5350	R7	170	250	600	Bussmann	JJS-250	T
ACS880-01-206A-2+N5350	R7	206	300	600	Bussmann	JJS-300	T
ACS880-01-274A-2+N5350	R8	274	400	600	Bussmann	JJS-400	T
ACS880-01-11A0-5+N5350	R1	11	20	600	Bussmann	JJS-20	T
ACS880-01-014A-5+N5350	R2	14	25	600	Bussmann	JJS-25	T
ACS880-01-021A-5+N5350	R2	21	35	600	Bussmann	JJS-35	T
ACS880-01-027A-5+N5350	R3	27	40	600	Bussmann	JJS-40	T
ACS880-01-034A-5+N5350	R3	34	50	600	Bussmann	JJS-50	T
ACS880-01-040A-5+N5350	R4	40	60	600	Bussmann	JJS-60	T
ACS880-01-052A-5+N5350	R4	52	80	600	Bussmann	JJS-80	T
ACS880-01-065A-5+N5350	R5	65	90	600	Bussmann	JJS-90	T
ACS880-01-077A-5+N5350	R5	77	110	600	Bussmann	JJS-110	T
ACS880-01-096A-5+N5350	R6	96	150	600	Bussmann	JJS-150	T
ACS880-01-124A-5+N5350	R6	124	200	600	Bussmann	JJS-200	T
ACS880-01-156A-5+N5350	R7	156	225	600	Bussmann	JJS-225	T
ACS880-01-180A-5+N5350	R7	180	300	600	Bussmann	JJS-300	T
ACS880-01-240A-5+N5350	R8	240	350	600	Bussmann	JJS-350	T
ACS880-01-260A-5+N5350	R8	260	400	600	Bussmann	JJS-400	T
ACS880-01-302A-5+N5350	R9	302	400	600	Bussmann	JJS-400	T
ACS880-01-361A-5+N5350	R9	361	500	600	Bussmann	JJS-500	T
ACS880-01-414A-5+N5350	R9	414	600	600	Bussmann	JJS-600	T

Note: For -3 and -7 drives, consult 3AUA0000078093 Hardware Manual for fuse information.

5.5 Motor Connections

The wiring between the drive and the motor must consist of 3 wires plus a ground routed in the same conduit. The ground wire must be continuous and terminated in the motor connection box as well as on the drive ground terminal. The output power wiring is terminated in the drive on terminals T1, T2, and T3 (see Figure 5-3 Motor Connections).

Note that a direct connection between the drive and motor without any other device is an acceptable means of controlling the motor, but local safety regulations may require the use of a motor isolation switch or contactor to provide a way to ensure that power is removed from the motor prior to servicing the tower.


The following warnings illustrate the things to consider when using a permanent magnet motor over an induction motor. Please review these warnings carefully before operating the permanent magnet cooling tower motor.

- WARNING:** Motor circuit may have high voltage present whenever AC power is applied, even when motor is not rotating. Electrical shock can cause serious or fatal injury.
- WARNING:** RPM AC permanent magnet motors can induce voltage and current in the motor leads by rotating the motor shaft. Electrical shock can cause serious or fatal injury. Therefore, do not couple the load to the motor shaft until all motor connections have been made. During any maintenance inspections, be sure the motor shaft will not rotate.
- WARNING:** If an output motor isolation contactor is installed, the control must be disabled for at least 200mSec before the contactor is opened. If the contactor is opened while the control is supplying voltage and current to the motor, the control may be damaged. Before the control is enabled, the contactor must be closed for at least 200mSec.
- WARNING:** If an output motor isolation disconnect switch is installed, the control must be disabled for at least 200mSec before the switch is opened. If the switch is opened while the control is supplying voltage and current to the motor, the control may be damaged. Before the control is enabled, the switch must be closed for at least 200mSec.

Example connection diagrams are shown later in this guide.

The wire leads that connect the motor to the control are critical in terms of sizing, shielding and the cable characteristics.

Figure 5-3 Motor Connections



5.5.1 Protecting the Motor Insulation and Bearings

The drive employs modern IGBT inverter technology. Regardless of frequency, the drive output comprises pulses of approximately the drive DC bus voltage with a very short rise time. The pulse voltage can almost double at the motor terminals, depending on the attenuation and reflection properties of the motor cable and the terminals. This can cause additional stress on the motor and motor cable insulation. Modern variable speed drives with their fast rising voltage pulses and high switching frequencies can generate current pulses that flow through the motor bearings. This can gradually erode the bearing races and rolling elements. Optional du/dt filters protect motor insulation system and reduce bearing currents. Optional common mode filters mainly reduce bearing currents. Insulated N-end (non-drive end) bearings protect the motor bearings. Cooling tower motors are also available with optional grounding brushes and insulated bearings, which also reduce bearing currents.

Chapter 6

Control Wiring

This section outlines the basics of the control wiring for the ACS880+N5350. Sample wiring diagrams are shown later in this guide.

6.1 Motor Thermostat

RPM AC permanent magnet cooling tower motors are provided with thermostats in the stator windings that operate should the motor overheat. The thermostats are dry contacts designed to provide a closed (short) circuit when the motor is at a safe temperature and an open circuit should the motor overheat. Dedicated connections are provided for a series connection of these leads within the ACS880+N5350. All ACS880+N5350 drives must be used with motor overtemperature sensing by correctly connecting the RPM AC cooling tower motor thermostats to the XD24-1 and XD24-2 terminals. The terminal designations for the motor thermostat connections are XD24-1 and XD24-2 within the ACS880+N5350. The thermostat wiring between the motor and the control must be run in a conduit separate from the motor power leads to avoid noise related problems with the system.

6.2 Digital Inputs


The ACS880+N5350 is supplied with 9 digital inputs for controlling the cooling tower fan. The connections for these digital inputs are made on terminals XD24, XD10 and XDI. XDIO-1 & 2 terminals are dedicated to trickle current and de-ice enable inputs and cannot be changed. XDI-6 is shipped as an External Trip input as discussed in the next section and it is recommended that this not be changed. The definitions of inputs on XDI-1 through XDI-5 are determined by the selected operating mode of the drive. Operating mode selection is used to easily select a pre-configured setup of the drive thus minimizing the programming required to commission the control. The available operating modes are described later in this guide.

The digital inputs are shipped as “active high” (NPN) inputs. This means that an input signal is true when it is connected to XD24-4 (Internal 24VDC Source). Conversely, the digital inputs can be set up to be “active high” inputs. In this case, an input signal is true or when it is connected to the +24VDC power of a customer provided power source that is being used to control the digital inputs.

Switch J6 on the control board are used to set up the digital inputs. If the inputs are to be controlled as “active high” signals utilizing the internal supply of the ACS880+N5350, then no changes to the jumpers will be required. To set up the digital inputs for other methods of control, reference Figure 6-2 for the jumper settings and the connections required to the customer supplied inputs and power source.

Figure 6-1 Ground Isolation Diagram

Ground isolation diagram



Switch J6 settings:

- All digital inputs and outputs share a common ground.
- Ground of digital inputs DI1...DI5 and DIIL (DICOM) is separated from the DIO signal ground (DIOGND) (insulation voltage 50V). Inputs are "active low" when 24VDC connected to DICOM.

Table 6-1 Jumpers and Switches

Jumper/ Switch	Description	Positions	
J1 (AI1)	Determines whether analog input AI1 is used as a current or voltage input.		Current (I)
			Voltage (U) (Default)
J2 (AI2)	Determines whether analog input AI2 is used as a current or voltage input.		Current (I) (Default)
			Voltage (U)
J3	Drive-to-drive link termination. Must be set to terminated position when the drive is the last unit on the link.		Bus is terminated.
			Bus is not terminated.
J6	Common digital input ground selection switch. Determines whether DICOM is separated from DIOGND (i.e., common reference for digital inputs floats). See Ground isolation diagram in Appendix A.		DICOM and DIOGND connected (Default),
			DICOM and DIOGND separated.

Notes:

1. Current [0(4)...20mA, $R_{in} > 100\text{ohm}$] or voltage [0(2)...10V, $R_{in} > 200\text{kohm}$] input selected with jumper J1. Change of setting requires reboot of control unit.
2. Current [0(4)...20mA, $R_{in} > 100\text{ohm}$] or voltage [0(2)...10V, $R_{in} > 200\text{kohm}$] input selected with jumper J2. Change of setting requires reboot of control unit.
3. Total load capacity of these outputs is 4.8W (200mA / 24V) minus the power taken by DIO1 and DIO2.
4. 0 = open, 1 = closed

D13	Ramp times according to
0	Parameters 23.12 and 23.13
1	Parameters 23.14 and 23.15

Further information on the usage of the connectors and jumpers is given in the sections below.

6.2.1 Vibration Switch / External Trip

An input is provided within the ACS880+N5350 that forces the drive to fault should the circuit connected to this input open. The intent for this input is to interrupt the operation of the drive should a customer supplied circuit open. A typical use for this input is the connection of a vibration sensor. The input is for a dry contact type device. Power is not supplied to the external device from the ACS880+N5350 and power from the device must not be supplied to the drive terminals. If the external device requires power (e.g. 120VAC) then the installer must make provisions for this power from an alternate source.

Make the connections for the dry contacts of this external device between terminals XDI6 and XD24-4 when using the factory default active low configuration. The wiring for this device must be run in a conduit separate from the motor leads to avoid noise related problems with the system.

6.2.2 Other Digital Inputs

Remaining digital inputs that may be required for operating the ACS880+N5350 are specific to the selected operating mode and are outlined later in this guide.

6.3 Analog Inputs

An analog input is provided standard in the ACS880+N5350 for controlling the speed of the cooling tower fan if desired.

6.3.1 Analog Input 1

Analog Input 1 is capable of accepting a single-ended voltage signal on terminal XAI4 with respect to the analog common on terminal XAI3. Should the customer desire to control the speed of the fan with a potentiometer, a +10V reference signal is provided on terminal XAI1 is provided. It is recommended that a potentiometer with a resistance value > 200kΩ be used.

See Table 6-2 for jumper settings. See parameter 12.15 (AI1 Unit Selection Command) to select Analog Input 1 as the speed reference and parameters 12.17 through 12.20 to customize the scaling and filtering for this input.

Note: This signal can be ±10VDC or 0 to 20mA. The mode (voltage or current) is selected by jumper J1. For detailed information on hardware settings and software see manual.

Figure 6-2 depicts a potentiometer connection to Analog Input 1.

XAI Reference voltage and analog inputs		
1	+VREF	10VDC , R_L 1...10 kohm
2	-VREF	-10VDC , R_L 1...10 kohm
3	AGND	Ground
4	AI1+	Speed reference
5	AI1-	0(2)...10V, $R_{in} > 200$ kohm
6	AI2+	By default not in use
7	AI2-	0(4)...20mA, $R_{in} > 200$ kohm

Table 6-2 Analog Input 1 Technical Data

Reference voltage for analog inputs +VREF and -VREF (XAI:1)	Connector pitch 5mm, wire size 2.5mm ²
	10V ±1% and -10V ±1%, R_{load} 1...10kohm
Analog inputs AI1 (XAI:4...XAI:7) Current/voltage input mode selection by jumpers.	Connector pitch 5mm, wire size 2.5mm ²
	Current input: -20...20mA, R_{in} : 100ohm
	Voltage input: -10...10V, R_{in} : > 200kohm
	Differential inputs, common mode range ±30V
	Sampling interval per channel: 0.25ms
	Hardware filtering: 0.25ms, adjustable digital filtering up to 8ms
	Resolution: 11 bit + sign bit
Inaccuracy: 2% of full scale range	

6.4 ACS880+N5350 Relay Outputs

The ACS880+N5350 has the ability of reporting multiple internal states to the user by the use of relay outputs. For example, a relay can be set up to illuminate an external indicator light should the drive fault.

Three Form-C relay outputs are provided in the ACS880+N5350.

The functions of the relay outputs are selected by parameters 10.24 RO1 Source, 10.27 RO2 Source and 10.30 RO3 Source. For details on setting the Relay Output function see the ACS880 software manual.

Figure 6-3 depicts connections to the digital outputs for the various ways they can be used.

XR01, XR02, XR03 Relay outputs

1	NC		Ready
2	COM		250 VAC / 30 VDC
3	NO		2 A
1	NC		Running
2	COM		250 VAC / 30 VDC
3	NO		2 A
1	NC		Faulted (-1)
2	COM		250 VAC / 30 VDC
3	NO		2 A

Table 6-3 Relay Output Technical Data

Relay outputs RO1...RO3 (XR01...XR03)	Connector pitch 5mm, wire size 2.5mm ²
	250VAC / 30VDC, 2A
	Protected by varistors
+24V output (XD24:2 and XD24:4)	Connector pitch 5mm, wire size 2.5mm ²
	Total load capacity of these outputs is 4.8W (200mA / 24V) minus the power taken by DIO1 and DIO2.

6.5 ACS880+N5350 Analog Outputs

Two analog outputs are provided in the ACS880+N5350 that can be used by the customer to indicate the value of various signals within the drive. An example of usage of these signals is to use them to indicate motor speed and torque on remote meters or to a building control computer system.

Table 6-4 Analog Output Technical Data

Analog outputs AO1 and AO2 (XAO)	Connector pitch 5mm, wire size 2.5mm ²
	0...20mA, $R_{load} < 500\text{ohm}$
	Frequency range: 0...300Hz
	Resolution: 11 bit + sign bit
	Inaccuracy: 2% of full scale range

Figure 6-4 Analog Outputs

XAO		Analog outputs
1	A01	Motor speed rpm
2	AGND	0...20mA, $R_L > 500\text{ohm}$
3	A02	Motor torque
4	AGND	0...20mA, $R_L > 500\text{ohm}$

Current is proportional to torque on the Baldor-Reliance Interior Permanent Magnet Cooling Tower Motor.

Chapter 7

Applying Power Quick Install Guide

This guide instructs briefly how to install the drive. For more detailed instructions, engineering guide lines, technical data and complete safety instructions, see the hardware manual.

Follow the safety listed instructions in Chapter 1.

WARNING: Ignoring the following instructions can cause physical injury or death, or damage to the equipment.

WARNING: The floor material below the drive must be non-flammable.

7.1 Select the Power Cables

Select the power cables according to local regulations to carry the nominal current given on the type designation label of your drive.

7.2 Ensure Proper Cooling

See Table 3-3 for the losses and the cooling air flow through the drive. The allowed operating temperature range of the drive without derating is -5°F to +104°F.


7.3 Protect the Drive and Input Power Cable

See Table 5-2. Check that the operating time of the fuse is below 0.5 seconds.

7.4 Check the Insulation of the Input and Motor Cables and the Motor

Check the insulation of the input cable according to local regulations before connecting it to the drive. Check the insulation of the motor cable and motor when the cable is disconnected from the drive. Measure the insulation resistance between each phase conductor and the Protective Earth conductor using a measuring voltage of 1000VDC. The insulation resistance of an ABB motor must exceed 100 Mohm (reference value at 25°C or 77°F). For the insulation resistance of other motors, consult the manufacturer's instructions. Note: Moisture inside the motor casing will reduce the insulation resistance. If moisture is suspected, dry the motor and repeat the measurement.

Figure 7-1



7.5 Connect the Power Cables

See Figures 5-1 and 5-3.

1. Undo the two mounting screws at the sides of the front cover.
2. Remove the cover by sliding it forward.
3. Attach the residual voltage warning sticker in the local language to the control panel mounting platform.
4. Remove the rubber grommets from the lead-through plate for the cables to be connected.
5. Fasten the cable conduits to the cable lead-through plate holes. Strip the cable ends. Slide the cables through the connectors.
6. Connect the grounding conductors to the grounding terminals.
7. Connect the phase conductors of the input and motor cables. Tighten the screws.
8. Units with option +D150: Connect the brake resistor cable conductors to the R+ and R- terminals.
9. Install the control cable grounding shelf in the cable entry box.
10. Connect the motor cable at the motor end.

7.6 Connect the Control Cables


See Figure 4-4.

1. Fasten the cable conduits to the cable lead-through plate holes. Slide the cables through the connectors.
2. Strip the cable ends and cut to suitable length (note the extra length of the grounding conductors).
3. Ground the outer shields of all control cables 360 degrees at a grounding clamp in the cable entry box.
4. Ground the pair-cable shields to the grounding clamp. Leave the other end of the shields unconnected or ground them indirectly via a high-frequency capacitor with a few nanofarads, eg, 3.3nF / 630V.
5. Connect the conductors to the appropriate terminals of the control board.
6. Wire the optional modules if included in the delivery.
7. Reinstall the front cover.

7.7 Default I/O Connections

The default I/O connections of the 2-wire mode of the ACS880+N5350 primary control program are shown below.

Figure 7-2



Wire sizes: 0.5 ... 2.5mm²
(24...12AWG)
Tightening torques: 0.5 N·m (5lbf·in)
for both stranded and solid wiring.

Total load capacity of these outputs is 4.8W (200mA / 24V) minus the power taken by DIO1 and DIO2.

Must be Closed for the drive to Start.

Must be Closed for the drive to Start.

7.8 UL Checklist

- The drive is to be used in a heated, indoor controlled environment. The drive must be installed in clean air according to enclosure classification. Cooling air must be clean, free from corrosive materials and electrically conductive dust. See the hardware manual.
- The maximum ambient air temperature is 40°C (104°F) at rated current. The current is derated for 40°C to 55°C (104°F to 131°F).
- The drive is suitable for use in a circuit capable of delivering not more than 100,000 rms symmetrical amperes, 500V maximum. The ampere rating is based on tests done according to UL 508C.
- The cables located within the motor circuit must be rated for at least 75°C (167°F) in UL-compliant installations.
- The input cable must be protected with fuses. Circuit breakers must not be used without fuses in the USA. Suitable IEC (class aR) fuses and UL (class T) fuses are listed in the hardware manual. For suitable circuit breakers, contact your local ABB representative.
- For installation in the United States, branch circuit protection must be provided in accordance with the National Electrical Code (NEC) and any applicable local codes. To fulfill this requirement, use the UL classified fuses.
- For installation in Canada, branch circuit protection must be provided in accordance with the Canadian Electrical Code and any applicable provincial codes. To fulfill this requirement, use the UL classified fuses.
- The drive provides overload protection in accordance with the National Electrical Code (NEC).

Keypad and Programming

The ACS880+N5350 is supplied with a display combined with a keypad so that the status of the control can be monitored and parameters can be programmed. Additionally, the keypad can be used to control the cooling tower fan locally. This keypad can be left on the front cover of the drive, but is not required to operate the drive in the remote mode where control is accomplished using the drive terminal strip or via a network communications card.

8.1 Installation and Start-Up

This section describes how to install and start up the Assistant control panel for the first time.

8.1.1 Installation

You can attach the control panel directly to the drive or use a separate mounting kit (for example, for cabinet door mounting).

To attach the control panel,

1. place its bottom end into the bottom of the slot in the drive (A),
2. pivot the control panel and push the upper part (B) until you hear a click.

To detach the control panel,

1. release the control panel by pressing the clip (B),
2. pull the upper end of the control panel out of the slot in the drive.

Figure 8-1



8.1.2 First Start-Up


The following instructions explain how to start up the control panel for the first time.

1. Make sure that all drive-specific safety precautions have been taken into account.
2. Install the control panel as instructed in Installation.
3. Power up the drive.

The control panel start-up begins automatically. Wait until the control panel enters the language selection view.

Note: The language selection view only appears during the first start-up of the control panel, but it is possible to change the language later in the Settings menu (see parameter 96.01) or with the set-up assistant.

Figure 8-2



4. Use or to select a language.

5. Press (OK) to confirm your selection.


Wait until the control panel completes uploading the language file. Its progress is indicated by a progress bar.

Figure 8-3




There is a Basic set-up assistant in the drive that the control panel prompts to begin the Cooling Tower Assistant. Details on the assistant are contained in Chapter 12 of this manual.

Figure 8-4



Completing the assistant or Exiting returns you to the Home view. Once you are in the Home view, the control panel is ready for use.

Figure 8-5



To return to the assistant screen, select Menu → Assistants → CTDD Setup. Press Select to launch the assistant.

8.2 Control Panel Overview

This section describes the display, keys and main parts of the Assistant control panel.

Figure 8-6 Display, Keys and Parts




Table 8-1

1	Display	8	Start (see Start and Stop)
2	Left softkey	9	Local/Remote (see Loc/Rem)
3	Right softkey	10	USB connector
4	Status LED	11	Clip
5	Help	12	RJ-45 connector
6	Arrow keys	13	Type code label
7	Stop (see Start and Stop)	14	Battery cover

8.2.1 Display

In most views, the following elements are shown on the display:

Figure 8-7

Local	↶ CTDD	0.0 rpm
Output voltage	V	0.0
Motor current	A	0.00
Motor torque%	%	0.0
Options	00:00	Menu

1. **Control location:** Indicates how the drive is controlled:
 - Local: The drive is in local control, ie, controlled from the control panel.
 - Remote: The drive is in remote control, ie, controlled through I/O or fieldbus.
 - (Remote): The drive is in remote control (as above), but some commands (such as start, stop, direction change or reference) are configured to be controlled by the control panel.
2. **Status icon:** Indicates the status of the drive and the motor. The direction of the arrow indicates forward (clockwise) or reverse (counter-clockwise) rotation.

Table 8-2

Status Icon	Animation	Drive Status
	-	Stopped
	-	Stopped, start inhibited
	Blinking	Stopped, start command given but start inhibited
	Blinking	Faulted
	Blinking	Running, at reference, but the reference value is 0
	Rotating	Running, not at reference
	Rotating	Running, at reference

Note: For non-rotating driven equipment, the numbers 1 and 0 are used to indicate that the drive is running or stopped, respectively.

3. **Drive name:** If a name has been given, it is displayed in the top pane. By default, it is blank. You can change the name in the Settings menu.
4. **Reference value:** Speed, frequency, etc. is shown with its unit.
5. **Content area:** The actual content of the view is displayed in this area. The content varies from view to view. The example view above is the main view of the control panel which is called the Home view.
6. **Softkey selections:** Displays the functions of the softkeys (and) in a given context.
7. **Clock:** The clock displays the current time. The time can be changed through the Settings menu.

You can adjust the display contrast and backlight functionality in the Settings menu.

8.2.2 Keys

The keys of the control panel are described below.

Figure 8-8



8.2.2.1 Left Softkey

The left softkey () is usually used for exiting and canceling. Its function in a given situation is shown by the softkey selection in the bottom left corner of the display.

Holding down exits each view in turn until you are back in the Home view. This function does not work in special screens.

8.2.2.2 Right Softkey

The right softkey () is usually used for selecting, accepting and confirming. The function of the right softkey in a given situation is shown by the softkey selection in the bottom right corner of the display.

8.2.2.3 Arrow Keys

The up and down arrow keys ( and ) are used to highlight selections in menus and selection lists, to scroll up and down on text pages, and to adjust values when, for example, setting the time, entering a passcode or changing a parameter value.

The left and right arrow keys ( and ) are used to move the cursor left and right in parameter editing and to move forward and backward in assistants. In menus,  and  function the same way as  and , respectively.

8.2.2.4 Help

The help key () opens a help page. The help page is context-sensitive, in other words, the content of the page is relevant to the menu or view in question.

8.2.2.5 Start and Stop

In local control, the start key () and the stop key () start and stop the drive, respectively.

8.2.2.6 Loc/Rem

The location key () is used for switching the control between the control panel (Local) and remote connections (Remote). When switching from Remote to Local while the drive is running, the drive keeps running at the same speed. When switching from Local to Remote, the status of the remote location is adopted. See the drive-specific firmware manual for more details.

8.2.2.7 Key Shortcuts

The table below lists key shortcuts and combinations. Simultaneous key presses are indicated by the plus sign (+).

Table 8-3

Shortcut	Available in	Effect
 +  + 	Any view	Save a screenshot. Up to fifteen images may be stored in the control panel memory. For instructions on how to transfer the images into a PC, see section the ACS-AP-X assistant control panel manual.
 +   + 	Any view	Adjust backlight brightness.
 +   + 	Any view	Adjust display contrast.
 or 	Home view	Adjust reference.
 + 	Parameter edit views	Revert an editable parameter to its default value.
 + 	Any view	Show/hide parameter index and parameter group numbers.
 (keep down)	Any view	Return to Home view by pressing down the key until Home view is shown.

8.2.3 Status LED

The control panel has a status LED that indicates if there are any faults or warnings present. The table below shows the meaning of the LED indications.

Table 8-4 LED Indications

Green, Continuous		The drive is functioning normally.
Green, Flickering		Data is transferred between the PC tool and drive through the USB connection of the control panel.
Green, Blinking		There is an active warning in the drive.
Red, Continuous		There is an active fault in the drive.

For further information on fault and warning indications, see Chapter 13, Troubleshooting.

8.2.4 USB Connector

The USB connector is used for connecting the control panel to a PC. When connected, the control panel acts as an USB adapter for data transfer between the PC tool and the drive. It is also possible to transfer data between the PC and the control panel through the USB connection.

8.2.5 RJ-45 Connector

The RJ-45 connector is used to electrically connect the control panel to the drive. Mechanical connection is achieved with the clip on the top.

8.2.6 Type Code Label

The type code label contains revision information. The revision letter and the software version of the control panel are highlighted in the image below.

Figure 8-9




8.2.7 Battery Cover

Underneath the cover there is a compartment for the battery that powers the real-time clock of the control panel.

8.3 Local Control vs. Remote Control

The ACS880+N5350 is designed so that it can be run via keypad control (Local) or via the terminal strip or network communications (Remote). The Local/Remote Control can be changed by using the Local/Remote key on the keypad.

Figure 8-10 ACS880



8.3.1 Local Control

The control commands are given from the control panel keypad or from a PC equipped with Drive composer when the drive is set to local control. Speed control is available for local control.

Local control is mainly used during commissioning and maintenance. The control panel always overrides the external control signal sources when used in local control. Thermal and Vibration signals are still active.

By default the drive will fault if there is a control panel or PC tool communication break. See software manual if desired function is to be changed in parameter 49.05 (communication loss action).

8.3.2 Remote Control

When the drive is in remote control, control commands are given through:

- the I/O terminals (digital and analog inputs), or optional I/O extension modules
- or
- an optional fieldbus adapter module

The source for the Start/Stop and Speed Reference commands is selected using control operating modes. See Chapter 9 for available operating mode configurations.

8.4 Basic Operation

This section describes the basic operations and components of the user interface, lists common user tasks and gives short instructions on how to complete them.

8.4.1 User Interface Overview

The user interface has the following main components:

- The Home view through which you can monitor signals.
- The main Menu through which you can access most functions of the control panel. The Menu functions are described in detail in chapter Functions in the main Menu.
- The Options menu through which you can set a reference, change the motor direction, select the drive, edit Home view pages, and see the fault and warning status.
- The Help view which provides advice in many situations.
- Faults and warnings view which appear when the drive or the control panel experiences an error.

8.4.2 Control Panel Navigation

Use the arrow keys and softkeys for navigation. Follow the choices on the screen.

Figure 8-11

Home view



8.4.2.1 Navigation Memory

The Assistant control panel has a navigation memory that allows you to backtrack your steps through the user interface with the arrow keys (◀) and (▶). The path you have last accessed remains in the memory for 10 minutes.


- The left arrow key (◀) moves you backwards in the menu structure. If you press (◀) repeatedly, you return back to the Home view.
- The right arrow key (▶) moves you forward in the menu structure. If you press (▶) repeatedly, you move forward along the path in the menu structure you had previously accessed.

8.4.3 Home View

The main view of the control panel is called the Home view. In the Home view, you can monitor the status of the drive, such as its speed, torque or power. The Home view has nine pages, each of which can display a set of signals.

In the example below, three Home view pages are used, showing different display formats.

Figure 8-12



The Home view opens automatically when you power up the drive. The Home view is also displayed from the Options menu or the main Menu if no key is pressed for 10 minutes.

Tip: You can return to the Home view from any view except special screens by holding down the left softkey .

8.4.3.1 Navigating in the Home View

- Use and to move between the different pages of the Home view. The page numbers are shown while you scroll between pages.
- Use or to adjust the reference (visible in the top right corner).
- Press (Menu) to open the main Menu.
- Press (Options) to open the Options menu.

8.4.4 Help

You can open a context-sensitive help page in all menus and views by pressing . The help page provides information on the use of the current view or menu, or on possible problems associated with it.

On the help page, you can:

- Press again or (Exit) to exit.

8.4.5 Common User Tasks

This following tables list common user tasks and describes how to complete them.

8.4.5.1 Basic Operation of the Drive

Table 8-5

Task	Actions
Start and stop the drive.	In local control, press to start the drive and to stop the drive.
Set the reference (for example, speed) in the Home view.	In local control, go to Options > Reference. Set the reference with the arrow keys.
Switch between local and remote control.	Press .
Change the direction of motor rotation.	In local control, go to the Home view, press (Options) to open the Options menu and select Direction change.

8.4.5.2 Parameters

Table 8-6

Task	Actions
Choose parameters displayed on the Favorites list.	Go to Menu > Parameters > Favorites > Edit.
View/edit parameters.	Go to Menu > Parameters to view parameters.
Add parameters to the Home view.	See assistant panel manual.
Show/hide parameter index and group numbers.	Press + .
Restore parameter default value.	In the editing mode, press + . To save the default value, press (Save).
View parameters that differ from Application defaults.	Go to Menu > Parameters > Modified.

8.4.5.3 System Information and Help

Table 8-7

Task	Actions
How to get help.	Press to open the context-sensitive help.
View control panel version.	Go to Menu > System info > Control panel.
View drive information.	Go to Menu > System info > Drive.

8.4.5.4 Faults and Warnings

See Fault tracing in Chapter 13 for detailed information on faults and warnings.

Table 8-8

Task	Actions
Hide/view an active fault.	Faults are automatically displayed. If you hide a fault by pressing (Hide), it automatically reappears after 60 seconds of no key presses. You can also view the fault through Options > Fault status.
Open help page on a fault.	Press to view the help page.
Reset an active fault.	Press (Reset) to reset an active fault.
View tripping faults.	Go to Menu > Event log > Primary faults.
Hide/view and active warning.	Warnings are automatically displayed. If you hide a warning by pressing (Hide), it automatically reappears if the warning is still active after 60 seconds of no key presses.
Open help page on a warning.	Press (How to fix) or to view the help page.
Reset an active warning.	Warnings disappear automatically once the condition that has triggered it goes away.
View past warnings and faults.	Go to Menu > Event log > Other events.

8.4.5.5 Basic Settings and Assistants

Table 8-9

Task	Actions
Adjust backlight brightness.	Press + or .
Adjust display contrast.	Press + or .
Change language.	Go to Menu > Settings > Language.
Change time and date, and related settings.	Go to Menu > Settings > Date & time.
Launch an assistant.	Go to Menu > Assistants and select an assistant to launch.

Chapter 9

Operating Modes


The ACS880+N5350 can be placed in any one of 5 different operating modes. These modes are used to quickly set up the drive to operate from the drive terminal strip or from a network communications card. Many inputs are still programmable.

NOTE: Stop drive and place drive in “Local” before changing mode. Cycle power or reboot drive after changing mode.

CAUTION: Drive may start unexpectedly on changing mode.


9.1 2-Wire Operating Mode (Default)

Figure 9-1 ACS880+N5350 2-Wire Operating Mode Connection Diagram (76.03 = 1)



9.2 3-Wire Operating Mode

Figure 9-2 ACS880+N5350 3-Wire Operating Mode Connection Diagram (76.03 = 2)




9.3 Process Control (PID) Operating Mode

The process control mode provides an auxiliary closed loop general purpose PID set point control. The process control loop may be configured in various ways.

For details on setting parameters and adjusting PID configuration see the ACS880 software manual. Default I/O configurations are shown in the figure below.

Figure 9-3 Process Control Operating Mode Connection Diagram (76.03 = 3)



9.4 Fieldbus Operating Mode

The drive can be connected to an external control system through an optional fieldbus adapter mounted onto the control unit of the drive or via the Embedded Fieldbus (D2D Port – MODBUS – RTU Protocol). When Fieldbus Operating Mode is selected, the drive Starts and Stops using the Main Command Word, (6.01) bit 2, if DI2 is on for Remote Fieldbus Control. DI2(1) also selects FBA Ref1 as the speed reference. The drive actually has two independent interfaces for fieldbus connection called “fieldbus adapter A” (FBA A) and “fieldbus adapter B” (FBA B). Fieldbus adapters are available for various communication systems and Industrial Protocols, for example:


Fieldbus Adapters

FDNA-01	DeviceNet™ Adapter	K451
FPBA-01	PROFIBUS DP Adapter	K454
FCAN-01	CanOpen Adapter	K457
FSCA-01	Modbus Adapter, comes with a price when Built-in Modbus	K458
FCNA-01	ControlNet™ Adapter	K462
FECA-01	EtherCAT Adapter	K469
FEPL-02	Ethernet Powerlink Adapter	K470
FENA-21	Two-Port Ethernet Adapter (EtherNet/IP™, Modbus/TCP, PROFINET IO)	K475
FEIPO-21	Ethernet/IP	K490
FMBT-21	Modbus TCP/IP	K491
FPIO-21	Profinet I/O	K492

NOTES:

- Only Fieldbus Adapter A (FBA A or embedded Fieldbus (EFB) can be used to control the drive.
- Only the transparent 16 profile can be used with the ACS880+N5350 drive due to the fact that additional control word bits and status word bits are used in the CTDD Application that are not supported in other profiles.

Figure 9-4 Fieldbus Operating Mode Connection Diagram (76.03 = 4)



* Remote reference is FBA Ref1

** If only Remote Fieldbus Control is desired, DI2 and DI3 may be jumpered to +24 Vdc (XD24-4)

To activate Fieldbus Control Mode, set parameter 76.03 (Operating Mode) to either “Fieldbus” (for FBA-A or FBA-B Control) or to “EFB” (for Embedded Fieldbus Control).

In addition to Starting and Stopping the drive, it is also possible to Activate Trickle Current Heating or De-Ice Mode for Fieldbus Control Mode.

The Main Control Word (MCW) in the ACS880+N5350 CTDD Drive is different than that of a Standard ACS880. Three bits are available in the Control Word to control the drive as follows:

Main Control Word (MCW) Bit #	Function
0	Trickle Current Heating
1	De-Ice Mode
2	Start Forward
3-15	Not used

To be able to activate Trickle Current Heating over the Communications link, parameter 74.01 (Trickle Current Selection) must be set to FBA (for Fieldbus Adapter Modules) or to EFB (for the Embedded Fieldbus on the D2D Port).

To be able to activate De-Ice Mode over the Communications link, parameter 75.01 (De-Ice Selection) must be set to FBA (for Fieldbus Adapter Modules) or to EFB (for the Embedded Fieldbus on the D2D Port).

The Main Status Word (MSW) in the ACS880+N5350 CTDD Drive is different than that of a Standard ACS880. In addition to the Standard 9 Bits of the Status Word, the following additional Status Bits are available in the ACS880+N5350 CTDD Drive.

Bit	Name	Value	Description
0	Ready to switch ON	1	Ready to switch ON
		0	Not ready to switch ON
1	Ready run	1	Ready to operate
		0	OFF1 active
2	Ready ref	1	Operation enabled
		0	Operation inhibited
3	Tripped	1	Fault
		0	No Fault
4	OFF2 inactive	1	OFF2 inactive
		0	OFF2 active
5	OFF3 inactive	1	OFF3 inactive
		0	OFF3 active
6	Switch-on inhibited	1	Switch-on inhibited
		0	--
7	Warning	1	Warning active
		0	No warning active
8	At setpoint	1	Operating - Actual value equals reference = is within tolerance limits (see parameters 46.21 - 46.23)
		0	Actual value differs from reference = is outside tolerance limits
9	Remote	1	Drive control location: Remote (EXT1 or EXT2)
		0	Drive control location: Local
10	Trickle Current Active	0	Trickle Current OFF
		1	Trickle Current ON
11	De-Ice Mode Active	0	De-Ice Mode OFF
		1	De-Ice Mode ON
12	CTD Run	0	CTD Drive Not Running
		1	CTD Drive Running
13	CTD HOLD	0	CTD Autophase OFF
		1	CTD Autophase ON
14	User bit 3	-	See parameter 06.33 MSW bit 14 sel
15	Reserved		

9.4.1 Using Fieldbus Adapter Modules for Control of the Drive

If a Fieldbus Adapter Module is used to control and monitor the drive, the module must be configured in Group 50 and 51 (for FBA-A) or 54 (for FBA-B). Parameters that must be configured are shown below:

- Group 50 – Fieldbus Adapter
 - 50.01 (for FBA-A or 50.31 for FBA-B) must be set to the Option Slot that corresponds to the actual slot where the Fieldbus Adapter Module is physically installed.
 - 50.07 and 50.08 should be programmed to Transparent
 - 50.09 (for FBA-A or 50.39 for FBA-B) must be set to map to Parameter 6.11[16] to map the Status Word of the drive to the communication link
 - 50.10 (for FBA-A or 50.40 for FBA-B) must be set to map to Parameter 1.01[16] to map the Actual Speed Used of the drive to the communication link
 - 50.11 (for FBA-A or 50.40 for FBA-B) must be set to map to Parameter 1.10[16] to map the Motor Torque of the drive to the communication link
- Group 51 (for FBA-A) or Group 54 (for FBA-B)
 - 51.01 the Type of Fieldbus Adapter Module physically installed in the drive (Ethernet, Profibus, DeviceNet, etc.)
 - 51.02 must be set to match the protocol desired and the Transparent 16 Profile. For example, if Ethernet is used and the MODBUS-TCP Protocol is desired, then this parameter must be set to “MB/TCP T16”.

Important Note: Only the Transparent 16 Profile can be used with the ACS880+N5350 CTDD Drive due to the fact that additional Control Word Bits and Status Word Bits are used in the CTDD Application that are not supported in the other profiles.

- 51.03 and other subsequent parameters should be set to match the Baud Rate, Drive Drop Address, etc. of your specific Fieldbus Network. Please see the appropriate Fieldbus Adapter Module Manual for information on your specific Fieldbus Adapter.
- Group 52 – FBA-A Data In (or Group 55 – FBA-B Data In)
 - The first three Read Only Words moved over the communications link will be the Drive Status Word, the Actual Speed, and the Motor Torque.
 - To configure additional Read Only Words to be moved from the drive over the communications link, set parameters 52.01 up to 52.12 to the Read Only Parameters you wish to send over the communications link.
- Group 53 – FBA-A Data Out (or Group 55 – FBA-B Data Out)
 - The first two Words sent from the controller over the communications link to the drive will be the Control Word, and the Speed Reference. The third word is not used.
 - To configure additional Words to be sent from the controller over the communications link to the drive, set parameters 53.01 up to 53.12 to the Parameters you wish the drive to receive over the communications link.

After making changes to the Communications Groups (50 thru 55) always set parameter 51.27 to “Refresh” to update the drive and Fieldbus Modules to accept the changes and refresh the communications setup.

For an example setup using an Ethernet Fieldbus Adapter to control the drive over MODBUS-TCP Ethernet, please see Appendix E.

9.4.2 Using the Embedded Fieldbus Port to Control the Drive

If Embedded Field Port (EFB) is used to control and monitor the drive over MODBUS-RTU, the D2D port must be configured in Group 58. Parameters that must be configured are shown below:

- Group 58 – Embedded Fieldbus
 - 58.01 – Protocol Enable – Must be set to MODBUS-RTU.
 - 58.03 – Node Address – Should be set to match the desired Modbus Node Address of the drive.
 - 58.25 – Control Profile – Must be set to Transparent.
 - 58.26 – EFB Ref1 Type = Speed.
 - 58.28 – EFB Act1 Type = Speed.
 - 58.30 – Status Word Transparent – Should be mapped to Parameter 6.11 as a 16-bit Word (“6.11[16]”).
 - 58.31 – EFB Act1 Transparent Source – Should be mapped to Parameter 1.1 as a 16-bit Word (“1.1[16]”). This maps the Actual Motor Speed to the communications link.
 - 58.32 – EFB Act2 Transparent Source – Should be mapped to Parameter 1.10 as a 16-bit Word (“1.10[16]”). This maps the Motor Torque to the communications link.
 - 58.34 – Word Order – Should be set to HI-LO
 - 58.110 – Data I/O 10 – Should be mapped to Parameter 1.7 as a 16-bit Word (“1.7[16]”). This maps the Motor Current to the communications link.
 - 58.111 – Data I/O 11 – Should be mapped to Parameter 1.11 as a 16-bit Word (“1.11[16]”). This maps the DC Bus Voltage to the communications link.
 - 58.112 – Data I/O 12 – Should be mapped to Parameter 1.14 as a 16-bit Word (“1.4[16]”). This maps the Motor Power to the communications link.

Important Note: Only the Transparent 16 Profile can be used with the ACS880+N5350 CTDD Drive due to the fact that additional Control Word Bits and Status Word Bits are used in the CTDD Application that are not supported in the other profiles.

After making changes to the EFB Group (58) always set parameter 58.06 to “Refresh” to update the drive and EFB Port to accept the changes and refresh the communications setup.

For an example setup using an Ethernet Fieldbus Adapter to control the drive over MODBUS-RTU RS-485, please see Appendix F.

Chapter 10

Additional Setup

Once the motor has been identified to the drive and the operating mode chosen, the drive is ready to operate. Additional setup may be desired to enable trickle current heating when not running, for set up of skip frequencies during operation, and/or enabling De-Ice control function.

10.1 Trickle Current Heating

Trickle Current Heating is a feature of the ACS880+N5350 that can be used by the customer to maintain a small amount of power going to the motor from the drive while the fan is not being used. This feature will not cause fan rotation and aids in eliminating moisture in the motor. This eliminates the need for motor space heaters which are normally specified when a motor is placed in a humid environment.

Trickle Current Heating is disabled as a factory default since it depends on motor related information. Once enabled, trickle current will start flowing in the motor windings after the fan has been stopped. Note that the drive trickle current enable signal on XDIO1 must be present for trickle current to flow and (74.01) Trickle Current Enable = 1. Should the motor be restarted at any time (before or after the timer has expired) trickle current will immediately stop and the motor will start normally. In other words, the Run Command has priority over Trickle.

The below chart has traditionally been used to size space heaters for various frame motors and is equally applicable to deciding how much trickle current to the motor.

Table 10-1

Motor Frame Size	Wattage
FL250	75
FL280	100
FL320	125
FL360	150
FL400	175
FL440	225
FL5800	400

In addition to the wattage from the above table, the motor stator resistance value is needed. The stator resistance is taken from parameter 98.09 Rs user SI after ID run is complete.

Utilize the below calculation to check the trickle current value:

$$\text{Trickle Current} = \sqrt{\frac{\text{Wattage from Table 10-1}}{3 \times \text{Stator R}}}$$

The wattage from the above table can then be programmed into parameter 74.02 (Trickle Power). This will enable trickle current to flow in the motor after it has been stopped for time set in parameter 74.03 Trickle Delay Time. Note that the customer is limited to a current value that is no more than 100% of the motor rated current so that there is no danger in overheating the motor.

Should the motor be restarted at any time (before or after the timer has expired) trickle current will immediately stop and the motor will start normally.

Trickle current will not work while the motor is in Local, Trickle must be stopped before motor will start in Custom mode.

10.1.1 Parameter Settings

Trickle Current Enable (74.01)	Default: 0 (Disable) Range: 0 - 4
	0 (Disable) Disable trickle current
	1 (Enable) Enable trickle current whenever motor is not running
	3 (FBA) Enable trickle current over Fieldbus Adapter Module
4 (EFB) Enable trickle current over Embedded Fieldbus	


Trickle Power (74.02)	Default: 100W Range: 0 to 1000W
	The level of trickle current is determined by frame size of the motor.

Trickle Current Delay (74.03)	Default: 1 Min Range: 0 - 10 Min
	The time delay before trickle current starts. This delay ensures the motor has ramped down and stopped prior to trickle current beginning.

10.1.2 CTDD Assistant Access

In addition to programming changes in group 74, Trickle Current is an option under the CTDD startup assistant:

Figure 10-1 Trickle Current



10.2 Critical Speed Function

When applying a variable speed control to a cooling tower fan, mechanical resonances may occur at various points of operation. The ACS880+N5350 provides for up to three frequency avoidance bands that are used to prohibit continuous operation at the points of mechanical resonance.

While in LOCAL control, the keypad can be used to start and stop the drive and to locally adjust the speed.

Use the “UP” arrow key to slowly increase the speed of the motor. Should the cooling tower fan start to resonate, record the RPM. Continue this process until you have tested the motor at all points between minimum speed and maximum speed. The parameters that are used to provide for the critical speeds are located in the Speed Reference Selection Block (parameter numbers 22.51 through 22.57). Program a band around each point of resonance using parameter settings critical speed low and high.

For a more detailed description of these parameters see Chapter 12.

10.3 De-Ice Function

This is a cooling tower function to run at low speed in the opposite (reverse) direction than standard. This function is for prevention of ice build up in colder climates.

Set De-Ice Speed (75.02) to a value under 30% base motor speed.

Set the De-Ice Run Time (75.03) to the time desired for operation in this function.

Select a De-Ice Enabling Mechanism and see 75.01 accordingly.

When De-Ice is enabled with XDIO2 terminal Closed, the drive will enter De-Ice mode for the Run Time set in 75.03. If the drive has a valid Run Command applied at the same time as a De-Ice Command, the drive will run in De-Ice Mode (Reverse) for the specified time and then enter Run.

NOTE: De-Ice in Keypad Operation

The Keypad operates the CTDD drive in local control. To initiate De-Ice while using the Keypad, the drive must first be placed in remote control.

10.3.1 De-Ice Parameter Settings

De-Ice Enable (75.01)	Default: 0 (Disable) Range: 0 - 3
	0 (Disable) Disable De-Ice mode
	1 (DIO2) Enable De-Ice mode using DIO2
	2 (FBA) Enable De-Ice mode using Embedded Fieldbus
	3 (EFB) Enable De-Ice mode using Embedded Fieldbus
	Disable (0) disables the De-Ice function. If set to DIO2 (1), the Digital Input DIO2 will be used to enable the De-Ice function. If set to FBA (2), the De-Ice function is commanded via the Control Word of the Fieldbus Adapter Module. If set to EFB (3), the De-Ice function is commanded via the Copntrol Word of the Embedded Fieldbus.
De-Ice Speed (75.02)	Default: 30% Range: 0 to 100%
	De-Ice speed can be reprogrammed from 0% to 100% speed.
De-Ice Run Time (75.03)	Default: 1 Min. Range: 0 to 1500 Minutes
	Value of time to run in De-Ice function when Software Enable is active, and a hardware input is present. Drive will run at De-Ice function speed for the set run time and then shut down.

10.3.2 CTDD Assistant Access

In addition to programming changes in group 75, De-Ice function setup is an option under the CTDD startup assistant:

Figure 10-2 De-Ice Function

Local	 CTDD	50.0 rpm
De-Ice		
Set parameters for De-ice.		
Enable	Disabled	▶
De-Ice Speed	30%	▶
Run Time	1 min	▶
Minimum torque 1	-30.0 %	▶
Back	00:00	Next

10.4 Advanced Drive Settings

See ACS880 Software Manual, 3AUA0000085967, for information on advanced drive functions such as PID and Fieldbus control.

10.4.1 Access Levels

Access levels are based on CTDD USER, Fieldbus or Expert Commissioner. Selection for access level is contained in the 96.02 passcode parameter; accessible in the programming window (but not the startup assistant, passcode changes are for expert users only). Changing modes will automatically set access level.

There is no default setting for 96.02. Setting access level to 13 (Fieldbus) opens all Fieldbus applicable parameters. Expert Commissioner enables all parameters in the drive by setting 96.02 = 12. Expert Commissioner is set in PID and Custom modes.

Fieldbus operating mode opens up all parameters in groups 50 to 56 and monitoring parameters 3.05, 3.06, 6.01 and 6.11.

CTDD User Default Access Level

Pass Code (96.02)	
	Default: - Set to values below for access level
14	CTDD User
13	Fieldbus
12	Expert Commissioner


Parameter 96.03 shows the current access level setting, note ABB default will show active with the addition of the set level shown below. Value is offset by one from the password entered.

Access Level (96.03)	
	Default: Read Only Range: -
11	Expert Commissioner
12	Fieldbus
13	CTDD User

NOTE: The drive will reset to CTDD User on a power cycle.

10.4.2 Access Level Flow Diagram

Figure 10-3 Access Level Flow Diagram



10.4.3 Access Level Indication

The display will indicate the access level with a key symbol and access level:

Figure 10-4

 CTDD User

If no symbol is present, the ABB default access level is active.

Chapter 11

Example Connection Diagrams

The installation of the ACS880+N5350 is ultimately the responsibility of the user to ensure that it is installed in a manner that will provide a safe and trouble-free system that meets local safety and electrical codes. The information provided in this section is not intended to specifically dictate how the ACS880+N5350 is to be wired or even to imply that all safety factors have been considered since these may vary from one installation to another. These diagrams are provided so that the installer may visualize several possible ways the drive can be connected based upon the 2-Wire Operating Mode as well as the 3-Wire Operating Mode.

The devices external to the ACS880+N5350 and the RPM AC Cooling Tower Motor depicted in the following diagrams are considered user supplied unless they are ordered as a packaged drive from ABB or as separate line items. Contact your local ABB representative for support regarding the additional equipment or a packaged drive.


11.1 ACS880+N5350 2-Wire Operating Mode Example

The 2-Wire Operating Mode is provided for those customers that wish to control their cooling tower fan using what is traditionally called “2-Wire Control”. This method of control utilizes a single “Off – On” selector switch to stop / run the fan. On power loss to the drive, the drive will restart automatically when power is restored.

11.1.1 Manual Motor Disconnect Switch

This diagram depicts an example of using the 2-Wire Operating Mode along with a manual disconnect switch between the drive and the motor. The disconnect switch used in this diagram is a 3 position switch. The intent here is to provide one position that is used when the fan is actually being run by the ACS880+N5350. There is a neutral position where the motor leads are open circuit, and also a position which shorts the motor leads together. The position that shorts the leads together is used to prohibit hazardous voltages from being present on the motor leads when it is disconnected from the drive should the fan rotate. This could occur since the motor includes permanent magnets in its rotor thus giving it the characteristics of being a generator when not connected to a drive. Another benefit of this position is that it will cause the motor to resist windmilling. Note that it is required to provide an auxiliary contact on the disconnect switch that is open any time the motor is not connected to the drive. This contact needs to be of the “Late Make / Early Break” style such that the contacts on the auxiliary open before the power contacts open. Additionally, when the disconnect switch is closed, the power contacts of the disconnect switch must close prior to the closure of the auxiliary contact.

Figure 11-1 ACS880+N5350 2-Wire Manual Motor Disconnect Switch




11.2 ACS880+N5350 3-Wire Operating Mode Example

The 3-Wire Operating Mode is provided for those customers that wish to control their cooling tower fan using what is traditionally called “3-Wire Control”. This method of control utilizes a momentary normally open “Start” pushbutton to run the fan and a momentary normally closed “Stop” pushbutton to stop the fan. On power loss to the drive, the “start” pushbutton will restart the drive when power is restored.

11.2.1 Manual Motor Disconnect Switch

This diagram depicts an example of using the CTD 3-Wire Operating Mode along with a manual disconnect switch between the drive and the motor. The disconnect switch used in this diagram is a 3 position switch. The intent here is to provide one position that is used when the fan is actually being run by the ACS880+N5350. There is a neutral position where the motor leads are open circuit, and also a position which shorts the motor leads together. The position that shorts the leads together is used to prohibit hazardous voltages from being present on the motor leads when it is disconnected from the drive should the fan rotate. This could occur since the motor includes permanent magnets in its rotor thus giving it the characteristics of being a generator when not connected to a drive. Another benefit of this position is that it will cause the motor to resist windmilling. Note that it is required to provide an auxiliary contact on the disconnect switch that is open any time the motor is not connected to the drive. This contact needs to be of the “Late Make / Early Break” style such that the contacts on the auxiliary open before the power contacts open. Additionally, when the disconnect switch is closed, the power contacts of the disconnect switch must close prior to the closure of the auxiliary contact.

Figure 11-2 ACS880+N5350 3-Wire Manual Motor Disconnect Switch



11.3 Motor Contactor or Shorting Contactor Examples

The following configurations are intended as examples on providing a manual motor disconnect or a power off fail safe shorting contactor. These approaches can be used independent of the drive starting mode or reference source and are not tied directly to the drive controller. Figure 11-3 depicts the preferred usage of a shorting contactor and a motor disconnect when used with the ACS880+N5350 drive.

11.3.1 Manual Motor Disconnect Switch


The motor disconnect should be located remotely from the drive panel, within site of the direct drive RPM AC motor and driven load. This is in compliance with National Electric Code Sections 420.102 to 430.109. The switch should only be shorted after the ACS880+N5350 drive has been powered down or de-activated by opening the enable input.

11.3.2 Shorting Contactor

The intent of the Shorting Contactor is to provide one position (open) that is used when the fan is being run by the ACS880+N5350. This is the normal power on state. The other power off position (closed) shorts the motor leads together.

For both the options, the position that shorts the leads together is used to prohibit hazardous voltages from being present on the motor leads when it is disconnected from the drive should the fan rotate. This could occur since the motor includes permanent magnets in its rotor thus giving it the characteristics of being a generator when not connected to a drive. Another benefit of this position is that it will cause the motor to resist wind-milling.

Figure 11-3 Motor Contactor Example



Chapter 12

Startup Assistant & Parameters

12.1 Startup Assistants Guide for ACS880+N5350

This chapter describes the basic start-up assistants for motor data and ID run; and setting up the ACS880 drive equipped with +N5350 cooling tower program. In this guide, the drive is set up using the ACS-AP-I control panel. Complete documentation of the drive firmware can be found in Firmware manual, 3AUA0000085967.

Never work on the drive, the braking chopper circuit, the motor cable or the motor when power is applied to the drive. Always ensure by measuring that no voltage is actually present.

Note: Before you start ensure that the drive has been mechanically and electrically installed as described in the appropriate sections of this manual.



WARNING: All electrical installation and maintenance work on the drive should be carried out by qualified electricians.

12.1.1 Motor Data and ID Run

On initial startup, the drive automatically goes into the Motor data setup.

Table 12-1 Initial Start-up / Motor Data and ID Run

Safety	
	The start-up may only be carried out by a qualified electrician. The safety instructions must be followed during the start-up procedure. See the safety instructions on the first pages of the appropriate Hardware manual.
<input type="checkbox"/>	Check the installation. See the installation checklist in the appropriate Hardware manual.
<input type="checkbox"/>	Check that the starting of the motor does not cause any danger. De-couple the driven machine if there is a risk of damage in case of an incorrect direction of rotation.
Power-Up, Date and Time Settings	
<input type="checkbox"/>	<p>Power up the drive.</p> <p>On initial power up the cooling tower drive requests a language selection for the setup process.</p>
<input type="checkbox"/>	<p>Select language using and and press (continue) to accept.</p> <p>The drive will load the selected language; this may take a few minutes.</p> <p>ABB loading screen will appear after the language selection completes.</p>

Table 12-1 Initial Start-up / Motor Data and ID Run




<p>On initial startup, the drive goes into the Motor data setup. and this screen will not be shown.</p> <p>Note: This screen will not show on first startup.</p> <p>On subsequent startups, select “Motor Data and ID Run” from the Assistants menu, which is located off of the main menu.</p>		
<p><input type="checkbox"/></p>	<p>Motor Data and ID Run Assistant will load. Press  (continue) to begin the cooling tower startup assistant.</p>	
<p><input type="checkbox"/></p>	<p>Press  (next) to start the set-up assistant.</p>	

Table 12-1 Initial Start-up / Motor Data and ID Run





<p>☐</p>	<p>In the Date & Time menu, use the to highlight the value to edit. It is recommended to set the current date & time so that faults & alarms can provide accurate time stamps. Highlight date and press to edit or (next) to continued.</p> <p>In the month screen use to select the value for editing. Use to modify the value. Pressing (save) returns to the date & time menu.</p> <p>This screen is only visible the first time the Motor Data assistant is run.</p>	 <p>Date & Time Please enter the current date and time.</p> <p>Date 01.01.2014 ▶ Time 12:34:56 ▶ Show date as day.month.year ▶ Show time as 24-hour ▶</p> <p>Exit 00:00 Next</p>  <p>Date Month day Year 03/20/2014 Thursday</p> <p>Cancel 00:00 Save</p>
<p>☐</p>	<p>Confirm language selection. Highlight the language with the and press (continue).</p>	 <p>Local CTDD 0.0 rpm</p> <p>Language Language changes take some time. Not selected English Deutsch Italiano</p> <p>Exit 00:00 Next</p>
<p>Unit Selection</p>		
<p>☐</p>	<p>Confirm local units. Highlight selection with the and press (next).</p>	 <p>Local CTDD 0.0 rpm</p> <p>Localization Unit Defaults: US standard (Imperial) International (SI)</p> <p>Exit 00:00 Next</p>

Table 12-1 Initial Start-up / Motor Data and ID Run

<p><input type="checkbox"/> Highlight the desired unit with the and press (next).</p> <p>Use to move between the units. Use to select the value for editing.</p> <p>Pressing (save) returns to the unit selection menu.</p>	<p>Local CTDD 0.0 rpm</p> <p>Units </p> <p>Change the display units if needed.</p> <p>Unit Selection</p> <p>0000 0000 0001 00011 </p> <p>Tariff currency unit USD </p> <p>All unit selection V </p> <p>Back 00:00 Next</p>																				
<p>Supply Voltage Settings</p>																					
<p><input type="checkbox"/> Press to edit the supply voltage input to the CTDD drive.</p> <p>Note: For 460...480 V, it is recommended that supply voltage is set to 500 V.</p>	<p>Local CTDD 0.0 rpm</p> <p>Supply voltage </p> <p>Set supply voltage.</p> <p>Supply voltage 500 V </p> <p>Back 00:00 Next</p>																				
<p>Motor Data Settings</p>																					
<p>Refer to the motor nameplate for the following parameter settings. Whenever possible, enter the values exactly as shown on the motor nameplate.</p>																					
<p>Example of a nameplate of a Back-EMF motor:</p> <div style="border: 1px solid black; border-radius: 15px; padding: 10px; text-align: center;"> <p>WARNING</p> <p>PERMANENT MAGNET MOTOR WHEN SHAFT IS ROTATED, VOLTAGE WILL BE GENERATED AT THE MOTOR TERMINALS. MEASURED OPEN CIRCUIT VOLTAGE IS _____ VOLTS AT _____ RPM. MOTOR PHASE CURRENT SHOULD NOT EXCEED _____ AMPS RMS PEAK TO AVOID DEMAGNETIZATION. patent US 7,385,328</p> <p style="font-size: small;">000692-000VY</p> </div>	<p>Example of a nameplate of a permanent magnet motor:</p> <div style="border: 1px solid black; border-radius: 15px; padding: 10px;"> <p style="text-align: center;">BALDOR • RELIANCE</p> <p style="text-align: center;">RPMAC™ INVERTER DUTY</p> <p style="text-align: center; font-size: small;">BALDOR ELECTRIC CO • FT. SMITH, AR. MFG. IN U.S.A.</p> <table border="1" style="width: 100%; border-collapse: collapse; font-size: x-small;"> <thead> <tr> <th>DUTY</th> <th>HP</th> <th>RPM</th> <th>AMPS</th> <th>VOLTS</th> <th>HZ</th> </tr> </thead> <tbody> <tr> <td> </td> <td> </td> <td> </td> <td> </td> <td> </td> <td> </td> </tr> </tbody> </table> <p style="font-size: x-small;">CAT. NO. _____ SPEC. NO. _____</p> <p style="font-size: x-small;">SER. NO. _____ FR. _____ INSUL. _____</p> <table border="1" style="width: 100%; border-collapse: collapse; font-size: x-small;"> <tr> <td>PH.</td> <td>MAX. SAFE SPEED</td> <td>AMB. °C</td> <td>MIN. AMB. °C</td> </tr> <tr> <td> </td> <td> </td> <td> </td> <td> </td> </tr> </table> <p style="font-size: x-small;">DESIGN NO. _____ TYPE _____ ENCL. _____</p> <p style="font-size: x-small;">S.F. _____ D.E. BRG. _____</p> <p style="font-size: x-small;">ENCL. MOD. _____ O.D.E. BRG. _____</p> <p style="font-size: x-small;">MINIMUM AIRFLOW VELOCITY _____ FT. PER MINUTE</p> <p style="font-size: x-small;">PATENT US 7,880,348 B2 PLANT 15</p> </div>	DUTY	HP	RPM	AMPS	VOLTS	HZ							PH.	MAX. SAFE SPEED	AMB. °C	MIN. AMB. °C				
DUTY	HP	RPM	AMPS	VOLTS	HZ																
PH.	MAX. SAFE SPEED	AMB. °C	MIN. AMB. °C																		

Table 12-1 Initial Start-up / Motor Data and ID Run

<p><input type="checkbox"/> Highlight the motor value to be edited using keys. Use to edit the values.</p> <p>Use and to change the value of a digit. Use and to move the cursor left and right. Press (save) to enter the value.</p> <p>Important! Motor Back EMF voltage (located on the motor nameplate) is critical to the successful operation of the cooling tower motor. Please record this data here for future reference.</p> <p>Back EMF Voltage: _____</p> <p>Motor Serial Number: _____</p> <p>Note: Back EMF Voltage is referred to as Measured Open Circuit Voltage on the motor nameplate.</p>	<div style="border: 1px solid black; padding: 5px;"> <p>Local CTDD 50.0 rpm</p> <hr/> <p>Motor data </p> <p>Check the values from the motor's nameplate, and enter them here.</p> <p>Motor Type PMSM </p> <p>Back EMF voltage 360.0 V </p> <p>Motor nominal current 1.3 A </p> <hr/> <p>Back 00:00 Next</p> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <p>Local CTDD 0.0 rpm</p> <hr/> <p>99.07 Motor Back EMF voltage</p> <p style="font-size: 2em; text-align: center;">000.0 v</p> <p style="text-align: center;">80.0 960.0</p> <hr/> <p>Cancel 00:00 Save</p> </div>
<p>Motor ID Run</p>	
<p><input type="checkbox"/> Autophasing</p> <p>The drive is now ready to run the motor identification routine (ID run). During the ID run, the motor is injected with DC current. Autophase stops the rotor prior to the ID run.</p> <p>Note: Autophase time has a default of 15 seconds. It is best to observe the time it takes the fan to stop moving and use this as an accurate autophase time. Use the keys to move between selections. Use to select the value to edit.</p>	<div style="border: 1px solid black; padding: 5px;"> <p>Local CTDD 50.0 rpm</p> <hr/> <p>Autophasing </p> <p>Select parameters for autophasing.</p> <p>Autophasing Current 50% </p> <p>Autophasing Time 15 S </p> <hr/> <p>Back 00:00 Next</p> </div>

Table 12-1 Initial Start-up / Motor Data and ID Run

<input type="checkbox"/>	<p>Motor ID Run</p> <p>The drive is now ready to run the motor identification routine (ID run). The motor is injected with DC current.</p> <p>Use the  key to select Standstill ID run and then press  (next).</p> <p>Note: On initial startup, an ID run must be performed and Next will not advance to next step.</p>	<div style="border: 1px solid black; padding: 5px;"> <p>Local  CTDD 50.0 rpm</p> <hr/> <p>ID run? </p> <p>None XXXXXXXXXX</p> <p>Standstill ID run</p> <hr/> <p>Back 00:00 Next</p> </div> <div style="border: 1px solid black; padding: 5px;"> <p>Local  CTDD 50.0 rpm</p> <hr/> <p>ID run? </p> <p>None</p> <p>Standstill ID run XXXXXXXXXX</p> <hr/> <p>Back 00:00 Next</p> </div>
<input type="checkbox"/>	<p>Motor ID Run</p> <p>No command rotation is given, however with a permanent magnet motor the shaft could rotate up to half a revolution.</p> <p>You must press Local Keypad START to activate ID Run.</p> <p>Note: ID Run requires Local control, press  if the Keypad does not indicated local control is active.</p> <p>Next is not visible until ID run is performed once.</p>	<div style="border: 1px solid black; padding: 5px;"> <p>Local  CTDD 50.0 rpm</p> <hr/> <p>Press Start for ID run </p> <p>When you press Start, the motor is injected with DC Current for about 1 minute, and may Rotate up to half a Revolution. After the ID run the drive stops.</p> <hr/> <p>Back 00:00 Next</p> </div>

Table 12-1 Initial Start-up / Motor Data and ID Run

<p>□ The ID run in progress screen will automatically display showing speed and amps.</p> <p>The screen will also indicate if an ID run has been completed before. If not, it will read “none”. If a run has been completed, it will read “Standstill”.</p> <p>When ID run is complete, the next screen will be displayed.</p>	<div style="border: 1px solid black; padding: 5px;"> <p>Local  CTDD 50.0 rpm</p> <hr/> <p>ID run in progress...</p> <p>01.01 Motor speed used 0.00 rpm ▶</p> <p>01.07 Motor current 0.00 A ▶</p> <p>99.14 Last ID run performed None ▶</p> <hr/> <p>Back 00:00</p> </div> <div style="border: 1px solid black; padding: 5px;"> <p>Local  CTDD 50.0 rpm</p> <hr/> <p>ID run in progress...</p> <p>01.01 Motor speed used 0.00 rpm ▶</p> <p>01.07 Motor current 0.00 A ▶</p> <p>99.14 Last ID run performed None ▶</p> <hr/> <p style="text-align: center;"> ID run done</p> <hr/> <p>Exit 00:00</p> </div>
<p>NOTE: If the motor data is incorrect, after pressing , the display will indicate check motor parameters. Press  (exit) and check that the motor information is correct.</p>	<div style="border: 1px solid black; padding: 5px;"> <p>Local  CTDD 0.0 rpm</p> <hr/> <p>Check the motor param... <input type="text"/></p> <p>The motor parameters are probably set incorrectly. Check the parameters.</p> <hr/> <p>Exit 00:00 Check params</p> </div>

Table 12-1 Initial Start-up / Motor Data and ID Run

<input type="checkbox"/>	<p>Direction Test</p> <p>NOTE: The Autophasing delay occurs everytime the motor starts, including direction testing.</p> <p>Use the  key to perform a direction test of the rotation of the motor. Then press  (next).</p>	<div style="border: 1px solid black; padding: 5px;"> <p>Local  CTDD 50.0 rpm</p> <hr/> <p>Direction test </p> <p>Spin the motor to check direction</p> <p>No, skip the test</p> <p>Yes, test now</p> <hr/> <p>Back 00:00 Next</p> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <p>Local  CTDD 50.0 rpm</p> <hr/> <p>Direction test </p> <p>Spin the motor to check direction</p> <p>No, skip the test</p> <p>Yes, test now</p> <hr/> <p>Back 00:00 Next</p> </div>
<input type="checkbox"/>	<p>The following warning message will appear.</p> <p>Press START to check direction of the motor.</p> <p>A screen will appear next asking if the motor is running in the correct direction.</p>	<div style="border: 1px solid black; padding: 5px;"> <p>Local  CTDD 50.0 rpm</p> <hr/> <p>Press Start </p> <p>Warning! Until set-up is done, safeties are not activate and motor speed is limited between 1/3 to 2/3 speed. Press Start now to start the motor, then check the direction of rotation.</p> <hr/> <p>Back 00:00 Next</p> </div>
<input type="checkbox"/>	<p>Motor set-up is complete.</p> <p>To exit and save all data, select  (Done).</p> <p>To exit without saving data, select  (cancel).</p>	<div style="border: 1px solid black; padding: 5px;"> <p>Local  CTDD 50.0 rpm</p> <hr/> <p>Motor set-up complete </p> <p>Connect I/O according to the User Manual.</p> <hr/> <p>Cancel 00:00 Done</p> </div>
<p>NOTE: After initial startup sequencing a new power-up will initiate the standard CTDD startup mode (see Table 12-2).</p>		

12.1.2 Drive Assistant

Selecting drive assistant (CTDD) will display the cooling tower application assistant. After motor data start-up, the applicaiton is only capable of 2-wire functionality with no options.

Table 12-2 Drive Assistant

Safety	
	The start-up may only be carried out by a qualified electrician. The safety instructions must be followed during the start-up procedure. See the safety instructions on the first pages of the appropriate Hardware manual.
<input type="checkbox"/>	Check the installation. See the installation checklist in the appropriate Hardware manual.
<input type="checkbox"/>	Check that the starting of the motor does not cause any danger. De-couple the driven machine if there is a risk of damage in case of an incorrect direction of rotation.
Power-Up, Date and Time Settings	
<input type="checkbox"/>	Power up the drive. Main Menu Screen appears. Select "Assistants" from the main menu.
<input type="checkbox"/>	Select assistant to run. Selecting the CTDD Setup will display the cooling tower application assistant.
	<div style="display: flex; justify-content: space-between;"> Remote  CTDD 0.0 rpm </div> <hr/> <p>Assistants _____</p> <p>Motor Data & ID Run</p> <p>CTDD Setup ████████████████████</p> <hr/> <div style="display: flex; justify-content: space-between;"> Back 00:00 Select </div>
<input type="checkbox"/>	In the assistant view, press  (continue) to enter the Startup Assistant. Note: To leave the assistant, press  (exit) and go back to the Home screen.
	<div style="display: flex; justify-content: space-between;"> Local  CTDD 0.0 rpm </div> <hr/> <p>Drive Set-up ████████████████████</p> <p>Use arrow keys and soft keys to navigate the assistant.</p> <hr/> <div style="display: flex; justify-content: space-between;"> Exit 00:00 Continue </div>

Table 12-2 Drive Assistant




<p>□</p>	<p>Press  (next) to start the set-up assistant.</p> <p>“Restore” will reload all default parameters except for motor data.</p>	
<p>□</p>	<p>In the Date & Time menu, use the   to highlight the value to edit. It is recommended to set the current date & time so that faults & alarms can provide accurate time stamps. Highlight date and press  to edit or  (next) to continued.</p> <p>In the month screen use   to select the value for editing. Use   to modify the value. Pressing  (save) returns to the date & time menu.</p> <p>(See Motor Data)</p>	
<p>□</p>	<p>Highlight the language with the   and press  (continued).</p>	
<p>NOTE: After editing all desired date & time values, press  (next) to continue.</p>		

Table 12-2 Drive Assistant

Drive Limit Settings	
<p><input type="checkbox"/> The CTDD will automatically set limits according to motor data entered. For most CTDD applications, the default values are acceptable. However, values are adjustable within Limits:</p> <p>Minimum Speed ≥ 10% Motor Speed Maximum Speed ≤ Motor Speed Minimum Torque set to -30% (adjustable) Maximum Torque set to 110% (adjustable)</p> <p>Use the   to highlight the ramp rate to be adjusted. Press  to enter the edit screen once highlighted or  (next) if the default value is acceptable.</p>	<div style="border: 1px solid black; padding: 5px;"> <p>Local  CTDD 50.0 rpm</p> <hr/> <p>Limits </p> <p>CT Minimum Speed 50.00 rpm </p> <p>Maximum speed 500.00 rpm </p> <p>Minimum torque -30.0 % </p> <p>Maximum torque 110.0 % </p> <hr/> <p>Back 00:00 Next</p> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <p>Local  CTDD 50.0 rpm</p> <hr/> <p>Limits </p> <p>Maximum torque 110.0 % </p> <p>Acceleration time 1 100.000 s </p> <p>Deceleration time 1 100.000 s </p> <p>Acceleration time 2 100.000 s </p> <p>Deceleration time 2 100.000 s </p> <hr/> <p>Back 00:00 Next</p> </div>
<p><input type="checkbox"/> Naming the Drive</p> <p>The default drive name is CTDD. Use  to edit the drive name or  (next) to continue.</p>	<div style="border: 1px solid black; padding: 5px;"> <p>Local  CTDD 50.0 rpm</p> <hr/> <p>Naming the drive </p> <p>The name will show at the top of the panel screen, making it easier to see which motor this drive controls.</p> <p>Drive name CTDD </p> <hr/> <p>Back 00:00 Next</p> </div>
Selecting Operating Mode	
<p><input type="checkbox"/> Select Operating Mode</p> <p>Operating modes are sets of default wire and parameters suitable for most CTDD applications.</p> <p>The active operating mode is displayed, (2-wire) default. If this is correct, press  (next). To edit the operating mode press .</p> <p>Caution: Ensure drive is stopped and in Local before changing mode. Drive could unexpectedly start when changing mode.</p>	<div style="border: 1px solid black; padding: 5px;"> <p>Local  CTDD 50.0 rpm</p> <hr/> <p>Select Operating Mode </p> <p>Select mode below.</p> <p>Operating Mode 2-Wire </p> <hr/> <p>Back 00:00 Next</p> </div>

Table 12-2 Drive Assistant

<p><input type="checkbox"/> Highlight the operating mode suitable to the application and press save.</p> <p>Press  (save) to select.</p> <p>If mode was changed, cycle power to drive after setup is complete.</p>	<table border="1"> <tr> <td>Local</td> <td> CTDD</td> <td>50.0 rpm</td> </tr> <tr> <td colspan="3">76.03 Operating Mode</td> </tr> <tr> <td colspan="3">[1] 2-Wire</td> </tr> <tr> <td colspan="3">[7] 3-Wire</td> </tr> <tr> <td colspan="3">[8] PID</td> </tr> <tr> <td colspan="3">[9] Fieldbus</td> </tr> <tr> <td>Cancel</td> <td>00:00</td> <td>Save</td> </tr> </table>	Local	 CTDD	50.0 rpm	76.03 Operating Mode			[1] 2-Wire			[7] 3-Wire			[8] PID			[9] Fieldbus			Cancel	00:00	Save			
Local	 CTDD	50.0 rpm																							
76.03 Operating Mode																									
[1] 2-Wire																									
[7] 3-Wire																									
[8] PID																									
[9] Fieldbus																									
Cancel	00:00	Save																							
<p>Additional Settings & Parameter Backup</p>																									
<p><input type="checkbox"/> Trickle Current Function</p> <p>Primary purpose is to prevent fan rotation during standby condition and to prevent condensation in the motor. Use the  to enable the function in software. Highlight enable or fieldbus and press  (save). Use   to highlight trickle power and  to set the level. Refer to Chapter 10 or parameter group 74 for proper setup of this function. When finished, press  (next) to continue.</p>	<table border="1"> <tr> <td>Local</td> <td> CTDD</td> <td>50.0 rpm</td> </tr> <tr> <td colspan="3">Trickle Current</td> </tr> <tr> <td colspan="3">Set parameters for Trickle Current.</td> </tr> <tr> <td colspan="3">Enable </td> </tr> <tr> <td colspan="3">Trickle Power 100W </td> </tr> <tr> <td colspan="3">Trickle Time Delay 1 min</td> </tr> <tr> <td>Back</td> <td>00:00</td> <td>Next</td> </tr> </table>	Local	 CTDD	50.0 rpm	Trickle Current			Set parameters for Trickle Current.			Enable 			Trickle Power 100W 			Trickle Time Delay 1 min			Back	00:00	Next			
Local	 CTDD	50.0 rpm																							
Trickle Current																									
Set parameters for Trickle Current.																									
Enable 																									
Trickle Power 100W 																									
Trickle Time Delay 1 min																									
Back	00:00	Next																							
<p><input type="checkbox"/> Trickle Selection</p> <p>Select the I/O or Communication Link that will Enable the Trickle Current Function.</p> <p>If you select “ENABLE”, the Trickle Current Function will be Enabled whenever the Drive is not running.</p>	<table border="1"> <tr> <td>Local</td> <td> CTDD</td> <td> 0.0 rpm</td> </tr> <tr> <td colspan="3">74.01 Trickle Selection</td> </tr> <tr> <td colspan="3">[0] DISABLE</td> </tr> <tr> <td colspan="3">[1] ENABLE</td> </tr> <tr> <td colspan="3">[2] DI01</td> </tr> <tr> <td colspan="3">[3] FBA</td> </tr> <tr> <td colspan="3">[4] EFB</td> </tr> <tr> <td>Cancel</td> <td>00:00</td> <td>Save</td> </tr> </table>	Local	 CTDD	 0.0 rpm	74.01 Trickle Selection			[0] DISABLE			[1] ENABLE			[2] DI01			[3] FBA			[4] EFB			Cancel	00:00	Save
Local	 CTDD	 0.0 rpm																							
74.01 Trickle Selection																									
[0] DISABLE																									
[1] ENABLE																									
[2] DI01																									
[3] FBA																									
[4] EFB																									
Cancel	00:00	Save																							
<p><input type="checkbox"/> De-Ice</p> <p>This is a Cooling Tower mode to run the tower in reverse at a slow speed to prevent ice build up. Use the   to highlight the setting and  to access level values.</p> <p>Refer to Chapter 10 or parameter group 75 for proper setup. When finished, press  (next) to continue.</p>	<table border="1"> <tr> <td>Local</td> <td> CTDD</td> <td>50.0 rpm</td> </tr> <tr> <td colspan="3">De-Ice</td> </tr> <tr> <td colspan="3">Set parameters for De-ice.</td> </tr> <tr> <td colspan="3">Enable </td> </tr> <tr> <td colspan="3">De-Ice Speed 30% </td> </tr> <tr> <td colspan="3">Run Time 1 min </td> </tr> <tr> <td colspan="3">Minimum torque 1 -30.0 % </td> </tr> <tr> <td>Back</td> <td>00:00</td> <td>Next</td> </tr> </table>	Local	 CTDD	50.0 rpm	De-Ice			Set parameters for De-ice.			Enable 			De-Ice Speed 30% 			Run Time 1 min 			Minimum torque 1 -30.0 % 			Back	00:00	Next
Local	 CTDD	50.0 rpm																							
De-Ice																									
Set parameters for De-ice.																									
Enable 																									
De-Ice Speed 30% 																									
Run Time 1 min 																									
Minimum torque 1 -30.0 % 																									
Back	00:00	Next																							

Table 12-2 Drive Assistant

<input type="checkbox"/>	<p>De-Ice Selection</p> <p>Select the I/O or Communication Link that will Enable De-Ice mode</p>	<div style="border: 1px solid black; padding: 5px;"> <p>Local ↶ CTDD ▲ 0.0 rpm</p> <hr/> <p>75.01 De-Ice Selection</p> <p>[0] DISABLE</p> <p>[1] DI01</p> <p>[2] FBA</p> <p>[3] EFB</p> <hr/> <p>Cancel 00:00 Save</p> </div>
<input type="checkbox"/>	<p>Backup</p> <p>Copies all settings into a backup file stored in the control panel. Press   to highlight Backup and  to begin the Backup.</p>	<div style="border: 1px solid black; padding: 5px;"> <p>Local ↶ CTDD 50.0 rpm</p> <hr/> <p>Make backup? ██████████</p> <p>Copies all settings into a backup file stored in the control panel. To restore a backup, go to Menu > Backups.</p> <p>Not now</p> <p>Backup</p> <hr/> <p>Back 00:00 Next</p> </div>
<input type="checkbox"/>	<p>Backup Status</p> <p>A status screen indicates progress.</p>	<div style="border: 1px solid black; padding: 5px;"> <p>Local ↶ CTDD 0.0 rpm</p> <hr/> <p style="text-align: center;">Backing up data from drive</p> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> </div>
<input type="checkbox"/>	<p>Press  (back) to backout and exit to home menu.</p>	<div style="border: 1px solid black; padding: 5px;"> <p>Remote ↶ CTDD 600.0 rpm</p> <hr/> <p>Set-up complete ██████████</p> <p>I/O should be connected as follows:</p> <p>Start/Stop: Digital Input DI 1</p> <p>Speed reference: Analog Input AI 90-10 V</p> <hr/> <p>Back 00:00 Done</p> </div>
Control Signal Settings		
<input type="checkbox"/>	<p>Check the positions of jumpers J1 and J2 on the control unit of the drive. These jumpers determine whether analog inputs AI1 and AI2 are current or voltage.</p>	

Table 12-2 Drive Assistant



Check/adjust the following parameters.	
<input type="checkbox"/>	<p>12.15 AI1 unit selection Set this to either mA or V corresponding to the setting of jumper J1.</p>
<input type="checkbox"/>	<p>12.17 AI1 min 12.18 AI1 max 12.19 AI1 scaled at AI1 min 12.20 AI1 scaled at AI1 max</p> <p>The default input for speed reference is analog input AI1. (This is controlled by the parameters in group 22.) Parameters 12.17 and 12.18 set the low and high limits of the analog input signal. Scaling parameters 12.19 and 12.20 define the internal signal levels that correspond to these limits as follows:</p>  <p>The corresponding parameters for analog input AI2 are 12.27 - 12.30.</p>
<input type="checkbox"/>	<p>13.12 AO1 source 13.17 AO1 source min 13.18 AO1 source max 13.19 AO1 out at AI1 src min 13.20 AO1 out at AI1 src max</p> <p>Parameter 13.12 selects the source for analog output AO1 (by default, motor speed in rpm). Parameters 13.17 and 13.18 set low and high source signal values that correspond to the actual analog output values defined by parameters 13.19 and 13.20.</p> 

Table 12-2 Drive Assistant

<input type="checkbox"/>	<p>46.10 Speed scaling 23.11 Ramp set selection 23.12 Acceleration time 1 23.13 Deceleration time 1 23.14 Acceleration time 2 23.15 Deceleration time 2</p> <p>You can define two different sets of acceleration/deceleration ramps. The source that switches between the two sets is selected by parameter 23.11. Each acceleration/deceleration time set in parameters 23.12 - 23.15 refers to the time it takes for the drive to accelerate or decelerate between 0 and scaling speed (parameter 46.10).</p>
<input type="checkbox"/>	<p>30.11 Minimum speed 30.12 Maximum speed 30.17 Maximum current 30.19 Minimum torque 30.20 Maximum torque</p> <p>Check, and set if necessary, the limits for motor speed, current and torque.</p>
<input type="checkbox"/>	<p>Start the drive with a positive (forward) speed reference:</p> <ul style="list-style-type: none"> From control panel (Local control): In the Home view, press (Options), select Reference, adjust the reference using the , , , and keys, press Save, and press the Start button. From I/O: In Remote control, adjust analog input AI1 (reference), switch digital input DI1 to 1 (start).

The ACS880+N5350 utilizes various parameters to determine its operation. Many of these parameters will not need adjusting for most applications, but are provided to allow for a user to customize the operation of the control if desired.

Table 12-3 Terms and Abbreviations

Term	Definition
Actual Signal	Type of parameter that is the result of a measurement or calculation by the drive, or contains status information. Most actual signals are read-only, but some (especially counter-type actual signals) can be reset.
Def	(In the following table, shown on the same row as the parameter name) The default value of a parameter when used in the CTDD macro.
FbEq16	(In the following table, shown on the same row as the parameter range, or for each selection) A dash (-) indicates that the parameter is not accessible in 16-bit format.
Other	The value is taken from another parameter. Choosing "Other" displays a parameter list in which the user can specify the source parameter.
Other [bit]	The value is taken from a specific bit in another parameter. Choosing "Other" displays a parameter list in which the user can specify the source parameter and bit.
Parameter	Either a user-adjustable operating instruction for the drive, or an actual signal.
p.u.	Per unit

12.2 Level 1 Parameters (Advanced Prog, Level 1 Blocks)

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
ACTUAL VALUES	Basic signals for monitoring the drive. All parameters in this group are read-only unless otherwise noted.	
	MOTOR SPEED USED (01.01)	Default: Read Only Range: -30000.00 to +30000.00 RPM
		Measured or estimated motor speed depending on which type of feedback is used (see parameter 90.41 Motor feedback selection). A filter time constant for this signal can be defined by parameter 46.11 Filter time motor speed.
	MOTOR SPEED ESTIMATED (01.02)	Default: Read Only Range: -30000.00 to +30000.00 RPM
		Estimated motor speed in rpm. a filter time constant for this signal can be defined b parameter 46.11 Filter time motor speed.
	MOTOR SPEED % (01.03)	Default: 10 = 1% Range: -1000.00 to +1000.00%
		Measured or estimated motor speed. Shows the value of 01.01 Motor speed used in percent of the synchronous speed of the motor.
	OUTPUT FREQUENCY (01.06)	Default: Read Only Range: -500.00 to +500.00 Hz
		Estimated drive output frequency in Hz. A filter time constant for this signal can be defined by parameter 46.12 Filter time output frequency.
	MOTOR CURRENT (01.07)	Default: Read Only Range: 0.00 to 30000.00 A
		Measured (absolute) motor current in A.
	MOTOR CURRENT % OF MOTOR NOM (01.08)	Default: Read Only Range: 0.00 to 1000.0 %
		Measured motor current in %
	MOTOR TORQUE % (01.10)	Default: Read Only Range: -1600.0 to +1600.0 %
		Motor torque in percent of the nominal motor torque. See also parameter 01.30 Nominal torque scale. A filter time constant for this signal can be defined by parameter 46.13 Filter time motor torque
DC VOLTAGE (01.11)	Default: Read Only Range: 0.00 - 2000.00 V	
	Measured DC link voltage.	
OUTPUT VOLTAGE (01.13)	Default: Read Only Range: 0 - 2000 V	
	Calculated motor voltage in VAC. Fieldbus Equivalent: 10 = 1 V	
OUTPUT POWER (01.14)	Default: Read Only Range: -32768 to +32767 kW or HP	
	Drive output power. The unit is selected by parameter 96.16 Unit selection. A filter time constant for this signal can be defined by parameter 46.14 Filter time power out.	
OUTPUT POWER % OF MOTOR NOM (01.15)	Default: Read Only Range: -300.00 + 300.0%	
	Shows the value of 01.14 Output power in percent of the normal power of the motor.	

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
ACTUAL VALUES (Continued)	MOTOR SHAFT POWER (01.17)	Default: Read Only Range: -32768 to + 32767 kW or HP
		Estimated mechanical power at motor shaft. The unit is selected by parameter 96.16 Unit selection. A filter time constant for this signal can be defined by parameter 46.14 Filter time power out.
	INVERTER GWh COUNTER (01.18)	Default: Read Only Range: 0 - 65535 GWh
		Energy in GWh - Amount of energy that has passed through the drive (in either direction) in full gigawatt-hours. The minimum value is zero.
	INVERTER MWh COUNTER (01.19)	Default: Read Only Range: 0 - 999 MWh
		Energy in MWh - Amount of energy that has passed through the drive (in either direction) in full megawatt-hours. Whenever the counter rolls over, 01.18 Inverter GWh counter is incremented. The minimum value is zero.
	INVERTER kWh COUNTER (01.20)	Default: Read Only Range: 0 - 999 kWh
		Energy in kWh - Amount of energy that has passed through the drive (in either direction) in full kilowatt-hours. Whenever the counter rolls over, 01.19 Inverter MWh counter is incremented. The minimum value is zero. Fieldbus Equivalent: 10 = 1kWh
	U-PHASE CURRENT (01.21)	Default: Read Only Range: -30000.00 to +30000.00A
		Measured U-phase current.
	V-PHASE CURRENT (01.22)	Default: Read Only Range: -30000.00 to +30000.00A
		Measured V-phase current.
	W-PHASE CURRENT (01.23)	Default: Read Only Range: -30000.00 to +30000.00A
		Measured W-phase current.
FLUX ACTUAL % (01.24)	Default: Read Only Range: -0 to +200%	
	Used flux reference in percent of nominal flux of motor.	
SPEED CHANGE RATE (01.29)	Default: Read Only Range: -15000 to +15000 RPM	
	Rate of actual speed change. Positive values indicate acceleration, negative values indicate deceleration. See also parameters 31.32 Emergency ramp supervision, 31.33 Emergency ramp supervision delay, 31.37 Ramp stop supervision and 31.38 Ramp stop supervision delay.	
NOMINAL TORQUE SCALE (01.30)	Default: Read Only Range: 0.0000 - lb-ft	
	Nominal Torque - Torque that corresponds to 100% of nominal motor torque. The unit is selected by parameter 96.16 Unit selection. Note: This value is copied from parameter 99.12 Motor nominal torque if entered. Otherwise the value is calculated from other motor data.	

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
ACTUAL VALUES (Continued)	AMBIENT TEMPERATURE (01.31)	Default: Read Only Range: -32768 to +32767°C or °F
		Measured temperature of incoming cooling air. The unit is selected by parameter 96.16 Unit selection.
	INVERTER GWh REGENERATING (01.32)	Default: Read Only Range: 0 to 32767 GWh
		Motoring energy in GWh. Amount of energy that has passed through the drive (towards the supply) in full gigawatt-hours. The minimum value is zero.
	INVERTER MWh REGENERATING (01.33)	Default: Read Only Range: 0 to 999 MWh
		Motoring energy in MWh. Amount of energy that has passed through the drive (towards the supply) in full megawatt-hours. Whenever the counter rolls over, 01.32 Inverter GWh regenerating is incremented. The minimum value is zero.
	INVERTER kWh REGENERATING (01.34)	Default: Read Only Range: 0 to 999 kWh
		Motoring energy in kWh. Amount of energy that has passed through the drive (towards the supply) in full megawatt-hours. Whenever the counter rolls over, 01.33 Inverter MWh regenerating is incremented. The minimum value is zero.
	MOT - REGEN ENERGY GWh (01.35)	Default: Read Only Range: -32768 to +32767 GWh
		Motoring energy in GWh. Amount of net energy (motoring energy - regenerating energy) that has passed through the drive in full gigawatt hours.
	MOT - REGEN ENERGY MWh (01.36)	Default: Read Only Range: -999 to +999 MWh
		Motoring energy in MWh. Amount of net energy (motoring energy - regenerating energy) that has passed through the drive in full megawatt hours. Whenever the counter rolls over, 01.35 Mot - regen energy GWh is incremented or decremented.
	MOT - REGEN ENERGY kWh (01.37)	Default: Read Only Range: -999 to +999 kWh
		Motoring energy in kWh. Amount of net energy (motoring energy - regenerating energy) that has passed through the drive in full kilowatt hours. Whenever the counter rolls over, 01.36 Mot - regen energy MWh is incremented or decremented.
ABS MOTOR SPEED USED (01.61)	Default: Read Only Range: 0.000 to 30000.00 RPM	
	Measured or estimated motor speed. Absolute value of 01.01 Motor speed used.	
ABS MOTOR SPEED % (01.62)	Default: Read Only Range: 0.00 to 1000.00%	
	Measured or estimated motor speed. Absolute value of 01.03 Motor speed %.	
ABS OUTPUT FREQUENCY (01.63)	Default: Read Only Range: 0.00 to 500.00 Hz	
	Estimated output frequency. Absolute value of 01.06 Output frequency.	

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
ACTUAL VALUES (Continued)	ABS OUTPUT POWER % MOTOR NOM (01.66)	Default: Read Only Range: 0.00 to 300.00%
		Output power. Absolute value of 01.15 Output power % of motor nom
	ABS OUTPUT POWER (01.65)	Default: Read Only Range: 0.0 to 1600.0%
		Motor torque. Absolute value of 01.10 Motor torque.
	ABS MOTOR SHAFT POWER (01.68)	Default: Read Only Range: 0.0 to 32767.00 kW or HP
		Motor shaft power. Absolute value of 01.17 Motor shaft power.
INPUT REFERENCES	Values of references received from various sources. All parameters in this group are read-only unless otherwise noted. These parameters are for Fieldbus only.	
	FB A REFERENCE 1 (03.05) "Fieldbus" mode reference	Default: Read Only Range: -100000.00 to + 100000.00
		Reference 1 received through fieldbus adapter A.
	FB A REFERENCE 2 (03.06)	Default: Read Only Range: -100000.00 to + 100000.00
		Reference 2 received through fieldbus adapter A.
	FB B REFERENCE 1 (03.07)	Default: Read Only Range: -100000.00 to + 100000.00
		Reference 2 received through fieldbus adapter B.
	FB B REFERENCE 2 (03.08)	Default: Read Only Range: -100000.00 to + 100000.00
		Reference 2 received through fieldbus adapter B.
	EFB REFERENCE 1 (03.09)	Default: Read Only Range: -30000.00 to + 30000.00
		Reference 1 received through the imbedded fieldbus interface. Scaled reference 1 received through the embedded fieldbus interface. The scaling is defined by 58.26 EFB ref1 type.
	EFB REFERENCE 2 (03.10)	Default: Read Only Range: -30000.00 to + 30000.00
Reference 2 received through the imbedded fieldbus interface. Scaled reference 2 received through the embedded fieldbus interface. The scaling is defined by 58.27 EFB ref2 type.		
WARNINGS AND FAULTS	Information on warnings and faults that occurred last. All parameters in this group are read-only unless otherwise noted.	
	TRIPPING FAULT (04.01)	Default: Read Only Range: 0000h - FFFFh
		Code of the 1st active fault (the fault that caused the current trip).
	ACTIVE FAULT 2 (04.02)	Default: Read Only Range: 0000h - FFFFh
		Code of the 2nd active fault.
	ACTIVE FAULT 3 (04.03)	Default: Read Only Range: 0000h - FFFFh
		Code of the 3rd active fault.
ACTIVE FAULT 4 (04.04)	Default: Read Only Range: 0000h - FFFFh	
	Code of the 4th active fault.	

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
WARNINGS AND FAULTS (Continued)	ACTIVE FAULT 5 (04.05)	Default: Read Only Range: 0000h - FFFFh
		Code of the 5th active fault.
	ACTIVE WARNING 1 (04.06)	Default: Read Only Range: 0000h - FFFFh
		Code of the 1st active warning.
	ACTIVE WARNING 2 (04.07)	Default: Read Only Range: 0000h - FFFFh
		Code of the 2nd active warning.
	ACTIVE WARNING 3 (04.08)	Default: Read Only Range: 0000h - FFFFh
		Code of the 3rd active warning.
	ACTIVE WARNING 4 (04.09)	Default: Read Only Range: 0000h - FFFFh
		Code of the 4th active warning.
	ACTIVE WARNING 5 (04.10)	Default: Read Only Range: 0000h - FFFFh
		Code of the 5th active warning.
	LATEST FAULT (04.11)	Read Only Range: 0000h - FFFFh
		Code of the 1st stored (non-active) fault.
	2ND LATEST FAULT (04.12)	Default: Read Only Range: 0000h - FFFFh
		Code of the 2nd stored (non-active) fault.
	3RD LATEST FAULT (04.13)	Default: Read Only Range: 0000h - FFFFh
		Code of the 3rd stored (non-active) fault.
	4TH LATEST FAULT (04.14)	Default: Read Only Range:
		Code of the 4th stored (non-active) fault.
5TH LATEST FAULT (04.15)	Default: Read Only Range: 0000h - FFFFh	
	Code of the 5th stored (non-active) fault.	
LATEST WARNING (04.16)	Default: Read Only Range: 0000h - FFFFh	
	Code of the 1st stored (non-active) warning.	
2ND LATEST WARNING (04.17)	Default: Read Only Range: 0000h - FFFFh	
	Code of the 2nd stored (non-active) warning.	
3RD LATEST WARNING (04.18)	Default: Read Only Range: 0000h - FFFFh	
	Code of the 3rd stored (non-active) warning.	
4TH LATEST WARNING (04.19)	Default: Read Only Range: 0000h - FFFFh	
	Code of the 4th stored (non-active) warning.	

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions															
WARNINGS AND FAULTS (Continued)	5TH LATEST WARNING (04.20)	Default: Read Only Range: 0000h - FFFFh Code of the 5th stored (non-active) warning.															
	EVENT WORD (04.40)	Default: Read Only Range: 0000h - FFFFh User-defined event word. This word collects the status of the events (warnings, faults or pure events) selected by parameters 04.41 to 04.72. For each event, an auxiliary code can optionally be specified for filtering. This parameter is read-only. <table border="1" data-bbox="769 646 1563 919"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>User bit 0</td> <td>1 = Event selected by parameters 04.41 (and 04.42) is active</td> </tr> <tr> <td>1</td> <td>User bit 1</td> <td>1 = Event selected by parameters 04.43 (and 04.44) is active</td> </tr> <tr> <td>---</td> <td>---</td> <td>---</td> </tr> <tr> <td>15</td> <td>User bit 15</td> <td>1 = Event selected by parameters 04.71 (and 04.72) is active</td> </tr> </tbody> </table>	Bit	Name	Description	0	User bit 0	1 = Event selected by parameters 04.41 (and 04.42) is active	1	User bit 1	1 = Event selected by parameters 04.43 (and 04.44) is active	---	---	---	15	User bit 15	1 = Event selected by parameters 04.71 (and 04.72) is active
	Bit	Name	Description														
	0	User bit 0	1 = Event selected by parameters 04.41 (and 04.42) is active														
	1	User bit 1	1 = Event selected by parameters 04.43 (and 04.44) is active														
	---	---	---														
	15	User bit 15	1 = Event selected by parameters 04.71 (and 04.72) is active														
	EVENT WORD 1 BIT 0 CODE (04.41)	Default: 0000h Range: 0000h - FFFFh Code of event. Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 0 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing.															
	EVENT WORD 1 BIT 0 AUX CODE (04.42)	Default: 0000 0000h Range: 0000 0000h - FFFF FFFFh Code of warning, fault or pure event. Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter. With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.															
	EVENT WORD 1 BIT 1 CODE (04.43)	Default: 0000h Range: 0000h - FFFFh Code of event. Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 1 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing.															
	EVENT WORD 1 BIT 1 AUX CODE (04.44)	Default: 0000 0000h Range: 0000 0000h - FFFF FFFFh Code of warning, fault or pure event. Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter. With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.															
	EVENT WORD 1 BIT 2 CODE (04.45)	Default: 0000h Range: 0000h - FFFFh Code of event. Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 2 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing.															

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
WARNINGS AND FAULTS (Continued)	EVENT WORD 1 BIT 2 AUX CODE (04.46)	Default: 0000 0000h Range: 0000 0000h - FFFF FFFFh Code of warning, fault or pure event. Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter. With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.
	EVENT WORD 1 BIT 3 CODE (04.47)	Default: 0000h Range: 0000h - FFFFh Code of event. Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 3 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing.
	EVENT WORD 1 BIT 3 AUX CODE (04.48)	Default: 0000 0000h Range: 0000 0000h - FFFF FFFFh Code of warning, fault or pure event. Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter. With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.
	EVENT WORD 1 BIT 4 CODE (04.49)	Default: 0000h Range: 0000h - FFFFh Code of event. Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 4 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing.
	EVENT WORD 1 BIT 4 AUX CODE (04.50)	Default: 0000 0000h Range: 0000 0000h - FFFF FFFFh Code of warning, fault or pure event. Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter. With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.
	EVENT WORD 1 BIT 5 AUX CODE (04.52)	Default: 0000 0000h Range: 0000 0000h - FFFF FFFFh Code of warning, fault or pure event. Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter. With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.
	EVENT WORD 1 BIT 6 CODE (04.53)	Default: 0000h Range: 0000h - FFFFh Code of event. Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 6 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing.

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
WARNINGS AND FAULTS (Continued)	EVENT WORD 1 BIT 7 CODE (04.55)	Default: 0000h Range: 0000h - FFFFh
		Code of event. Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 7 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing.
	EVENT WORD 1 BIT 7 AUX CODE (04.56)	Default: 0000 0000h Range: 0000 0000h - FFFF FFFFh
		Code of warning, fault or pure event. Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter. With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.
	EVENT WORD 1 BIT 8 CODE (04.57)	Default: 0000h Range: 0000h - FFFFh
		Code of event. Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 8 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing.
	EVENT WORD 1 BIT 8 AUX CODE (04.58)	Default: 0000 0000h Range: 0000 0000h - FFFF FFFFh
		Code of warning, fault or pure event. Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter. With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.
	EVENT WORD 1 BIT 9 CODE (04.59)	Default: 0000h Range: 0000h - FFFFh
		Code of event. Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 9 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing.
	EVENT WORD 1 BIT 9 AUX CODE (04.60)	Default: 0000 0000h Range: 0000 0000h - FFFF FFFFh
		Code of warning, fault or pure event. Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter. With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.
	EVENT WORD 1 BIT 10 CODE (04.61)	Default: 0000h Range: 0000h - FFFFh
		Code of event. Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 10 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing.
EVENT WORD 1 BIT 10 AUX CODE (04.62)	Default: 0000 0000h Range: 0000 0000h - FFFF FFFFh	
	Code of warning, fault or pure event. Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter. With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.	

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
WARNINGS AND FAULTS (Continued)	EVENT WORD 1 BIT 11 CODE (04.63)	Default: 0000h Range: 0000h - FFFFh Code of event. Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 11 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing.
	EVENT WORD 1 BIT 11 AUX CODE (04.64)	Default: 0000 0000h Range: 0000 0000h - FFFF FFFFh Code of warning, fault or pure event. Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter. With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.
	EVENT WORD 1 BIT 12 CODE (04.65)	Default: 0000h Range: 0000h - FFFFh Code of event. Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 12 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing.
	EVENT WORD 1 BIT 12 AUX CODE (04.66)	Default: 0000 0000h Range: 0000 0000h - FFFF FFFFh Code of warning, fault or pure event. Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter. With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.
	EVENT WORD 1 BIT 13 CODE (04.67)	Default: 0000h Range: 0000h - FFFFh Code of event. Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 13 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing.
	EVENT WORD 1 BIT 13 AUX CODE (04.68)	Default: 0000 0000h Range: 0000 0000h - FFFF FFFFh Code of warning, fault or pure event. Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter. With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.
	EVENT WORD 1 BIT 14 CODE (04.69)	Default: 0000h Range: 0000h - FFFFh Code of event. Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 14 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing.
	EVENT WORD 1 BIT 14 AUX CODE (04.70)	Default: 0000 0000h Range: 0000 0000h - FFFF FFFFh Code of warning, fault or pure event. Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter. With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions											
WARNINGS AND FAULTS (Continued)	EVENT WORD 1 BIT 15 CODE (04.71)	Default: 0000h Range: 0000h - FFFFh											
		Code of event. Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 15 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing.											
	EVENT WORD 1 BIT 15 AUX CODE (04.72)	Default: 0000 0000h Range: 0000 0000h - FFFF FFFFh											
		Code of warning, fault or pure event. Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter. With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code.											
DIAGNOSTICS	Various run-time-type counters and measurements related to drive maintenance. All parameters in this group are read-only unless otherwise noted.												
	ON-TIME COUNTER (05.01)	Default: Read Only Range: 0 - 65535 d											
		On-time counter - The counter runs when the drive is powered.											
	RUN-TIME COUNTER (05.02)	Default: Read Only Range: 0 - 65535 d											
		Motor run-time counter - The counter runs when the inverter modulates.											
	FAN ON-TIME COUNTER (05.04)	Default: Read Only Range: 0 - 65535 d											
		Cooling fan run-time counter - Running time of the drive cooling fan. Can be reset from the control panel by keeping Reset depressed for over 3 sec.											
	INVERTER TEMPERATURE (05.11)	Default: Read Only Range: -40.0 to +160.0 %											
Drive temperature in percent - Estimated drive temperature in percent of fault limit. The fault limit varies according to the type of the drive. 0.0% = 0°C (32°F); 100.0% = Fault limit													
DIAGNOSTIC WORD 3 (05.22)	Default: Read Only Range: 0000h - FFFFh												
	Diagnostic word 3.												
	<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0 - 10</td> <td>Reserved</td> <td></td> </tr> <tr> <td>11</td> <td>Fan command</td> <td>1 = Drive fan is rotating above idle speed.</td> </tr> <tr> <td>12 - 15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>	Bit	Name	Value	0 - 10	Reserved		11	Fan command	1 = Drive fan is rotating above idle speed.	12 - 15	Reserved	
	Bit	Name	Value										
0 - 10	Reserved												
11	Fan command	1 = Drive fan is rotating above idle speed.											
12 - 15	Reserved												
MAIN FAN SERVICE COUNTER (05.41)	Default: Read Only Range: 0 to 150%												
	Main cooling fan age. Displays the age of the main cooling fan as a percentage of its estimated lifetime. The estimate is based on the duty, operating conditions and other operating parameters of the fan. When the counter reaches 100%, a warning (A8C0 Fan service counter) is generated. Can be reset from the control panel by keeping Reset depressed for over 3 seconds.												

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
DIAGNOSTICS (Continued)	AUX. FAN SERVICE COUNTER (05.42)	Default: Read Only Range: 0 to 150% Auxiliary cooling fan age. Displays the age of the auxiliary cooling fan as a percentage of its estimated lifetime. The estimate is based on the duty, operating conditions and other operating parameters of the fan. When the counter reaches 100%, a warning (A8C0 Fan service counter) is generated. Can be reset from the control panel by keeping Reset depressed for over 3 seconds.
CONTROL AND STATUS WORDS	All parameters in this group are read-only unless otherwise noted. These parameters are for Fieldbus only. Main Control Word only used in "Custom" mode.	
	MAIN CONTROL WORD (06.01)	Default: Read Only Range: 0 - 15
	0 (Off1 control)	1 - Proceed to READY TO OPERATE. 0 - Stop along currently active deceleration ramp. Proceed to OFF1 ACTIVE; proceed to READY TO SWITCH ON unless other interlocks (OFF2, OFF3) are active.
	1 (Off2 control)	1 - Continue operation (OFF2 inactive). 0 - Emergency OFF, coast to a stop. Proceed to OFF2 ACTIVE, proceed to SWITCH-ON INHIBITED.
	2 (Off3 control)	1 - Continue operation (OFF3 inactive). 0 - Emergency stop, stop within time defined by drive parameter. Proceed to OFF3 ACTIVE; proceed to SWITCH-ON INHIBITED.
	3 (Run)	1 - Proceed to OPERATION ENABLED. Note: Run enable signal must be active; see drive documentation. If the drive is set to receive the Run enable signal from the fieldbus, this bit activates the signal. 0 - Inhibit operation. Proceed to OPERATION INHIBITED.
	4 (Ramp out zero)	1 - Normal operation. Proceed to RAMP FUNCTION GENERATOR: OUTPUT ENABLED. 0 - Force Ramp function generator output to zero. The drive will immediately decelerate to zero speed (observing the torque limits).
	5 (Ramp hold)	1 - Enable ramp function. Proceed to RAMP FUNCTION GENERATOR: ACCELERATOR ENABLED. 0 - Halt ramping (Ramp Function Generator output held).
	6 (Ramp in zero)	1 - Normal operation. Proceed to OPERATING. Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters. 0 - Force Ramp function generator input to zero.
	7 (Reset)	0=>1 - Fault reset if an active fault exists. Proceed to SWITCH-ON INHIBITED. Note: This bit is effective only if the fieldbus interface is set as the source of the reset signal by drive parameters. 0 - Continue normal operation.
	8 (Inching 1)	1 - Accelerate to inching (jogging) setpoint 1. Notes: Bits 4...6 must be 0. 0 - Inching (jogging) 1 disabled.
	9 (Inching 2)	1 - Accelerate to inching (jogging) setpoint 2. See notes at bit 8. 0 - Inching (jogging) 2 disabled.

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
CONTROL AND STATUS WORDS (Continued)	MAIN CONTROL WORD (06.01) (Cont.)	Default: Read Only Range: 0 - 15
	10 (Remote cmd)	1 - Fieldbus control enabled. 0 - Control word and reference not getting through to the drive, except for bits 0...2.
	11 (Ext ctrl loc)	1 - Select External Control Location EXT2. Effective if control location is parameterized to be selected from fieldbus. 0 - Select External Control Location EXT1. Effective if control location is parameterized to be selected from fieldbus.
	12 - 15 (Reserved)	The main control word of the drive. This parameter shows the control signals as received from the selected sources (such as digital inputs, the fieldbus interfaces and the application program). Note: Bits 12 - 15 can be used to carry additional control data, and used as a signal source by any binary-source selector parameter.
	APPLICATION CONTROL WORD (06.02)	Default: Read Only Range: 0000h - FFFFh
		Application program control word. The drive control word received from the application program (if any). This parameter is read-only.
	FBA A TRANSPARENT CONTROL WORD (06.03)	Default: Read Only Range: 00000000h - FFFFFFFFh
		Control word received through fieldbus adapter A. Displays the unaltered control word received from the PLC through fieldbus adapter A when a transparent communication profile is selected eg. by parameter group 51 FBA A settings. See section Control word and Status word. This parameter is read-only.
FBA B TRANSPARENT CONTROL WORD (06.04)	Default: Read Only Range: 00000000h - FFFFFFFFh	
	Control word received through fieldbus adapter B. Displays the unaltered control word received from the PLC through fieldbus adapter B when a transparent communication profile is selected eg. by parameter group 54 FBA B settings. See section Control word and Status word. This parameter is read-only.	
EFB TRANSPARENT CONTROL WORD (06.05)	Default: Read Only Range: 00000000h - FFFFFFFFh	
	Control word received through the embedded fieldbus interface. Displays the unaltered control word received from the PLC through the embedded fieldbus interface when a transparent communication profile is selected in parameter 58.25 Control profile. See section The Transparent profile. This parameter is read-only.	

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions																																																																																																			
CONTROL AND STATUS WORDS (Continued)	MAIN STATUS WORD (06.11)	Default: Read Only Range: 0 - 15																																																																																																			
		Main status word of the drive. This parameter is read-only.																																																																																																			
		<table border="1"> <thead> <tr> <th data-bbox="701 413 824 445">Bit</th> <th data-bbox="829 413 1003 445">Name</th> <th data-bbox="1008 413 1101 445">Value</th> <th data-bbox="1105 413 1497 445">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="701 451 824 531" rowspan="2">0</td> <td data-bbox="829 451 1003 531" rowspan="2">Ready to switch ON</td> <td data-bbox="1008 451 1101 483">1</td> <td data-bbox="1105 451 1497 483">Ready to switch ON</td> </tr> <tr> <td data-bbox="1008 489 1101 520">0</td> <td data-bbox="1105 489 1497 520">Not ready to switch ON</td> </tr> <tr> <td data-bbox="701 527 824 606" rowspan="2">1</td> <td data-bbox="829 527 1003 606" rowspan="2">Ready run</td> <td data-bbox="1008 527 1101 558">1</td> <td data-bbox="1105 527 1497 558">Ready to operate</td> </tr> <tr> <td data-bbox="1008 564 1101 596">0</td> <td data-bbox="1105 564 1497 596">OFF1 active</td> </tr> <tr> <td data-bbox="701 602 824 682" rowspan="2">2</td> <td data-bbox="829 602 1003 682" rowspan="2">Ready ref</td> <td data-bbox="1008 602 1101 634">1</td> <td data-bbox="1105 602 1497 634">Operation enabled</td> </tr> <tr> <td data-bbox="1008 640 1101 672">0</td> <td data-bbox="1105 640 1497 672">Operation inhibited</td> </tr> <tr> <td data-bbox="701 678 824 758" rowspan="2">3</td> <td data-bbox="829 678 1003 758" rowspan="2">Tripped</td> <td data-bbox="1008 678 1101 709">1</td> <td data-bbox="1105 678 1497 709">Fault</td> </tr> <tr> <td data-bbox="1008 716 1101 747">0</td> <td data-bbox="1105 716 1497 747">No Fault</td> </tr> <tr> <td data-bbox="701 753 824 833" rowspan="2">4</td> <td data-bbox="829 753 1003 833" rowspan="2">OFF2 inactive</td> <td data-bbox="1008 753 1101 785">1</td> <td data-bbox="1105 753 1497 785">OFF2 inactive</td> </tr> <tr> <td data-bbox="1008 791 1101 823">0</td> <td data-bbox="1105 791 1497 823">OFF2 active</td> </tr> <tr> <td data-bbox="701 829 824 909" rowspan="2">5</td> <td data-bbox="829 829 1003 909" rowspan="2">OFF3 inactive</td> <td data-bbox="1008 829 1101 861">1</td> <td data-bbox="1105 829 1497 861">OFF3 inactive</td> </tr> <tr> <td data-bbox="1008 867 1101 898">0</td> <td data-bbox="1105 867 1497 898">OFF3 active</td> </tr> <tr> <td data-bbox="701 905 824 984" rowspan="2">6</td> <td data-bbox="829 905 1003 984" rowspan="2">Switch-on inhibited</td> <td data-bbox="1008 905 1101 936">1</td> <td data-bbox="1105 905 1497 936">Switch-on inhibited</td> </tr> <tr> <td data-bbox="1008 942 1101 974">0</td> <td data-bbox="1105 942 1497 974">--</td> </tr> <tr> <td data-bbox="701 980 824 1060" rowspan="2">7</td> <td data-bbox="829 980 1003 1060" rowspan="2">Warning</td> <td data-bbox="1008 980 1101 1012">1</td> <td data-bbox="1105 980 1497 1012">Warning active</td> </tr> <tr> <td data-bbox="1008 1018 1101 1050">0</td> <td data-bbox="1105 1018 1497 1050">No warning active</td> </tr> <tr> <td data-bbox="701 1056 824 1270" rowspan="2">8</td> <td data-bbox="829 1056 1003 1270" rowspan="2">At setpoint</td> <td data-bbox="1008 1056 1101 1087">1</td> <td data-bbox="1105 1056 1497 1186">Operating - Actual value equals reference = is within tolerance limits (see parameters 46.21 - 46.23)</td> </tr> <tr> <td data-bbox="1008 1192 1101 1224">0</td> <td data-bbox="1105 1192 1497 1270">Actual value differs from reference = is outside tolerance limits</td> </tr> <tr> <td data-bbox="701 1266 824 1346" rowspan="2">9</td> <td data-bbox="829 1266 1003 1346" rowspan="2">Remote</td> <td data-bbox="1008 1266 1101 1297">1</td> <td data-bbox="1105 1266 1497 1323">Drive control location: Remote (EXT1 or EXT2)</td> </tr> <tr> <td data-bbox="1008 1329 1101 1360">0</td> <td data-bbox="1105 1329 1497 1360">Drive control location: Local</td> </tr> <tr> <td data-bbox="701 1341 824 1421" rowspan="2">10</td> <td data-bbox="829 1341 1003 1421" rowspan="2">Trickle Current Active</td> <td data-bbox="1008 1341 1101 1373">0</td> <td data-bbox="1105 1341 1497 1373">Trickle Current OFF</td> </tr> <tr> <td data-bbox="1008 1379 1101 1411">1</td> <td data-bbox="1105 1379 1497 1411">Trickle Current ON</td> </tr> <tr> <td data-bbox="701 1417 824 1497" rowspan="2">11</td> <td data-bbox="829 1417 1003 1497" rowspan="2">De-Ice Mode Active</td> <td data-bbox="1008 1417 1101 1449">0</td> <td data-bbox="1105 1417 1497 1449">De-Ice Mode OFF</td> </tr> <tr> <td data-bbox="1008 1455 1101 1486">1</td> <td data-bbox="1105 1455 1497 1486">De-Ice Mode ON</td> </tr> <tr> <td data-bbox="701 1493 824 1572" rowspan="2">12</td> <td data-bbox="829 1493 1003 1572" rowspan="2">CTD Run</td> <td data-bbox="1008 1493 1101 1524">0</td> <td data-bbox="1105 1493 1497 1524">CTD Drive Not Running</td> </tr> <tr> <td data-bbox="1008 1530 1101 1562">1</td> <td data-bbox="1105 1530 1497 1562">CTD Drive Running</td> </tr> <tr> <td data-bbox="701 1568 824 1648" rowspan="2">13</td> <td data-bbox="829 1568 1003 1648" rowspan="2">CTD HOLD</td> <td data-bbox="1008 1568 1101 1600">0</td> <td data-bbox="1105 1568 1497 1600">CTD Autophase OFF</td> </tr> <tr> <td data-bbox="1008 1606 1101 1638">1</td> <td data-bbox="1105 1606 1497 1638">CTD Autophase ON</td> </tr> <tr> <td data-bbox="701 1644 824 1703">14</td> <td data-bbox="829 1644 1003 1703">User bit 3</td> <td data-bbox="1008 1644 1101 1703">-</td> <td data-bbox="1105 1644 1497 1703">See parameter 06.33 MSW bit 14 sel</td> </tr> <tr> <td data-bbox="701 1698 824 1757">15</td> <td data-bbox="829 1698 1003 1757">Reserved</td> <td data-bbox="1008 1698 1101 1757"></td> <td data-bbox="1105 1698 1497 1757"></td> </tr> </tbody> </table>				Bit	Name	Value	Description	0	Ready to switch ON	1	Ready to switch ON	0	Not ready to switch ON	1	Ready run	1	Ready to operate	0	OFF1 active	2	Ready ref	1	Operation enabled	0	Operation inhibited	3	Tripped	1	Fault	0	No Fault	4	OFF2 inactive	1	OFF2 inactive	0	OFF2 active	5	OFF3 inactive	1	OFF3 inactive	0	OFF3 active	6	Switch-on inhibited	1	Switch-on inhibited	0	--	7	Warning	1	Warning active	0	No warning active	8	At setpoint	1	Operating - Actual value equals reference = is within tolerance limits (see parameters 46.21 - 46.23)	0	Actual value differs from reference = is outside tolerance limits	9	Remote	1	Drive control location: Remote (EXT1 or EXT2)	0	Drive control location: Local	10	Trickle Current Active	0	Trickle Current OFF	1	Trickle Current ON	11	De-Ice Mode Active	0	De-Ice Mode OFF	1	De-Ice Mode ON	12	CTD Run	0	CTD Drive Not Running	1	CTD Drive Running	13	CTD HOLD	0	CTD Autophase OFF	1	CTD Autophase ON	14	User bit 3	-	See parameter 06.33 MSW bit 14 sel	15	Reserved		
		Bit	Name	Value	Description																																																																																																
		0	Ready to switch ON	1	Ready to switch ON																																																																																																
				0	Not ready to switch ON																																																																																																
		1	Ready run	1	Ready to operate																																																																																																
				0	OFF1 active																																																																																																
		2	Ready ref	1	Operation enabled																																																																																																
				0	Operation inhibited																																																																																																
		3	Tripped	1	Fault																																																																																																
				0	No Fault																																																																																																
		4	OFF2 inactive	1	OFF2 inactive																																																																																																
				0	OFF2 active																																																																																																
		5	OFF3 inactive	1	OFF3 inactive																																																																																																
0	OFF3 active																																																																																																				
6	Switch-on inhibited	1	Switch-on inhibited																																																																																																		
		0	--																																																																																																		
7	Warning	1	Warning active																																																																																																		
		0	No warning active																																																																																																		
8	At setpoint	1	Operating - Actual value equals reference = is within tolerance limits (see parameters 46.21 - 46.23)																																																																																																		
		0	Actual value differs from reference = is outside tolerance limits																																																																																																		
9	Remote	1	Drive control location: Remote (EXT1 or EXT2)																																																																																																		
		0	Drive control location: Local																																																																																																		
10	Trickle Current Active	0	Trickle Current OFF																																																																																																		
		1	Trickle Current ON																																																																																																		
11	De-Ice Mode Active	0	De-Ice Mode OFF																																																																																																		
		1	De-Ice Mode ON																																																																																																		
12	CTD Run	0	CTD Drive Not Running																																																																																																		
		1	CTD Drive Running																																																																																																		
13	CTD HOLD	0	CTD Autophase OFF																																																																																																		
		1	CTD Autophase ON																																																																																																		
14	User bit 3	-	See parameter 06.33 MSW bit 14 sel																																																																																																		
15	Reserved																																																																																																				

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions			
CONTROL AND STATUS WORDS (Continued)	DRIVE STATUS WORD 1 (06.16)	Default: Read Only Range: 0000h - FFFFh			
		Drive status word 1. This parameter is read-only.			
		Bit	Name	Descriptions	
		0	Enabled	1 = Both run enable (see par. 20.12) and start enable (20.19) signals are present Note: This bit is not affected by the presence of a fault	
		1	Inhibited	1 = Start inhibited - See parameters 06.18 and 06.25 for the source of the inhibiting signal	
		2	DC charged	1 = DC circuit has been charged	
		3	Ready to start	1 = Drive is ready to receive a start command	
		4	Following reference	1 = Drive is ready to follow given reference	
		5	Started	1 = Drive has been started	
		6	Modulating	1 = Drive is modulating (output stage is being controlled)	
7	Limiting	1 = Any operating limit (speed, torque, etc.) is active			
8	Local control	1 = Drive is in local control			
	Network ctrl	1 = Drive is in network control			
10	Ext1 active	1 = Control location Ext1 active			
11	Ext2 active	1 = Control location Ext2 active			
12	Reserved				
13	Start request	1 = Start requested			
14-15	Reserved				

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions																																																			
CONTROL AND STATUS WORDS (Continued)	DRIVE STATUS WORD 2 (06.17)	Default: Read Only Range: 0000h - FFFFh																																																			
		Drive status word 2. This parameter is read-only.																																																			
		<table border="1"> <thead> <tr> <th data-bbox="699 415 773 457">Bit</th> <th data-bbox="773 415 987 457">Name</th> <th data-bbox="987 415 1497 457">Descriptions</th> </tr> </thead> <tbody> <tr> <td data-bbox="699 457 773 520">0</td> <td data-bbox="773 457 987 520">Identification run done</td> <td data-bbox="987 457 1497 520">1 = Motor identification (ID) run has been performed</td> </tr> <tr> <td data-bbox="699 520 773 562">1</td> <td data-bbox="773 520 987 562">Magnetized</td> <td data-bbox="987 520 1497 562">1 = The motor has been magnetized</td> </tr> <tr> <td data-bbox="699 562 773 604">2</td> <td data-bbox="773 562 987 604">Torque control</td> <td data-bbox="987 562 1497 604">1 = Torque control mode active</td> </tr> <tr> <td data-bbox="699 604 773 646">3</td> <td data-bbox="773 604 987 646">Speed control</td> <td data-bbox="987 604 1497 646">1 = Speed control mode active</td> </tr> <tr> <td data-bbox="699 646 773 688">4</td> <td data-bbox="773 646 987 688">Power control</td> <td data-bbox="987 646 1497 688">1 = Power control mode active</td> </tr> <tr> <td data-bbox="699 688 773 772">5</td> <td data-bbox="773 688 987 772">Safe reference active</td> <td data-bbox="987 688 1497 772">1 = A "safe" reference is being applied by functions such as parameters 49.05 and 50.02</td> </tr> <tr> <td data-bbox="699 772 773 856">6</td> <td data-bbox="773 772 987 856">Last speed active</td> <td data-bbox="987 772 1497 856">1 = A "last speed" reference is being applied by functions such as parameters 49.05 and 50.02</td> </tr> <tr> <td data-bbox="699 856 773 898">7</td> <td data-bbox="773 856 987 898">Loss of reference</td> <td data-bbox="987 856 1497 898">1 = Reference signal lost</td> </tr> <tr> <td data-bbox="699 898 773 961">8</td> <td data-bbox="773 898 987 961">Emergency stop failed</td> <td data-bbox="987 898 1497 961">1 = Emergency stop failed (see parameters 31.32 and 31.33)</td> </tr> <tr> <td data-bbox="699 961 773 1003">9</td> <td data-bbox="773 961 987 1003">Jogging active</td> <td data-bbox="987 961 1497 1003">1 = Jogging enable signal is on</td> </tr> <tr> <td data-bbox="699 1003 773 1108">10</td> <td data-bbox="773 1003 987 1108">Above limit</td> <td data-bbox="987 1003 1497 1108">1 = Actual speed, frequency or torque equals or exceeds limit (defined by parameters 46.31 - 46.33) - Valid in both directions of rotation</td> </tr> <tr> <td data-bbox="699 1108 773 1192">11</td> <td data-bbox="773 1108 987 1192">Emergency stop active</td> <td data-bbox="987 1108 1497 1192">1 = An emergency stop command signal is active, or the drive is stopping after receiving an emergency stop command</td> </tr> <tr> <td data-bbox="699 1192 773 1255">12</td> <td data-bbox="773 1192 987 1255">Reduced run</td> <td data-bbox="987 1192 1497 1255">1 = Reduced run active (see section Reduced run function)</td> </tr> <tr> <td data-bbox="699 1255 773 1297">13</td> <td colspan="2" data-bbox="773 1255 1497 1297">Reserved</td> </tr> <tr> <td data-bbox="699 1297 773 1360">14</td> <td data-bbox="773 1297 987 1360">Stop failed</td> <td data-bbox="987 1297 1497 1360">1 = Stopping failed (see parameters 31.37 and 31.38)</td> </tr> <tr> <td data-bbox="699 1360 773 1409">15</td> <td colspan="2" data-bbox="773 1360 1497 1409">Reserved</td> </tr> </tbody> </table>	Bit	Name	Descriptions	0	Identification run done	1 = Motor identification (ID) run has been performed	1	Magnetized	1 = The motor has been magnetized	2	Torque control	1 = Torque control mode active	3	Speed control	1 = Speed control mode active	4	Power control	1 = Power control mode active	5	Safe reference active	1 = A "safe" reference is being applied by functions such as parameters 49.05 and 50.02	6	Last speed active	1 = A "last speed" reference is being applied by functions such as parameters 49.05 and 50.02	7	Loss of reference	1 = Reference signal lost	8	Emergency stop failed	1 = Emergency stop failed (see parameters 31.32 and 31.33)	9	Jogging active	1 = Jogging enable signal is on	10	Above limit	1 = Actual speed, frequency or torque equals or exceeds limit (defined by parameters 46.31 - 46.33) - Valid in both directions of rotation	11	Emergency stop active	1 = An emergency stop command signal is active, or the drive is stopping after receiving an emergency stop command	12	Reduced run	1 = Reduced run active (see section Reduced run function)	13	Reserved		14	Stop failed	1 = Stopping failed (see parameters 31.37 and 31.38)	15	Reserved	
		Bit	Name	Descriptions																																																	
		0	Identification run done	1 = Motor identification (ID) run has been performed																																																	
		1	Magnetized	1 = The motor has been magnetized																																																	
		2	Torque control	1 = Torque control mode active																																																	
		3	Speed control	1 = Speed control mode active																																																	
		4	Power control	1 = Power control mode active																																																	
		5	Safe reference active	1 = A "safe" reference is being applied by functions such as parameters 49.05 and 50.02																																																	
		6	Last speed active	1 = A "last speed" reference is being applied by functions such as parameters 49.05 and 50.02																																																	
		7	Loss of reference	1 = Reference signal lost																																																	
		8	Emergency stop failed	1 = Emergency stop failed (see parameters 31.32 and 31.33)																																																	
		9	Jogging active	1 = Jogging enable signal is on																																																	
		10	Above limit	1 = Actual speed, frequency or torque equals or exceeds limit (defined by parameters 46.31 - 46.33) - Valid in both directions of rotation																																																	
11	Emergency stop active	1 = An emergency stop command signal is active, or the drive is stopping after receiving an emergency stop command																																																			
12	Reduced run	1 = Reduced run active (see section Reduced run function)																																																			
13	Reserved																																																				
14	Stop failed	1 = Stopping failed (see parameters 31.37 and 31.38)																																																			
15	Reserved																																																				

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions																																																			
CONTROL AND STATUS WORDS (Continued)	START INHIBIT STATUS WORD (06.18)	Default: Read Only Range: 0000h - FFFFh																																																			
		Start inhibit status word. This word specifies the source of the inhibiting signal that is preventing the drive from starting. The conditions marked with an asterisk (*) only require that the start command is cycled. In all other instances, the inhibiting condition must be removed first. See also parameter 06.25 Drive inhibit status word 2, and 06.16 Drive status word 1, bit 1. This parameter is read-only.																																																			
		<table border="1"> <thead> <tr> <th data-bbox="764 571 841 604">Bit</th> <th data-bbox="841 571 1052 604">Name</th> <th data-bbox="1052 571 1568 604">Descriptions</th> </tr> </thead> <tbody> <tr> <td data-bbox="764 604 841 716">0</td> <td data-bbox="841 604 1052 716">Not ready run</td> <td data-bbox="1052 604 1568 716">1 = DC voltage is missing or drive has not been parametrized correctly - Check the parameters in groups 95 and 99</td> </tr> <tr> <td data-bbox="764 716 841 783">1</td> <td data-bbox="841 716 1052 783">Ctrl location changed</td> <td data-bbox="1052 716 1568 783">* 1 = Control location has changed</td> </tr> <tr> <td data-bbox="764 783 841 850">2</td> <td data-bbox="841 783 1052 850">SSW inhibit</td> <td data-bbox="1052 783 1568 850">1 = Control program is keeping itself in inhibited state</td> </tr> <tr> <td data-bbox="764 850 841 884">3</td> <td data-bbox="841 850 1052 884">Fault reset</td> <td data-bbox="1052 850 1568 884">* 1 = A fault has been reset</td> </tr> <tr> <td data-bbox="764 884 841 917">4</td> <td data-bbox="841 884 1052 917">Lost start enable</td> <td data-bbox="1052 884 1568 917">1 = Start enable signal missing</td> </tr> <tr> <td data-bbox="764 917 841 951">5</td> <td data-bbox="841 917 1052 951">Lost run enable</td> <td data-bbox="1052 917 1568 951">1 = Run enable signal missing</td> </tr> <tr> <td data-bbox="764 951 841 1018">6</td> <td data-bbox="841 951 1052 1018">FSO inhibit</td> <td data-bbox="1052 951 1568 1018">1 = Operation prevented by FSO-xx safety functions module</td> </tr> <tr> <td data-bbox="764 1018 841 1052">7</td> <td data-bbox="841 1018 1052 1052">STO</td> <td data-bbox="1052 1018 1568 1052">1 = Safe torque off active</td> </tr> <tr> <td data-bbox="764 1052 841 1119">8</td> <td data-bbox="841 1052 1052 1119">Current Calibration ended</td> <td data-bbox="1052 1052 1568 1119">* 1 = Current calibration routine has finished</td> </tr> <tr> <td data-bbox="764 1119 841 1152">9</td> <td data-bbox="841 1119 1052 1152">ID run ended</td> <td data-bbox="1052 1119 1568 1152">* 1 = Motor identification run has finished</td> </tr> <tr> <td data-bbox="764 1152 841 1220">10</td> <td data-bbox="841 1152 1052 1220">Auto phase ended</td> <td data-bbox="1052 1152 1568 1220">* 1 = Autophasing routine has finished</td> </tr> <tr> <td data-bbox="764 1220 841 1253">11</td> <td data-bbox="841 1220 1052 1253">Em Off1</td> <td data-bbox="1052 1220 1568 1253">1 = Emergency stop signal (mode Off1)</td> </tr> <tr> <td data-bbox="764 1253 841 1287">12</td> <td data-bbox="841 1253 1052 1287">Em Off2</td> <td data-bbox="1052 1253 1568 1287">1 = Emergency stop signal (mode Off2)</td> </tr> <tr> <td data-bbox="764 1287 841 1320">13</td> <td data-bbox="841 1287 1052 1320">Em Off3</td> <td data-bbox="1052 1287 1568 1320">1 = Emergency stop signal (mode Off3)</td> </tr> <tr> <td data-bbox="764 1320 841 1388">14</td> <td data-bbox="841 1320 1052 1388">Auto reset inhibit</td> <td data-bbox="1052 1320 1568 1388">1 = The autoreset function is inhibiting operation</td> </tr> <tr> <td data-bbox="764 1388 841 1455">15</td> <td data-bbox="841 1388 1052 1455">Jogging active</td> <td data-bbox="1052 1388 1568 1455">1 = The jogging enable signal is inhibiting operation</td> </tr> </tbody> </table>	Bit	Name	Descriptions	0	Not ready run	1 = DC voltage is missing or drive has not been parametrized correctly - Check the parameters in groups 95 and 99	1	Ctrl location changed	* 1 = Control location has changed	2	SSW inhibit	1 = Control program is keeping itself in inhibited state	3	Fault reset	* 1 = A fault has been reset	4	Lost start enable	1 = Start enable signal missing	5	Lost run enable	1 = Run enable signal missing	6	FSO inhibit	1 = Operation prevented by FSO-xx safety functions module	7	STO	1 = Safe torque off active	8	Current Calibration ended	* 1 = Current calibration routine has finished	9	ID run ended	* 1 = Motor identification run has finished	10	Auto phase ended	* 1 = Autophasing routine has finished	11	Em Off1	1 = Emergency stop signal (mode Off1)	12	Em Off2	1 = Emergency stop signal (mode Off2)	13	Em Off3	1 = Emergency stop signal (mode Off3)	14	Auto reset inhibit	1 = The autoreset function is inhibiting operation	15	Jogging active	1 = The jogging enable signal is inhibiting operation
		Bit	Name	Descriptions																																																	
		0	Not ready run	1 = DC voltage is missing or drive has not been parametrized correctly - Check the parameters in groups 95 and 99																																																	
		1	Ctrl location changed	* 1 = Control location has changed																																																	
		2	SSW inhibit	1 = Control program is keeping itself in inhibited state																																																	
		3	Fault reset	* 1 = A fault has been reset																																																	
		4	Lost start enable	1 = Start enable signal missing																																																	
		5	Lost run enable	1 = Run enable signal missing																																																	
		6	FSO inhibit	1 = Operation prevented by FSO-xx safety functions module																																																	
		7	STO	1 = Safe torque off active																																																	
		8	Current Calibration ended	* 1 = Current calibration routine has finished																																																	
		9	ID run ended	* 1 = Motor identification run has finished																																																	
		10	Auto phase ended	* 1 = Autophasing routine has finished																																																	
		11	Em Off1	1 = Emergency stop signal (mode Off1)																																																	
12	Em Off2	1 = Emergency stop signal (mode Off2)																																																			
13	Em Off3	1 = Emergency stop signal (mode Off3)																																																			
14	Auto reset inhibit	1 = The autoreset function is inhibiting operation																																																			
15	Jogging active	1 = The jogging enable signal is inhibiting operation																																																			

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions			
CONTROL AND STATUS WORDS (Continued)	SPEED CONTROL STATUS WORD (06.19)	Default: Read Only Range: 0000h - FFFFh			
		Speed control status word. This parameter is read-only.			
		Bit	Name	Descriptions	
		0	Zero speed	1 = Drive is running at zero speed, ie. the absolute value of par. 90.01 Motor speed for control has remained below 21.06 Zero speed limit for longer than 21.07 Zero speed delay. Notes: • This bit is not updated when mechanical brake control is enabled by par. 44.06 and the drive is modulating. • During a ramp stop when the drive is running forward, the delay count runs whenever [90.01] < [21.06]. From the reverse direction, the delay count runs whenever 90.01 > -[21.06].	
		1	Forward	1 = Drive is running in forward direction above zero speed limit,	
		2	Reverse	1 = Drive is running in reverse direction above zero speed limit, ie. [90.01] < -[21.06]	
		3	Out of window	1 = Speed error window control active (see par. 24.41)	
		4	Internal speed feedback	1 = Estimated speed feedback used in motor control, ie. estimated speed is selected by par. 90.41 or 90.46, or selected encoder has faulted (par. 90.45) 0 = Encoder 1 or 2 used for speed feedback	
		5	Encoder 1 feedback	1 = Encoder 1 used for speed feedback in motor control 0 = Encoder 1 faulted or not selected as source of speed feedback (see par. 90.41 and 90.46)	
		6	Encoder 2 feedback	1 = Encoder 2 used for speed feedback in motor control 0 = Encoder 2 faulted or not selected as source of speed feedback (see par. 90.41 and 90.46)	
7	Any constant speed request	1 = A constant speed or frequency has been selected; see par. 06.20			
8	Follower speed corr min lim	1 = Minimum limit of speed correction (in a speed-controlled follower) has been reached (see par. 23.39 - 23.41)			
9	Follower speed corr max lim	1 = Maximum limit of speed correction (in a speed-controlled follower) has been reached (see par. 23.39 - 23.41)			
10 - 15	Reserved				

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions																											
CONTROL AND STATUS WORDS (Continued)	SPEED STATUS WORD (06.20)	Default: Read Only Range: 0000h - FFFFh Constant speed/frequency status word. Indicates which constant speed or frequency is active (if any). See also parameter 06.19 Speed control status word, bit 7, and section Constant speeds/frequencies. This parameter is read-only. <table border="1" data-bbox="771 493 1567 840"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Descriptions</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Constant speed 1</td> <td>1 = Constant speed or frequency 1 selected</td> </tr> <tr> <td>1</td> <td>Constant speed 2</td> <td>1 = Constant speed or frequency 2 selected</td> </tr> <tr> <td>2</td> <td>Constant speed 3</td> <td>1 = Constant speed or frequency 3 selected</td> </tr> <tr> <td>3</td> <td>Constant speed 4</td> <td>1 = Constant speed or frequency 4 selected</td> </tr> <tr> <td>4</td> <td>Constant speed 5</td> <td>1 = Constant speed or frequency 5 selected</td> </tr> <tr> <td>5</td> <td>Constant speed 6</td> <td>1 = Constant speed or frequency 6 selected</td> </tr> <tr> <td>6</td> <td>Constant speed 7</td> <td>1 = Constant speed or frequency 7 selected</td> </tr> <tr> <td>7 - 15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>	Bit	Name	Descriptions	0	Constant speed 1	1 = Constant speed or frequency 1 selected	1	Constant speed 2	1 = Constant speed or frequency 2 selected	2	Constant speed 3	1 = Constant speed or frequency 3 selected	3	Constant speed 4	1 = Constant speed or frequency 4 selected	4	Constant speed 5	1 = Constant speed or frequency 5 selected	5	Constant speed 6	1 = Constant speed or frequency 6 selected	6	Constant speed 7	1 = Constant speed or frequency 7 selected	7 - 15	Reserved	
	Bit	Name	Descriptions																										
	0	Constant speed 1	1 = Constant speed or frequency 1 selected																										
	1	Constant speed 2	1 = Constant speed or frequency 2 selected																										
	2	Constant speed 3	1 = Constant speed or frequency 3 selected																										
	3	Constant speed 4	1 = Constant speed or frequency 4 selected																										
	4	Constant speed 5	1 = Constant speed or frequency 5 selected																										
	5	Constant speed 6	1 = Constant speed or frequency 6 selected																										
	6	Constant speed 7	1 = Constant speed or frequency 7 selected																										
	7 - 15	Reserved																											
CONSTANT SPEED STATUS WORD (06.25)	Default: Read Only Range: 0000h - FFFFh Drive inhibit status word 2. This word specifies the source of the inhibiting signal that is preventing the drive from starting. See also parameter 06.18 Start inhibit status word, and 06.16 Drive status word 1, bit 1. This parameter is read-only. <table border="1" data-bbox="771 1060 1567 1512"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Descriptions</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Follower drive</td> <td>1 = A follower is preventing the master from starting</td> </tr> <tr> <td>1</td> <td>Application</td> <td>1 = The application program is preventing the drive from starting</td> </tr> <tr> <td>2</td> <td>Aux. power failure</td> <td>1 = A control unit auxiliary power failure is preventing the drive from starting</td> </tr> <tr> <td>3</td> <td>Encoder feedback</td> <td>1 = The encoder feedback configuration is preventing the drive from starting</td> </tr> <tr> <td>4</td> <td>Ref source parametrization</td> <td>1 = A reference source parametrization conflict is preventing the drive from starting. See warning A6DA Reference source parametrization</td> </tr> <tr> <td>5 - 15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>	Bit	Name	Descriptions	0	Follower drive	1 = A follower is preventing the master from starting	1	Application	1 = The application program is preventing the drive from starting	2	Aux. power failure	1 = A control unit auxiliary power failure is preventing the drive from starting	3	Encoder feedback	1 = The encoder feedback configuration is preventing the drive from starting	4	Ref source parametrization	1 = A reference source parametrization conflict is preventing the drive from starting. See warning A6DA Reference source parametrization	5 - 15	Reserved								
Bit	Name	Descriptions																											
0	Follower drive	1 = A follower is preventing the master from starting																											
1	Application	1 = The application program is preventing the drive from starting																											
2	Aux. power failure	1 = A control unit auxiliary power failure is preventing the drive from starting																											
3	Encoder feedback	1 = The encoder feedback configuration is preventing the drive from starting																											
4	Ref source parametrization	1 = A reference source parametrization conflict is preventing the drive from starting. See warning A6DA Reference source parametrization																											
5 - 15	Reserved																												
MSW BIT 14 SEL (06.33)	Default: False (0) Range: 0, 1, Other																												
False	0																												
True	1																												
Other [bit]	Source selection (see Terms and abbreviations)																												
	Selects a binary source whose status is transmitted as bit 14 of 06.11 Main status word.																												

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions																																										
CONTROL AND STATUS WORDS (Continued)	LSU STATUS WORD (06.36)	<p>Default: Read Only Range: 0000h - FFFFh</p> <p>(Only visible with a BCU control unit) Shows the status of the supply unit. See also section Control of a supply unit (LSU), and parameter group 60 DDCS communication. This parameter is read-only.</p> <table border="1" data-bbox="711 478 1500 1108"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Descriptions</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Ready on</td> <td>1 = Ready to switch on</td> </tr> <tr> <td>1</td> <td>Ready run</td> <td>1 = Ready to operate, DC link charged</td> </tr> <tr> <td>2</td> <td>Ready ref</td> <td>1 = Operation enabled</td> </tr> <tr> <td>3</td> <td>Tripped</td> <td>1 = A fault is active</td> </tr> <tr> <td>4-6</td> <td colspan="2">Reserved</td> </tr> <tr> <td>7</td> <td>Warning</td> <td>1 = A warning is active</td> </tr> <tr> <td>8</td> <td>Modulating</td> <td>1 = The supply unit is modulating</td> </tr> <tr> <td>9</td> <td>Remote</td> <td>1 = Remote control (EXT1 or EXT2) 0 = Local control</td> </tr> <tr> <td>10</td> <td>Net ok</td> <td>1 = Supply network voltage OK</td> </tr> <tr> <td>11-12</td> <td colspan="2">Reserved</td> </tr> <tr> <td>13</td> <td>Charging or ready run</td> <td>1 = Bit 1 or bit 14 active</td> </tr> <tr> <td>14</td> <td>Charging</td> <td>1 = Charging contactor closed 0 = Charging contactor open</td> </tr> <tr> <td>15</td> <td colspan="2">Reserved</td> </tr> </tbody> </table>	Bit	Name	Descriptions	0	Ready on	1 = Ready to switch on	1	Ready run	1 = Ready to operate, DC link charged	2	Ready ref	1 = Operation enabled	3	Tripped	1 = A fault is active	4-6	Reserved		7	Warning	1 = A warning is active	8	Modulating	1 = The supply unit is modulating	9	Remote	1 = Remote control (EXT1 or EXT2) 0 = Local control	10	Net ok	1 = Supply network voltage OK	11-12	Reserved		13	Charging or ready run	1 = Bit 1 or bit 14 active	14	Charging	1 = Charging contactor closed 0 = Charging contactor open	15	Reserved	
Bit	Name	Descriptions																																										
0	Ready on	1 = Ready to switch on																																										
1	Ready run	1 = Ready to operate, DC link charged																																										
2	Ready ref	1 = Operation enabled																																										
3	Tripped	1 = A fault is active																																										
4-6	Reserved																																											
7	Warning	1 = A warning is active																																										
8	Modulating	1 = The supply unit is modulating																																										
9	Remote	1 = Remote control (EXT1 or EXT2) 0 = Local control																																										
10	Net ok	1 = Supply network voltage OK																																										
11-12	Reserved																																											
13	Charging or ready run	1 = Bit 1 or bit 14 active																																										
14	Charging	1 = Charging contactor closed 0 = Charging contactor open																																										
15	Reserved																																											

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions																																				
CONTROL AND STATUS WORDS (Continued)	INTERNAL STATE MACHINE LSU CW (06.39)	<p>Default: Read Only Range: 0000h - FFFFh</p> <p>(Only visible with a BCU control unit) Shows the control word sent to the supply unit from the INULSU (inverter unit/supply unit) state machine. This parameter is read-only.</p> <table border="1" data-bbox="781 478 1552 1150"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Descriptions</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>ON/OFF</td> <td>1 = Start charging 0 = Open main contactor (switch power off)</td> </tr> <tr> <td>1</td> <td>OFF 2</td> <td>0 = Emergency stop (Off2)</td> </tr> <tr> <td>2</td> <td>OFF 3</td> <td>0 = Emergency stop (Off3)</td> </tr> <tr> <td>3</td> <td>START</td> <td>1 = Start modulating 0 = Stop modulating</td> </tr> <tr> <td>4-6</td> <td colspan="2">Reserved</td> </tr> <tr> <td>7</td> <td>RESET</td> <td>0 -> 1 = Reset an active fault - A fresh start command is required after reset</td> </tr> <tr> <td>8-11</td> <td colspan="2">Reserved</td> </tr> <tr> <td>12</td> <td>USER BIT 0</td> <td>See parameter 06.40 LSU CW user bit 0 selection</td> </tr> <tr> <td>13</td> <td>USER BIT 1</td> <td>See parameter 06.41 LSU CW user bit 1 selection</td> </tr> <tr> <td>14</td> <td>USER BIT 2</td> <td>See parameter 06.42 LSU CW user bit 2 selection</td> </tr> <tr> <td>15</td> <td>USER BIT 3</td> <td>See parameter 06.43 LSU CW user bit 3 selection</td> </tr> </tbody> </table>	Bit	Name	Descriptions	0	ON/OFF	1 = Start charging 0 = Open main contactor (switch power off)	1	OFF 2	0 = Emergency stop (Off2)	2	OFF 3	0 = Emergency stop (Off3)	3	START	1 = Start modulating 0 = Stop modulating	4-6	Reserved		7	RESET	0 -> 1 = Reset an active fault - A fresh start command is required after reset	8-11	Reserved		12	USER BIT 0	See parameter 06.40 LSU CW user bit 0 selection	13	USER BIT 1	See parameter 06.41 LSU CW user bit 1 selection	14	USER BIT 2	See parameter 06.42 LSU CW user bit 2 selection	15	USER BIT 3	See parameter 06.43 LSU CW user bit 3 selection
	Bit	Name	Descriptions																																			
0	ON/OFF	1 = Start charging 0 = Open main contactor (switch power off)																																				
1	OFF 2	0 = Emergency stop (Off2)																																				
2	OFF 3	0 = Emergency stop (Off3)																																				
3	START	1 = Start modulating 0 = Stop modulating																																				
4-6	Reserved																																					
7	RESET	0 -> 1 = Reset an active fault - A fresh start command is required after reset																																				
8-11	Reserved																																					
12	USER BIT 0	See parameter 06.40 LSU CW user bit 0 selection																																				
13	USER BIT 1	See parameter 06.41 LSU CW user bit 1 selection																																				
14	USER BIT 2	See parameter 06.42 LSU CW user bit 2 selection																																				
15	USER BIT 3	See parameter 06.43 LSU CW user bit 3 selection																																				
LSU CW USER BIT 0 SELECTION (06.40)	<p>Default: MCW user bit 0 (2) Range: 0 - 5, Other</p> <table border="1" data-bbox="781 1241 1552 1524"> <tbody> <tr> <td>False (0)</td> <td>0</td> </tr> <tr> <td>True (1)</td> <td>1</td> </tr> <tr> <td>MCW user bit 0 (2)</td> <td>Bit 12 of 06.01 Main control word</td> </tr> <tr> <td>MCW user bit 1 (3)</td> <td>Bit 13 of 06.01 Main control word</td> </tr> <tr> <td>MCW user bit 2 (4)</td> <td>Bit 14 of 06.01 Main control word</td> </tr> <tr> <td>MCW user bit 3 (5)</td> <td>Bit 15 of 06.01 Main control word</td> </tr> <tr> <td>Other [bit]</td> <td>Source selection (see Terms and abbreviations)</td> </tr> </tbody> </table> <p>(Only visible with a BCU control unit) Selects a binary source whose status is transmitted as bit 12 of 06.39 Internal state machine LSU CW to the supply unit.</p>	False (0)	0	True (1)	1	MCW user bit 0 (2)	Bit 12 of 06.01 Main control word	MCW user bit 1 (3)	Bit 13 of 06.01 Main control word	MCW user bit 2 (4)	Bit 14 of 06.01 Main control word	MCW user bit 3 (5)	Bit 15 of 06.01 Main control word	Other [bit]	Source selection (see Terms and abbreviations)																							
False (0)	0																																					
True (1)	1																																					
MCW user bit 0 (2)	Bit 12 of 06.01 Main control word																																					
MCW user bit 1 (3)	Bit 13 of 06.01 Main control word																																					
MCW user bit 2 (4)	Bit 14 of 06.01 Main control word																																					
MCW user bit 3 (5)	Bit 15 of 06.01 Main control word																																					
Other [bit]	Source selection (see Terms and abbreviations)																																					

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
CONTROL AND STATUS WORDS (Continued)	LSU CW USER BIT 1 SELECTION (06.41)	Default: MCW user bit 1 (3) Range: 0 - 5, Other
	False (0)	0
	True (1)	1
	MCW user bit 0 (2)	Bit 12 of 06.01 Main control word
	MCW user bit 1 (3)	Bit 13 of 06.01 Main control word
	MCW user bit 2 (4)	Bit 14 of 06.01 Main control word
	MCW user bit 3 (5)	Bit 15 of 06.01 Main control word
	Other [bit]	Source selection (see Terms and abbreviations)
		(Only visible with a BCU control unit) Selects a binary source whose status is transmitted as bit 12 of 06.39 Internal state machine LSU CW to the supply unit.
	LSU CW USER BIT 2 SELECTION (06.42)	Default: MCW user bit 2 (4) Range: 0 - 5, Other
	False (0)	0
	True (1)	1
	MCW user bit 0 (2)	Bit 12 of 06.01 Main control word
	MCW user bit 1 (3)	Bit 13 of 06.01 Main control word
	MCW user bit 2 (4)	Bit 14 of 06.01 Main control word
	MCW user bit 3 (5)	Bit 15 of 06.01 Main control word
	Other [bit]	Source selection (see Terms and abbreviations)
		(Only visible with a BCU control unit) Selects a binary source whose status is transmitted as bit 14 of 06.39 Internal state machine LSU CW to the supply unit.
	LSU CW USER BIT 3 SELECTION (06.43)	Default: MCW user bit 3 (5) Range: 0 - 5, Other
	False (0)	0
	True (1)	1
	MCW user bit 0 (2)	Bit 12 of 06.01 Main control word
	MCW user bit 1 (3)	Bit 13 of 06.01 Main control word
	MCW user bit 2 (4)	Bit 14 of 06.01 Main control word
	MCW user bit 3 (5)	Bit 15 of 06.01 Main control word
	Other [bit]	Source selection (see Terms and abbreviations)
		(Only visible with a BCU control unit) Selects a binary source whose status is transmitted as bit 15 of 06.39 Internal state machine LSU CW to the supply unit.

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
CONTROL AND STATUS WORDS (Continued)	FOLLOWER CW USER BIT 0 SELECTION (06.45)	Default: MCW user bit 0 (2) Range: 0 - 5, Other
	False (0)	0
	True (1)	1
	MCW user bit 0 (2)	Bit 12 of 06.01 Main control word
	MCW user bit 1 (3)	Bit 13 of 06.01 Main control word
	MCW user bit 2 (4)	Bit 14 of 06.01 Main control word
	MCW user bit 3 (5)	Bit 15 of 06.01 Main control word
	Other [bit]	Source selection (see Terms and abbreviations)
		Selects a binary source whose status is transmitted as bit 12 of the Follower control word to follower drives. (Bits 0-11 of the Follower control word are taken from 06.01 Main control word.) See also section Master/follower functionality.
	FOLLOWER CW USER BIT 1 SELECTION (06.46)	Default: MCW user bit 1 (3) Range: 0 - 5, Other
	False (0)	0
	True (1)	1
	MCW user bit 0 (2)	Bit 12 of 06.01 Main control word
	MCW user bit 1 (3)	Bit 13 of 06.01 Main control word
	MCW user bit 2 (4)	Bit 14 of 06.01 Main control word
	MCW user bit 3 (5)	Bit 15 of 06.01 Main control word
	Other [bit]	Source selection (see Terms and abbreviations)
		Selects a binary source whose status is transmitted as bit 13 of the Follower control word to follower drives. (Bits 0-11 of the Follower control word are taken from 06.01 Main control word.)
	FOLLOWER CW USER BIT 2 SELECTION (06.47)	Default: MCW user bit 2 (4) Range: 0 - 5, Other
	False (0)	0
	True (1)	1
	MCW user bit 0 (2)	Bit 12 of 06.01 Main control word
	MCW user bit 1 (3)	Bit 13 of 06.01 Main control word
	MCW user bit 2 (4)	Bit 14 of 06.01 Main control word
MCW user bit 3 (5)	Bit 15 of 06.01 Main control word	
Other [bit]	Source selection (see Terms and abbreviations)	
	Selects a binary source whose status is transmitted as bit 14 of the Follower control word to follower drives. (Bits 0-11 of the Follower control word are taken from 06.01 Main control word.)	

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions															
CONTROL AND STATUS WORDS (Continued)	FOLLOWER CW USER BIT 3 SELECTION (06.48)	Default: MCW user bit 3 (5) Range: 0 - 5, Other															
	False (0)	0															
	True (1)	1															
	MCW user bit 0 (2)	Bit 12 of 06.01 Main control word															
	MCW user bit 1 (3)	Bit 13 of 06.01 Main control word															
	MCW user bit 2 (4)	Bit 14 of 06.01 Main control word															
	MCW user bit 3 (5)	Bit 15 of 06.01 Main control word															
	Other [bit]	Source selection (see Terms and abbreviations)															
		Selects a binary source whose status is transmitted as bit 15 of the Follower control word to follower drives. (Bits 0-11 of the Follower control word are taken from 06.01 Main control word.)															
	USER STATUS WORD 1 (06.50)	Default: Read Only Range: 0000h - FFFFh															
		User-defined status word. This word shows the status of the binary sources selected by parameters 06.60 - 06.75. This parameter is read-only.															
		<table border="1"> <thead> <tr> <th data-bbox="699 905 792 936">Bit</th> <th data-bbox="792 905 1008 936">Name</th> <th data-bbox="1008 905 1503 936">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="699 947 792 999">0</td> <td data-bbox="792 947 1008 999">User status bit 0</td> <td data-bbox="1008 947 1503 999">Status of source selected by parameter 06.60</td> </tr> <tr> <td data-bbox="699 1010 792 1062">1</td> <td data-bbox="792 1010 1008 1062">User status bit 1</td> <td data-bbox="1008 1010 1503 1062">Status of source selected by parameter 06.61</td> </tr> <tr> <td data-bbox="699 1073 792 1104">--</td> <td data-bbox="792 1073 1008 1104">--</td> <td data-bbox="1008 1073 1503 1104">--</td> </tr> <tr> <td data-bbox="699 1115 792 1167">15</td> <td data-bbox="792 1115 1008 1167">User status bit 15</td> <td data-bbox="1008 1115 1503 1167">Status of source selected by parameter 06.75</td> </tr> </tbody> </table>	Bit	Name	Description	0	User status bit 0	Status of source selected by parameter 06.60	1	User status bit 1	Status of source selected by parameter 06.61	--	--	--	15	User status bit 15	Status of source selected by parameter 06.75
	Bit	Name	Description														
	0	User status bit 0	Status of source selected by parameter 06.60														
	1	User status bit 1	Status of source selected by parameter 06.61														
	--	--	--														
	15	User status bit 15	Status of source selected by parameter 06.75														
	USER STATUS WORD 1 BIT 0 SEL (06.60)	Default: False (0) Range: 0, 1, Other															
	False	0															
	True	1															
Other [bit]	Source selection (see Terms and abbreviations)																
	Selects a binary source whose status is shown as bit 0 of 06.50 User status word 1.																
USER STATUS WORD 1 BIT 1 SEL (06.61)	Default: Out of Window (2) Range: 0 - 2, Other																
False	0																
True	1																
Other [bit]	Source selection (see Terms and abbreviations)																
	Selects a binary source whose status is shown as bit 0 of 06.50 User status word 1.																

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
CONTROL AND STATUS WORDS (Continued)	USER STATUS WORD 1 BIT 2 SEL (06.62)	Default: Emergency stop failed (2) Range: 0 - 2, Other
		False 0
		True 1
		Emergency stop failed 2 - Bit 8 of 06.17 Drive status word 2
		Other [bit] Source selection (see Terms and abbreviations) Selects a binary source whose status is shown as bit 2 of 06.50 User status word 1.
	USER STATUS WORD 1 BIT 3 SEL (06.63)	Default: Magnetized (2) Range: 0 - 2, Other
		False 0
		True 1
		Magnetized 2 - Bit 1 of 06.17 Drive status word 2
		Other [bit] Source selection (see Terms and abbreviations) Selects a binary source whose status is shown as bit 3 of 06.50 User status word 1.
	USER STATUS WORD 1 BIT 4 SEL (06.64)	Default: Run disable (2) Range: 0 - 2, Other
		False 0
		True 1
		Run disable 2 - Bit 5 of 06.18 Start inhibit status word
		Other [bit] Source selection (see Terms and abbreviations) Selects a binary source whose status is shown as bit 4 of 06.50 User status word 1.
	USER STATUS WORD 1 BIT 5 SEL (06.65)	Default: False (0) Range: 0, 1, Other
		False 0
		True 1
		Other [bit] Source selection (see Terms and abbreviations) Selects a binary source whose status is shown as bit 5 of 06.50 User status word 1.
	USER STATUS WORD 1 BIT 6 SEL (06.66)	Default: False (0) Range: 0, 1, Other
False 0		
True 1		
Other [bit] Source selection (see Terms and abbreviations) Selects a binary source whose status is shown as bit 6 of 06.50 User status word 1.		

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
CONTROL AND STATUS WORDS (Continued)	USER STATUS WORD 1 BIT 7 SEL (06.67) False True Identification run done Other [bit]	Default: Identification run done (2) Range: 0 - 2, Other
		0
		1
		2 - Bit 0 of 06.17 Drive status word 2
		Source selection (see Terms and abbreviations) Selects a binary source whose status is shown as bit 7 of 06.50 User status word 1.
	USER STATUS WORD 1 BIT 8 SEL (06.68) False True Start inhibition Other [bit]	Default: Start inhibition (2) Range: 0 - 2, Other
		0
		1
		2 - Bit 7 of 06.18 Start inhibit status word
		Source selection (see Terms and abbreviations) Selects a binary source whose status is shown as bit 8 of 06.50 User status word 1.
	USER STATUS WORD 1 BIT 9 SEL (06.69) False True Limiting Other [bit]	Default: Limiting (2) Range: 0 - 2, Other
		0
		1
		2 - Bit 7 of 06.16 Drive status word 1
		Source selection (see Terms and abbreviations) Selects a binary source whose status is shown as bit 9 of 06.50 User status word 1.
	USER STATUS WORD 1 BIT 10 SEL (06.70) False True Limiting Other [bit]	Default: Limiting (2) Range: 0 - 2, Other
		0
		1
		2 - Bit 2 of 06.17 Drive status word 2
		Source selection (see Terms and abbreviations) Selects a binary source whose status is shown as bit 9 of 06.50 User status word 1.
USER STATUS WORD 1 BIT 11 SEL (06.71) False True Limiting Other [bit]	Default: Zero speed (2) Range: 0 - 2, Other	
	0	
	1	
	2 - Bit 0 of 06.19 Speed control status word	
	Source selection (see Terms and abbreviations) Selects a binary source whose status is shown as bit 11 of 06.50 User status word 1.	

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions															
CONTROL AND STATUS WORDS (Continued)	USER STATUS WORD 1 BIT 12 SEL (06.72)	Default: Internal speed feedback (2) Range: 0 - 2, Other															
	False	0															
	True	1															
	Internal speed feedback	2 - Bit 4 of 06.19 Speed control status word															
	Other [bit]	Source selection (see Terms and abbreviations)															
		Selects a binary source whose status is shown as bit 12 of 06.50 User status word 1.															
	USER STATUS WORD 1 BIT 13 SEL (06.73)	Default: False (0) Range: 0,1, Other															
	False	0															
	True	1															
	Other [bit]	Source selection (see Terms and abbreviations)															
		Selects a binary source whose status is shown as bit 13 of 06.50 User status word 1.															
	USER STATUS WORD 1 BIT 14 SEL (06.74)	Default: False (0) Range: 0,1, Other															
	False	0															
	True	1															
	Other [bit]	Source selection (see Terms and abbreviations)															
		Selects a binary source whose status is shown as bit 14 of 06.50 User status word 1.															
	USER STATUS WORD 1 BIT 15 SEL (06.75)	Default: False (0) Range: 0,1, Other															
	False	0															
	True	1															
	Other [bit]	Source selection (see Terms and abbreviations)															
		Selects a binary source whose status is shown as bit 15 of 06.50 User status word 1.															
	USER CONTROL WORD 1 (06.100)	Default: Read Only Range: 0000h - FFFFh User-defined control word 1. This parameter is read-only.															
		<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>User control word 1 bit 0</td> <td>User defined bit</td> </tr> <tr> <td>1</td> <td>User control word 1 bit 1</td> <td>User defined bit</td> </tr> <tr> <td>--</td> <td>--</td> <td>--</td> </tr> <tr> <td>15</td> <td>User control word 1 bit 15</td> <td>User defined bit</td> </tr> </tbody> </table>	Bit	Name	Description	0	User control word 1 bit 0	User defined bit	1	User control word 1 bit 1	User defined bit	--	--	--	15	User control word 1 bit 15	User defined bit
	Bit	Name	Description														
0	User control word 1 bit 0	User defined bit															
1	User control word 1 bit 1	User defined bit															
--	--	--															
15	User control word 1 bit 15	User defined bit															
USER CONTROL WORD 2 (06.101)	Default: Read Only Range: 0000h - FFFFh User-defined control word 2. This parameter is read-only.																
	<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>User control word 2 bit 0</td> <td>User defined bit</td> </tr> <tr> <td>1</td> <td>User control word 2 bit 1</td> <td>User defined bit</td> </tr> <tr> <td>--</td> <td>--</td> <td>--</td> </tr> <tr> <td>15</td> <td>User control word 2 bit 15</td> <td>User defined bit</td> </tr> </tbody> </table>	Bit	Name	Description	0	User control word 2 bit 0	User defined bit	1	User control word 2 bit 1	User defined bit	--	--	--	15	User control word 2 bit 15	User defined bit	
Bit	Name	Description															
0	User control word 2 bit 0	User defined bit															
1	User control word 2 bit 1	User defined bit															
--	--	--															
15	User control word 2 bit 15	User defined bit															

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions																					
SYSTEM INFO		Drive hardware and firmware information. All parameters in this group are read-only.																					
	DRIVE RATING ID (07.03)	Default: Read Only Range: 0 - 999 Type of the drive/inverter unit.																					
	FIRMWARE NAME (07.04)	Default: Read Only Range: - Firmware identification																					
	FIRMWARE VERSION (07.05)	Default: Read Only Range: - Version number of the firmware.																					
	LOADING PACKAGE NAME (07.06)	Default: Read Only Range: - Name of the firmware loading package.																					
	LOADING PACKAGE VERSION (07.07)	Default: Read Only Range: - Version number of the firmware loading package.																					
	BOOTLOADER VERSION (07.08)	Default: Read Only Range: - Version number of the firmware bootloader.																					
	CPU USAGE (07.011)	Default: Read Only Range: - Microprocessor load in percent.																					
	PU LOGIC VERSION NUMBER (07.013)	Default: Read Only Range: - Version number of the power unit logic.																					
	APPLICATION ENVIRONMENT STATUS 1 (07.21)	Default: Read Only Range: 0000h - FFFFh Shows which tasks of the application program are running. <table border="1" data-bbox="701 1272 1477 1549"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Pre task</td> <td>1 = Pre-task running</td> </tr> <tr> <td>1</td> <td>Appl task1</td> <td>1 = Task 1 running</td> </tr> <tr> <td>2</td> <td>Appl task2</td> <td>1 = Task 2 running</td> </tr> <tr> <td>3</td> <td>Appl task3</td> <td>1 = Task 3 running</td> </tr> <tr> <td>4-14</td> <td>Reserved</td> <td></td> </tr> <tr> <td>15</td> <td>Task monitoring</td> <td>1 = Task monitoring enabled</td> </tr> </tbody> </table>	Bit	Name	Description	0	Pre task	1 = Pre-task running	1	Appl task1	1 = Task 1 running	2	Appl task2	1 = Task 2 running	3	Appl task3	1 = Task 3 running	4-14	Reserved		15	Task monitoring	1 = Task monitoring enabled
	Bit	Name	Description																				
	0	Pre task	1 = Pre-task running																				
	1	Appl task1	1 = Task 1 running																				
	2	Appl task2	1 = Task 2 running																				
3	Appl task3	1 = Task 3 running																					
4-14	Reserved																						
15	Task monitoring	1 = Task monitoring enabled																					
APPLICATION ENVIRONMENT STATUS 1 (07.22)	Default: Read Only Range: 0000h - FFFFh Shows the status of the openings in the application program. <table border="1" data-bbox="701 1667 1477 1864"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Opening1</td> <td>Status of opening 1 in the application program</td> </tr> <tr> <td>1</td> <td>Opening2</td> <td>Status of opening 2 in the application program</td> </tr> <tr> <td>--</td> <td>--</td> <td>--</td> </tr> <tr> <td>15</td> <td>Opening16</td> <td>Status of opening 16 in the application program</td> </tr> </tbody> </table>	Bit	Name	Description	0	Opening1	Status of opening 1 in the application program	1	Opening2	Status of opening 2 in the application program	--	--	--	15	Opening16	Status of opening 16 in the application program							
Bit	Name	Description																					
0	Opening1	Status of opening 1 in the application program																					
1	Opening2	Status of opening 2 in the application program																					
--	--	--																					
15	Opening16	Status of opening 16 in the application program																					

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions																								
SYSTEM INFO (Continued)	APPLICATION NAME (07.23)	Default: Read Only Range: – First five ASCII letters of the name given to the application program in the programming tool. The full name is visible under System info on the control panel or the Drive composer PC tool. _N/A_ = None																								
	APPLICATION VERSION (07.24)	Default: Read Only Range: – Application program version number given to the application program in the programming tool. Also visible under System info on the control panel or the Drive composer PC tool.																								
	CUSTOMIZATION PACKAGE NAME (07.25)	Default: Read Only Range: – First five ASCII letters of the name given to the customization package. The full name is visible under System info on the control panel or the Drive composer PC tool. _N/A_ = None																								
	CUSTOMIZATION PACKAGE NAME (07.26)	Default: Read Only Range: – Customization package version number. Also visible under System info on the control panel or the Drive composer PC tool.																								
	ADAPTIVE PROGRAM STATUS (07.30)	Default: Read Only Range: 0000h - FFFFh Shows the status of the adaptive program. See section Adaptive programming. <table border="1" data-bbox="768 1073 1563 1413"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Initialized</td> <td>1 = Adaptive program initialized</td> </tr> <tr> <td>1</td> <td>Editing</td> <td>1 = Adaptive program is being edited</td> </tr> <tr> <td>2</td> <td>Edit done</td> <td>1 = Editing of adaptive program finished</td> </tr> <tr> <td>3</td> <td>Running</td> <td>1 = Adaptive program running</td> </tr> <tr> <td>4-13</td> <td>Reserved</td> <td></td> </tr> <tr> <td>14</td> <td>State changing</td> <td>1 = State change in progress in adaptive programming engine</td> </tr> <tr> <td>15</td> <td>Faulted</td> <td>1 = Error in adaptive program</td> </tr> </tbody> </table>	Bit	Name	Description	0	Initialized	1 = Adaptive program initialized	1	Editing	1 = Adaptive program is being edited	2	Edit done	1 = Editing of adaptive program finished	3	Running	1 = Adaptive program running	4-13	Reserved		14	State changing	1 = State change in progress in adaptive programming engine	15	Faulted	1 = Error in adaptive program
	Bit	Name	Description																							
0	Initialized	1 = Adaptive program initialized																								
1	Editing	1 = Adaptive program is being edited																								
2	Edit done	1 = Editing of adaptive program finished																								
3	Running	1 = Adaptive program running																								
4-13	Reserved																									
14	State changing	1 = State change in progress in adaptive programming engine																								
15	Faulted	1 = Error in adaptive program																								
STANDARD DI, RO	Configuration of digital inputs and relay outputs. DI STATUS (10.01)	Default: Read Only Range: 0000h - FFFFh Displays the electrical status of digital inputs DI1L and DI6 - DI1. The activation/deactivation delays of the inputs (if any are specified) are ignored. A filtering time can be defined by parameter 10.51 DI filter time. Bits 0 - 5 reflect the status of DI1 - DI6; bit 15 reflects the status of the DI1L input. Example: 1000000000010011b = DI1L, DI5, DI2 and DI1 are on, DI3, DI4 and DI6 are off. This parameter is read-only.																								

Table 12-4 Level 1 Parameter Block Definitions


Block Title	Parameter (Number) Selection (Value)	Descriptions																		
STANDARD DI, RO (Continued)	DI STATUS (10.02)	Default: Read Only Range: 0000h - FFFFh Displays the status of digital inputs DI1L and DI6 - DI1. This word is updated only after activation/deactivation delays (if any are specified). Bits 0 - 5 reflect the delayed status of DI1 - DI6; bit 15 reflects the delayed status of the DI1L input. This parameter is read-only.																		
	DI FORCE SELECTION (10.03)	Default: Read Only Range: 0000h - FFFFh The electrical statuses of the digital inputs can be overridden for eg. testing purposes. A bit in parameter 10.04 DI force data is provided for each digital input, and its value is applied whenever the corresponding bit in this parameter is 1. <table border="1" data-bbox="703 688 1498 1041"> <thead> <tr> <th>Bit</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1 = Force DI1 to value of bit 0 of parameter 10.04 DI force data</td> </tr> <tr> <td>1</td> <td>1 = Force DI2 to value of bit 1 of parameter 10.04 DI force data</td> </tr> <tr> <td>2</td> <td>1 = Force DI3 to value of bit 2 of parameter 10.04 DI force data</td> </tr> <tr> <td>3</td> <td>1 = Force DI4 to value of bit 3 of parameter 10.04 DI force data</td> </tr> <tr> <td>4</td> <td>1 = Force DI5 to value of bit 4 of parameter 10.04 DI force data</td> </tr> <tr> <td>5</td> <td>1 = Force DI6 to value of bit 5 of parameter 10.04 DI force data</td> </tr> <tr> <td>6-14</td> <td>Reserved</td> </tr> <tr> <td>15</td> <td>1 = Force DI1L to value of bit 15 of parameter 10.04 DI force data</td> </tr> </tbody> </table>	Bit	Value	0	1 = Force DI1 to value of bit 0 of parameter 10.04 DI force data	1	1 = Force DI2 to value of bit 1 of parameter 10.04 DI force data	2	1 = Force DI3 to value of bit 2 of parameter 10.04 DI force data	3	1 = Force DI4 to value of bit 3 of parameter 10.04 DI force data	4	1 = Force DI5 to value of bit 4 of parameter 10.04 DI force data	5	1 = Force DI6 to value of bit 5 of parameter 10.04 DI force data	6-14	Reserved	15	1 = Force DI1L to value of bit 15 of parameter 10.04 DI force data
	Bit	Value																		
	0	1 = Force DI1 to value of bit 0 of parameter 10.04 DI force data																		
	1	1 = Force DI2 to value of bit 1 of parameter 10.04 DI force data																		
2	1 = Force DI3 to value of bit 2 of parameter 10.04 DI force data																			
3	1 = Force DI4 to value of bit 3 of parameter 10.04 DI force data																			
4	1 = Force DI5 to value of bit 4 of parameter 10.04 DI force data																			
5	1 = Force DI6 to value of bit 5 of parameter 10.04 DI force data																			
6-14	Reserved																			
15	1 = Force DI1L to value of bit 15 of parameter 10.04 DI force data																			
DI FORCE DATA (10.04)	Default: Read Only Range: 0000h - FFFFh Contains the values that the digital inputs are forced to when selected by 10.03 DI force selection. Bit 0 is the forced value for DI1; bit 15 is the forced value for the DI1L input.																			
DI ON DELAY (10.05)	Default: 0.0 s Range: 0.0 to 3000.0 s Defines the activation delay for digital input DI1. <div style="text-align: center;">  <p>t_{on} = 10.05 DI1 ON delay t_{off} = 10.26 DI1 OFF delay</p> <p>*Electrical status of digital input. Indicated by 10.01 DI status **Indicated by 10.02 DI delayed status.</p> </div>																			
DI OFF DELAY (10.06)	Default: 0.0 s Range: 0.0 to 3000.0 s Defines the deactivation delay for digital input DI1. See parameter 10.05 DI1 ON delay.																			

Table 12-4 Level 1 Parameter Block Definitions




Block Title	Parameter (Number) Selection (Value)	Descriptions
STANDARD DI, RO (Continued)	DI2 ON DELAY (10.07)	Default: 0.0 s Range: 0.0 to 3000.0 s
		Defines the activation delay for digital input DI2.  <p> t_{on} = 10.07 DI2 ON delay t_{off} = 10.08 DI2 OFF delay *Electrical status of digital input. Indicated by 10.01 DI status **Indicated by 10.02 DI delayed status. </p>
	DI OFF DELAY (10.08)	Default: 0.0 s Range: 0.0 to 3000.0 s
		Defines the deactivation delay for digital input DI2. See parameter 10.07 DI2 ON delay.
	DI2 ON DELAY (10.09)	Default: 0.0 s Range: 0.0 to 3000.0 s
	Defines the activation delay for digital input DI2.  <p> t_{on} = 10.09 DI2 ON delay t_{off} = 10.10 DI2 OFF delay *Electrical status of digital input. Indicated by 10.01 DI status **Indicated by 10.02 DI delayed status. </p>	
DI3 OFF DELAY (10.10)	Default: 0.0 s Range: 0.0 to 3000.0 s	
	Defines the deactivation delay for digital input DI3. See parameter 10.09 DI3 ON delay.	
DI4 ON DELAY (10.011)	Default: 0.0 s Range: 0.0 to 3000.0 s	
	Defines the activation delay for digital input DI4.  <p> t_{on} = 10.11 DI4 ON delay t_{off} = 10.12 DI4 OFF delay *Electrical status of digital input. Indicated by 10.01 DI status **Indicated by 10.02 DI delayed status. </p>	

Table 12-4 Level 1 Parameter Block Definitions



Block Title	Parameter (Number) Selection (Value)	Descriptions
STANDARD DI, RO (Continued)	DI4 OFF DELAY (10.12)	Default: 0.0 s Range: 0.0 to 3000.0 s Defines the deactivation delay for digital input DI4. See parameter 10.11 DI4 ON delay.
	DI5 ON DELAY (10.013)	Default: 0.0 s Range: 0.0 to 3000.0 s Defines the activation delay for digital input DI5.  t_{on} = 10.13 DI5 ON delay t_{off} = 10.14 DI5 OFF delay *Electrical status of digital input. Indicated by 10.01 DI status **Indicated by 10.02 DI delayed status.
	DI5 OFF DELAY (10.14)	Default: 0.0 s Range: 0.0 to 3000.0 s Defines the deactivation delay for digital input DI5. See parameter 10.13 DI5 ON delay.
	DI6 ON DELAY (10.015)	Default: 0.0 s Range: 0.0 to 3000.0 s Defines the activation delay for digital input DI6.  t_{on} = 10.15 DI6 ON delay t_{off} = 10.16 DI6 OFF delay *Electrical status of digital input. Indicated by 10.01 DI status **Indicated by 10.02 DI delayed status.
	DI6 OFF DELAY (10.16)	Default: 0.0 s Range: 0.0 to 3000.0 s Defines the deactivation delay for digital input DI6. See parameter 10.15 DI6 ON delay.
	RO STATUS (10.21)	Default: Read Only Range: 0000h - FFFFh Status of relay outputs RO8 - RO1. Example: 00000001b = RO1 is energized, RO2 - RO8 are de-energized.

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
STANDARD DI, RO (Continued)	RO1 SOURCE (10.24)	Default: Ready run (2) Range: 0 - 44, Other
	Not energized (0) Enabled (4)	Output is not energized
	Energized (1)	Output is energized
	Ready run (2)	Bit 1 of 06.11 Main status word
	Enabled (4)	Bit 0 of 06.16 Drive status word 1
	Started (5)	Bit 5 of 06.16 Drive status word 1
	Magnetized (6)	Bit 1 of 06.17 Drive status word 2
	Running (7)	Bit 6 of 06.16 Drive status word 1
	Ready ref (8)	Bit 2 of 06.11 Main status word
	At setpoint (9)	Bit 8 of 06.11 Main status word
	Reverse (10)	Bit 2 of 06.19 Speed control status word
	Zero speed (11)	Bit 0 of 06.19 Speed control status word
	Above limit (12)	Bit 10 of 06.17 Drive status word 2
	Warning (13)	Bit 7 of 06.11 Main status word
	Fault (14)	Bit 3 of 06.11 Main status word
	Fault (-1) (15)	Inverted bit 3 of 06.11 Main status word
	Open brake command (22)	Bit 0 of 44.01 Brake control status
	Ext2 active (23)	Bit 11 of 06.16 Drive status word 1
	Remote control (24)	Bit 9 of 06.11 Main status word
	Supervision 1 (33)	Bit 0 of 32.01 Supervision status
	Supervision 2 (34)	Bit 1 of 32.01 Supervision status
	Supervision 3 (35)	Bit 2 of 32.01 Supervision status
	RO/DIO control word bit 0 (40)	Bit 0 of 10.99 RO/DIO control word
	RO/DIO control word bit 1 (41)	Bit 1 of 10.99 RO/DIO control word
	RO/DIO control word bit 2 (42)	Bit 2 of 10.99 RO/DIO control word
	RO/DIO control word bit 8 (43)	Bit 8 of 10.99 RO/DIO control word
	RO/DIO control word bit 9 (44)	Bit 9 of 10.99 RO/DIO control word
	Other [bit]	Source selection (see Terms and abbreviations)
		Selects a drive signal to be connected to relay output RO1.

Table 12-4 Level 1 Parameter Block Definitions



Block Title	Parameter (Number) Selection (Value)	Descriptions
STANDARD DI, RO (Continued)	RO1 ON DELAY (10.025)	Default: 0.0 s Range: 0.0 to 3000.0 s Defines the activation delay for relay output RO1.  <p> t_{On} = 10.25 RO1 ON delay t_{Off} = 10.26 RO1 OFF delay </p>
	RO1 OFF DELAY (10.26)	Default: 0.0 s Range: 0.0 to 3000.0 s Defines the deactivation delay for relay output RO1. See parameter 10.25 RO1 ON delay.
	RO2 SOURCE (10.27)	Default: Running (7) (95.20 b3) Range: 0 - 44, Other Selects a drive signal to be connected to relay output RO2. For the available selections, see parameter 10.24 RO1 source.
	RO2 ON DELAY (10.028)	Default: 0.0 s (95.20 b3) Range: 0.0 to 3000.0 s Defines the activation delay for relay output RO2.  <p> t_{On} = 10.28 RO2 ON delay t_{Off} = 10.29 RO2 OFF delay </p>
	RO2 OFF DELAY (10.29)	Default: 0.0 s (95.20 b3) Range: 0.0 to 3000.0 s Defines the deactivation delay for relay output RO2. See parameter 10.28 RO2 ON delay.
	RO3 SOURCE (10.30)	Default: Fault (-1) (15) Range: 0 - 44, Other Selects a drive signal to be connected to relay output RO3. For the available selections, see parameter 10.24 RO1 source.

Table 12-4 Level 1 Parameter Block Definitions


Block Title	Parameter (Number) Selection (Value)	Descriptions																				
STANDARD DI, RO (Continued)	RO2 ON DELAY (10.028)	Default: 0.0 s (95.20 b3) Range: 0.0 to 3000.0 s Defines the activation delay for relay output RO3.  <p style="font-size: small;"> t_{on} = 10.31 RO3 ON delay t_{off} = 10.32 RO3 OFF delay </p>																				
	RO3 OFF DELAY (10.32)	Default: 0.0 s Range: 0.0 to 3000.0 s Defines the deactivation delay for relay output RO3. See parameter 10.31 RO3 ON delay.																				
	DI FILTER TIME (10.51)	Default: 10.0 ms Range: 0.3 - 100.0 ms Defines a filtering time for parameter 10.01 DI status.																				
	RO/DIO CONTROL WORD (10.99)	Default: 0000h Range: 0000h - FFFFh Storage parameter for controlling the relay outputs and digital input/outputs eg. through the embedded fieldbus interface. To control the relay outputs (RO) and the digital input/outputs (DIO) of the drive, send a control word with the bit assignments shown below as Modbus I/O data. Set the target selection parameter of that particular data (58.101 - 58.124) to RO/DIO control word. In the source selection parameter of the desired output, select the appropriate bit of this word. <table border="1" data-bbox="771 1213 1555 1528" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>RO1</td> <td rowspan="3">Source bits for relay outputs RO1 - RO3 (see parameters 10.24, 10.27 and 10.30).</td> </tr> <tr> <td>1</td> <td>RO2</td> </tr> <tr> <td>2</td> <td>RO3</td> </tr> <tr> <td>3-7</td> <td>Reserved</td> <td></td> </tr> <tr> <td>8</td> <td>DIO1</td> <td rowspan="2">Source bits for digital input/outputs DIO1 - DIO3 (see parameters 11.06 and 11.10).</td> </tr> <tr> <td>9</td> <td>DIO2</td> </tr> <tr> <td>10-15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>	Bit	Name	Description	0	RO1	Source bits for relay outputs RO1 - RO3 (see parameters 10.24, 10.27 and 10.30).	1	RO2	2	RO3	3-7	Reserved		8	DIO1	Source bits for digital input/outputs DIO1 - DIO3 (see parameters 11.06 and 11.10).	9	DIO2	10-15	Reserved
Bit	Name	Description																				
0	RO1	Source bits for relay outputs RO1 - RO3 (see parameters 10.24, 10.27 and 10.30).																				
1	RO2																					
2	RO3																					
3-7	Reserved																					
8	DIO1	Source bits for digital input/outputs DIO1 - DIO3 (see parameters 11.06 and 11.10).																				
9	DIO2																					
10-15	Reserved																					
STANDARD DIO, FI, FO	Configuration of digital input/outputs and frequency inputs/outputs.																					
	DIO STATUS (11.01)	Default: Read Only Range: 0000b - 0011b Displays the status of digital input/outputs DIO2 and DIO1. The activation/deactivation delays (if any are specified) are ignored. A filtering time (for input mode) can be defined by parameter 10.51 DI filter time. Example: 0010 = DIO2 is on, DIO1 is off. This parameter is read-only.																				

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
STANDARD DIO, FI, FO (Continued)	DIO DELAYED STATUS (11.02)	Default: Read Only Range: 0000b - 0011b
		Displays the delayed status of digital input/outputs DIO2 and DIO1. This word is updated only after activation/deactivation delays (if any are specified). Example: 0010 = DIO2 is on, DIO1 is off. This parameter is read-only.
	DIO1 FUNCTION (11.05)	Default: Output (0) Range: 0 - 2
	Output (0)	DIO1 is used as a digital output
	Input (1)	DIO1 is used as a digital input
	Frequency (2)	DIO1 is used as a frequency input
		Selects whether DIO1 is used as a digital output or input, or a frequency input.
	DIO1 OUTPUT SOURCE (11.06)	Default: Ready run (2) Range: 0 - 44, Other
	Not energized (0)	Output is off
	Energized (1)	Output is on
	Ready run (2)	Bit 1 of 06.11 Main status word
	Enabled (4)	Bit 0 of 06.16 Drive status word 1
	Started (5)	Bit 5 of 06.16 Drive status word 1
	Magnetized (6)	Bit 1 of 06.17 Drive status word 2
	Running (7)	Bit 6 of 06.16 Drive status word 1
	Ready ref (8)	Bit 2 of 06.11 Main status word
	At setpoint (9)	Bit 8 of 06.11 Main status word
	Reverse (10)	Bit 2 of 06.19 Speed control status word
	Zero speed (11)	Bit 0 of 06.19 Speed control status word
	Above limit (12)	Bit 10 of 06.17 Drive status word 2
	Warning (13)	Bit 7 of 06.11 Main status word
	Fault (14)	Bit 3 of 06.11 Main status word
	Fault (-1) (15)	Inverted bit 3 of 06.11 Main status word
	Open brake command (22)	Bit 0 of 44.01 Brake control status
	Ext2 active (23)	Bit 11 of 06.16 Drive status word 1
	Remote control (24)	Bit 9 of 06.11 Main status word
	Supervision 1 (33)	Bit 0 of 32.01 Supervision status
	Supervision 2 (34)	Bit 1 of 32.01 Supervision status
	Supervision 3 (35)	Bit 2 of 32.01 Supervision status
	RO/DIO control word bit 0 (40)	Bit 0 of 10.99 RO/DIO control word
	RO/DIO control word bit 1 (41)	Bit 1 of 10.99 RO/DIO control word
	RO/DIO control word bit 2 (42)	Bit 2 of 10.99 RO/DIO control word
RO/DIO control word bit 8 (43)	Bit 8 of 10.99 RO/DIO control word	
RO/DIO control word bit 9 (44)	Bit 9 of 10.99 RO/DIO control word	
Other [bit]	Source selection (see Terms and abbreviations)	
		Selects a drive signal to be connected to digital input/output DIO1 when parameter 11.05 DIO1 function is set to Output.

Table 12-4 Level 1 Parameter Block Definitions



Block Title	Parameter (Number) Selection (Value)	Descriptions	
STANDARD DIO, FI, FO (Continued)	DIO1 ON DELAY (11.07)	Default: 0.0 s Range: 0.0 to 3000.0 s Defines the activation delay for digital input/output DIO1 (when used as a digital output or digital input).  t_{on} = 11.07 DIO1 ON delay t_{off} = 11.08 DIO1 OFF delay	
	DIO1 OFF DELAY (11.08)	Default: 0.0 s Range: 0.0 to 3000.0 s Defines the deactivation delay for digital input/output DIO1 (when used as a digital output or digital input). See parameter 11.07 DIO1 ON delay.	
	DIO2 FUNCTION (11.09)	Default: Output (0) Range: 0 - 2	DIO2 is used as a digital output
		Input (1)	DIO2 is used as a digital input
		Frequency (2)	DIO2 is used as a frequency input
		Selects whether DIO2 is used as a digital output or input, or a frequency output.	
	DIO2 OUTPUT SOURCE (11.10)	Default: Running (7) Range: 0 - 44, Other Selects a drive signal to be connected to digital input/output DIO2 when parameter 11.09 DIO2 function is set to Output. For the available selections, see parameter 11.06 DIO1 output source.	
	DIO2 ON DELAY (11.11)	Default: 0.0 s Range: 0.0 to 3000.0 s Defines the activation delay for digital input/output DIO2 (when used as a digital output or digital input).	
 t_{on} = 11.11 DIO2 ON delay t_{off} = 11.12 DIO2 OFF delay			
DIO2 OFF DELAY (11.12)	Default: 0.0 s Range: 0.0 to 3000.0 s Defines the deactivation delay for digital input/output DIO2 (when used as a digital output or digital input). See parameter 11.11 DIO2 ON delay.		

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
STANDARD DIO, FI, FO (Continued)	DIO FILTER TIME (11.81)	Default: 10.0 ms Range: 0.3 - 100.0 ms
		Defines a filtering time for parameter 11.01 DIO status. The filtering time will only affect the DIOs that are in input mode.
STANDARD AI	Configuration of standard analog inputs.	
	AI TUNE (12.01)	Default: No action (0) Range: 0 - 4
	No action (0)	AI tune is not activated.
	AI1 min tune (1)	Current analog input AI1 signal value is set as minimum value of AI1 into parameter 12.17 AI1 min. The value reverts back to No action automatically.
	AI1 max tune (2)	Current analog input AI1 signal value is set as maximum value of AI1 into parameter 12.18 AI1 max. The value reverts back to No action automatically.
	AI2 min tune (3)	Current analog input AI2 signal value is set as minimum value of AI2 into parameter 12.27 AI2 min. The value reverts back to No action automatically.
	AI2 max tune (4)	Current analog input AI2 signal value is set as maximum value of AI2 into parameter 12.28 AI2 max. The value reverts back to No action automatically.
		Triggers the analog input tuning function. Connect the signal to the input and select the appropriate tuning function.
	AI SUPERVISION FUNCTION (12.03)	Default: No action (0) Range: 0 - 4
	No action (0)	No action taken.
	Fault (1)	Drive trips on 80A0 AI supervision.
	Warning (2)	Drive generates an A8A0 AI supervision warning.
	Last speed (3)	Drive generates a warning (A8A0 AI supervision) and freezes the speed (or frequency) to the level the drive was operating at. The speed/frequency is determined on the basis of actual speed using 850 ms lowpass filtering. WARNING! Make sure that it is safe to continue operation in case of a communication break.
	Speed ref safe (4)	Drive generates a warning (A8A0 AI supervision) and sets the speed to the speed defined by parameter 22.41 Speed ref safe (or 28.41 Frequency ref safe when frequency reference is being used). WARNING! Make sure that it is safe to continue operation in case of a communication break.
		Selects how the drive reacts when an analog input signal moves out of the minimum and/or maximum limits specified for the input. The supervision applies a margin of 0.5 V or 1.0 mA to the limits. For example, if the maximum limit for the input is 7.000 V, the maximum limit supervision activates at 7.500 V. The inputs and the limits to be observed are selected by parameter 12.04 AI supervision selection. Note: Analog input signal supervision is only active when <ul style="list-style-type: none"> • the analog input is set as the source (using the AI1 scaled or AI2 scaled selection) in parameter 22.11, 22.12, 22.15, 22.17, 23.42, 26.11, 26.12, 26.16, 26.25, 28.11, 28.12, 30.21, 30.22, 40.16, 40.17, 40.50, 41.16, 41.17, 41.50 or 44.09, and • is being used as the active source.

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions																		
STANDARD AI (Continued)	AI SUPERVISION SELECTION (12.04)	Default: 0000b Range: 0000b - 1111b Specifies the analog input limits to be supervised. See parameter 12.03 AI supervision function.																		
		<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>AI1 < MIN</td> <td>1 = Minimum limit supervision of AI1 active</td> </tr> <tr> <td>1</td> <td>AI1 > MAX</td> <td>1 = Maximum limit supervision of AI1 active</td> </tr> <tr> <td>2</td> <td>AI2 < MIN</td> <td>1 = Minimum limit supervision of AI2 active</td> </tr> <tr> <td>3</td> <td>AI2 > MAX</td> <td>1 = Maximum limit supervision of AI2 active</td> </tr> <tr> <td>4-15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>	Bit	Name	Description	0	AI1 < MIN	1 = Minimum limit supervision of AI1 active	1	AI1 > MAX	1 = Maximum limit supervision of AI1 active	2	AI2 < MIN	1 = Minimum limit supervision of AI2 active	3	AI2 > MAX	1 = Maximum limit supervision of AI2 active	4-15	Reserved	
	Bit	Name	Description																	
	0	AI1 < MIN	1 = Minimum limit supervision of AI1 active																	
1	AI1 > MAX	1 = Maximum limit supervision of AI1 active																		
2	AI2 < MIN	1 = Minimum limit supervision of AI2 active																		
3	AI2 > MAX	1 = Maximum limit supervision of AI2 active																		
4-15	Reserved																			
AI1 ACTUAL VALUE (12.11)	Default: Read Only Range: -22.000 to +22.000mA or V Displays the value of analog input AI1 in mA or V (depending on whether the input is set to current or voltage by a hardware setting). This parameter is read-only.																			
AI1 UNIT SELECTION (12.15)	Default: V Range: V or mA V Volts mA Milliamperes Selects the unit for readings and settings related to analog input AI1. Note: This setting must match the corresponding hardware setting on the drive control unit (see the hardware manual of the drive). Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings.																			
AI1 FILTER TIME (12.16)	Default: 0.100 s Range: 0.000 - 30.000 s Defines the filter time constant for analog input AI1.																			
	<p style="text-align: center;"> $O = I \times (1 - e^{-t/T})$ </p> <p> I = filter input (step) O = filter output t = time T = filter time constant </p> <p>Note: The signal is also filtered due to the signal interface hardware (approximately 0.25 ms time constant). This cannot be changed by any parameter.</p>																			

Table 12-4 Level 1 Parameter Block Definitions


Block Title	Parameter (Number) Selection (Value)	Descriptions
STANDARD AI (Continued)	AI1 MIN (12.17)	Default: 0.000mA or V Range: -22.000 to +22.000mA or V Defines the minimum site value for analog input AI1. Set the value actually sent to the drive when the analog signal from plant is wound to its minimum setting. See also parameter 12.01 AI tune.
	AI1 MAX (12.18)	Default: 20.000mA or 10.000V Range: -22.000 to +22.000mA or V Defines the maximum site value for analog input AI1. Set the value actually sent to the drive when the analog signal from plant is wound to its maximum setting. See also parameter 12.01 AI tune.
	AI1 SCALED AT AI1 MIN (12.19)	Default: 0.000 Range: -32768.000 to +32767.000 Defines the real internal value that corresponds to the minimum analog input AI1 value defined by parameter 12.17 AI1 min. (Changing the polarity settings of 12.19 and 12.20 can effectively invert the analog input.) 
	AI1 SCALED AT AI1 MAX (12.20)	Default: 1500.000; 1800.000 (95.20 b0) Range: -32768.000 to +32767.000 Defines the real internal value that corresponds to the maximum analog input AI1 value defined by parameter 12.18 AI1 max. See the drawing at parameter 12.19 AI1 scaled at AI1 min.
	AI SUPERVISION SELECTION (12.21)	Default: Read Only Range: -22.000 to +22.000mA or V Displays the value of analog input AI2 in mA or V (depending on whether the input is set to current or voltage by a hardware setting). This parameter is read-only.
	AI2 SCALED VALUE (12.22)	Default: Read Only Range: -32768.000 to +32767.000 Displays the value of analog input AI2 after scaling. See parameters 12.29 AI2 scaled at AI2 min and 12.30 AI2 scaled at AI2 max. This parameter is read-only.

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
STANDARD AI (Continued)	AI2 UNIT SELECTION (12.25)	Default: mA Range: V or mA
		V
		mA
		Selects the unit for readings and settings related to analog input AI2. Note: This setting must match the corresponding hardware setting on the drive control unit (see the hardware manual of the drive). Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings.
	AI2 FILTER TIME (12.26)	Default: 0.100 s Range: 0.000 - 30.000 s
		Defines the filter time constant for analog input AI2. See parameter 12.16 AI1 filter time.
	AI2 MIN (12.27)	Default: 0.000mA or V Range: -22.000 to +22.000mA or V
		Defines the minimum site value for analog input AI2. Set the value actually sent to the drive when the analog signal from plant is wound to its minimum setting. See also parameter 12.01 AI tune.
	AI2 MAX (12.28)	Default: 20.000mA or 10.000V Range: -22.000 to +22.000mA or V
		Defines the maximum site value for analog input AI2. Set the value actually sent to the drive when the analog signal from plant is wound to its maximum setting. See also parameter 12.01 AI tune.
AI2 SCALED AT AI2 MIN (12.29)	Default: 0.000 Range: -32768.000 to +32767.000	
	Defines the real value that corresponds to the minimum analog input AI2 value defined by parameter 12.27 AI2 min. (Changing the polarity settings of 12.29 and 12.30 can effectively invert the analog input.)	




Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
STANDARD AI (Continued)	AI2 SCALED AT AI2 MAX (12.30)	Default: 100.000 Range: -32768.000 to +32767.000 Defines the real value that corresponds to the maximum analog input AI2 value defined by parameter 12.28 AI2 max. See the drawing at parameter 12.29 AI2 scaled at AI2 min.
	Configuration of standard analog outputs.	
	AO1 ACTUAL VALUE (13.11)	Default: Read Only Range: 0.000 to +22.000mA Displays the value of AO1 in mA. This parameter is read-only.
	AO1 SOURCE (13.12)	Default: 1 (Motor Speed Used) Range: 0 - 23, 37, 38, Other
	0	Zero
	1	Motor speed used
	3	Output frequency
	4	Motor current
	6	Motor torque
	7	DC voltage
	8	Power inu out
	10	Speed ref ramp in
	11	Speed ref ramp out
12	Speed ref used	
13	Torq ref used	
14	Freq ref used	
16	Process PID out	
17	Process PID fbk	
18	Process PID act	
19	Process PID dev	
20	Force PT100 excitation	
21	Force KTY84 excitation	
22	Force PTC excitation	
23	Force Pt1000 excitation	
37	AO1 data storage	
38	AO2 data storage	
-	Other	
Selects a signal to be connected to analog output AO1. Alternatively, sets the output to excitation mode to feed a constant current to a temperature sensor.		

Table 12-4 Level 1 Parameter Block Definitions




Block Title	Parameter (Number) Selection (Value)	Descriptions
STANDARD AI (Continued)	AO1 FILTER TIME (13.16)	<p>Default: 0.100 s Range: 0.000 - 30.000 s</p> <p>Defines the filtering time constant for analog output AO1.</p>  <p>$O = I \times (1 - e^{-t/T})$</p> <p>I = filter input (step) O = filter output t = time T = filter time constant</p>
	AO1 SOURCE MIN (13.17)	<p>Default: 0.0 Range: -32768.0 to +32767.0</p> <p>Defines the real minimum value of the signal (selected by parameter 13.12 AO1 source) that corresponds to the minimum required AO1 output value (defined by parameter 13.19 AO1 out at AO1 src min).</p> 
		<p>Programming 13.17 as the maximum value and 13.18 as the minimum value inverts the output.</p> 

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
STANDARD AI (Continued)	AO1 SOURCE MAX (13.18)	Default: 1500.0; 1800.0 (95.20 b0) Range: -32768.0 to +32767.0 Defines the real maximum value of the signal (selected by parameter 13.12 AO1 source) that corresponds to the maximum required AO1 output value (defined by parameter 13.20 AO1 out at AO1 src max). See parameter 13.17 AO1 source min.
	AO1 OUT AT AO1 SRC MIN (13.19)	Default: 0.000mA Range: 0.000 - 22.000mA Defines the minimum output value for analog output AO1. See also drawing at parameter 13.17 AO1 source min.
	AO1 OUT AT AO1 SRC MAX (13.20)	Default: 20.000mA Range: 0.000 - 22.000mA Defines the maximum output value for analog output AO1. See also drawing at parameter 13.17 AO1 source min.
	AO2 ACTUAL TIME (13.21)	Default: Read Only Range: 0.000 - 22.000mA Displays the value of AO2 in mA. This parameter is read-only.
	AO2 SOURCE (13.22)	Default: 4 (Motor Current) Range: 0 - 23, 37-38, Other Selects a signal to be connected to analog output AO2. Alternatively, sets the output to excitation mode to feed a constant current to a temperature sensor. For the selections, see parameter 13.12 AO1 source.
	AO2 FILTER TIME (13.26)	Default: 0.100 s Range: 0.000 - 30.000 s Defines the filtering time constant for analog output AO2. See parameter 13.16 AO1 filter time.

Table 12-4 Level 1 Parameter Block Definitions



Block Title	Parameter (Number) Selection (Value)	Descriptions
STANDARD AI (Continued)	AO2 SOURCE MIN (13.27)	Default: 0.0 Range: -32768.0 to +32767.0
		Defines the real minimum value of the signal (selected by parameter 13.22 AO2 source) that corresponds to the minimum required AO2 output value (defined by parameter 13.29 AO2 out at AO2 src min).
		
		Programming 13.27 as the maximum value and 13.28 as the minimum value inverts the output.
		
	AO2 SOURCE MAX (13.28)	Default: 100.0 Range: -32768.0 to +32767.0
		Defines the real maximum value of the signal (selected by parameter 13.22 AO2 source) that corresponds to the maximum required AO2 output value (defined by parameter 13.30 AO2 out at AO2 src max). See parameter 13.27 AO2 source min.
	AO2 OUT AT AO2 SRC MIN (13.29)	Default: 0.000mA Range: 0.000 - 22.000mA
		Defines the minimum output value for analog output AO2. See also drawing at parameter 13.27 AO2 source min.
	AO2 OUT AT AO2 SRC MAX (13.30)	Default: 20.000mA Range: 0.000 - 22.000mA
		Defines the maximum output value for analog output AO2. See also drawing at parameter 13.27 AO2 source min.

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions														
STANDARD AI (Continued)	AO1 DATA STORAGE (13.91)	Default: 0.00 Range: -327.68 to +327.67 Storage parameter for controlling analog output AO1 eg. through fieldbus. In 13.12 AO1 source, select AO1 data storage. Then set this parameter as the target of the incoming value data. With the embedded fieldbus interface, simply set the target selection parameter of that particular data (58.101 - 58.124) to AO1 data storage.														
	AO2 DATA STORAGE (13.92)	Default: 0.00 Range: -327.68 to +327.67 Storage parameter for controlling analog output AO2 eg. through fieldbus. In 13.22 AO2 source, select AO2 data storage. Then set this parameter as the target of the incoming value data. With the embedded fieldbus interface, simply set the target selection parameter of that particular data (58.101 - 58.124) to AO2 data storage.														
	Start and stop modes; emergency stop mode and signal source selection; DC magnetization settings; autophasing mode selection.															
	AUTO RESTART TIME (21.18) 0.0s 0.1 - 5.0s	Default: 5.0s Range: 0.0 - 5.0s Automatic restarting disabled Maximum power failure duration The motor can be automatically started after a short supply power failure using the automatic restart function. See section Automatic restart. When this parameter is set to 0.0 seconds, automatic restarting is disabled. Otherwise, the parameter defines the maximum duration of the power failure after which restarting is attempted. Note that this time also includes the DC precharging delay.  WARNING! Before you activate the function, make sure that no dangerous situations can occur. The function restarts the drive automatically and continues operation after a supply break.														
Speed reference selection; motor potentiometer settings. See the control chain diagrams																
SPEED REFERENCE SELECTION Only available in "Custom" mode	SPEED REF UNLIMITED (22.01)	Default: Read Only Range: -30000.00 to +30000.00 RPM Displays the output of the speed reference selection block. See the control chain diagram. This parameter is read-only.														
	CRITICAL SPEED FUNCTION (22.51)	Default: 00b Range: 0000h - FFFFh Enables/disables the critical speeds function. Also determines whether the specified ranges are effective in both rotating directions or not. See also section Critical speeds/frequencies. <table border="1" data-bbox="706 1669 1485 1921"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td rowspan="2">0</td> <td rowspan="2">Enabled</td> <td>1 = Enable: Critical speeds enabled.</td> </tr> <tr> <td>0 = Disable: Critical speeds disabled.</td> </tr> <tr> <td rowspan="2">1</td> <td rowspan="2">Sign Mode</td> <td>1 = Signed: The signs of parameters 22.52 - 22.57 are taken into account.</td> </tr> <tr> <td>0 = Absolute: Parameters 22.52 - 22.57 are handled as absolute values. Each range is effective in both directions of rotation.</td> </tr> <tr> <td>2 - 15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>	Bit	Name	Information	0	Enabled	1 = Enable: Critical speeds enabled.	0 = Disable: Critical speeds disabled.	1	Sign Mode	1 = Signed: The signs of parameters 22.52 - 22.57 are taken into account.	0 = Absolute: Parameters 22.52 - 22.57 are handled as absolute values. Each range is effective in both directions of rotation.	2 - 15	Reserved	
	Bit	Name	Information													
0	Enabled	1 = Enable: Critical speeds enabled.														
		0 = Disable: Critical speeds disabled.														
1	Sign Mode	1 = Signed: The signs of parameters 22.52 - 22.57 are taken into account.														
		0 = Absolute: Parameters 22.52 - 22.57 are handled as absolute values. Each range is effective in both directions of rotation.														
2 - 15	Reserved															

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
SPEED REFERENCE SELECTION Only available in "Custom" mode (Continued)	CRITICAL SPEED 1 LOW (22.52)	Default: 0.00 RPM Range: -30000.00 to +30000.00 RPM
		Defines the low limit for critical speed range 1. Note: This value must be less than or equal to the value of 22.53 Critical speed 1 high.
	CRITICAL SPEED 1 HIGH (22.53)	Default: 0.00 RPM Range: -30000.00 to +30000.00 RPM
		Defines the high limit for critical speed range 1. Note: This value must be greater than or equal to the value of 22.52 Critical speed 1 low.
	CRITICAL SPEED 2 LOW (22.54)	Default: 0.00 RPM Range: -30000.00 to +30000.00 RPM
		Defines the low limit for critical speed range 2. Note: This value must be less than or equal to the value of 22.55 Critical speed 2 high.
	CRITICAL SPEED 2 HIGH (22.55)	Default: 0.00 RPM Range: -30000.00 to +30000.00 RPM
		Defines the high limit for critical speed range 2. Note: This value must be greater than or equal to the value of 22.54 Critical speed 2 low.
	CRITICAL SPEED 3 LOW (22.56)	Default: 0.00 RPM Range: -30000.00 to +30000.00 RPM
		Defines the low limit for critical speed range 3. Note: This value must be less than or equal to the value of 22.57 Critical speed 3 high.
	CRITICAL SPEED 3 HIGH (22.57)	Default: 0.00 RPM Range: -30000.00 to +30000.00 RPM
		Defines the high limit for critical speed range 3. Note: This value must be greater than or equal to the value of 22.56 Critical speed 3 low.
	SPEED REFERENCE ACT 1 (22.81)	Default: Read Only Range: -30000.00 to +30000.00 RPM
		Displays the value of speed reference source 2 (selected by parameter 22.12 Speed ref2 source). See the control chain diagram on page 546. This parameter is read-only.
SPEED REFERENCE ACT 2 (22.82)	Default: Read Only Range: -30000.00 to +30000.00 RPM	
	Displays the value of speed reference source 2 (selected by parameter 22.12 Speed ref2 source). See the control chain diagram on page 546. This parameter is read-only.	
SPEED REFERENCE ACT 3 (22.83)	Default: Read Only Range: -30000.00 to +30000.00 RPM	
	Displays the value of speed reference after the mathematical function applied by parameter 22.13 Speed ref1 function and reference 1/2 selection (22.14 Speed ref1/2 selection). See the control chain diagram. This parameter is read-only.	

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
<p>SPEED REFERENCE SELECTION Only available in "Custom" mode (Continued)</p>	<p>SPEED REFERENCE ACT 4 (22.84)</p>	<p>Default: Read Only Range: -30000.00 to +30000.00 RPM</p> <p>Displays the value of speed reference after application of 1st speed additive (22.15 Speed additive 1 source). See the control chain diagram. This parameter is read-only.</p>
	<p>SPEED REFERENCE ACT 5 (22.85)</p>	<p>Default: Read Only Range: -30000.00 to +30000.00 RPM</p> <p>Displays the value of speed reference after the application of the speed share scaling factor (22.16 Speed share). See the control chain diagram. This parameter is read-only.</p>
	<p>SPEED REFERENCE ACT 6 (22.86)</p>	<p>Default: Read Only Range: -30000.00 to +30000.00 RPM</p> <p>Displays the value of speed reference after application of 2nd speed additive (22.17 Speed additive 2 source). See the control chain diagram. This parameter is read-only.</p>
	<p>SPEED REFERENCE ACT 7 (22.87)</p>	<p>Default: Read Only Range: -30000.00 to +30000.00 RPM</p> <p>Displays the value of speed reference before application of critical speeds. See the control chain diagram. The value is received from 22.86 Speed reference act 6 unless overridden by</p> <ul style="list-style-type: none"> • any constant speed • a jogging reference • network control reference • control panel reference • safe speed reference. <p>This parameter is read-only.</p>
<p>SPEED REFERENCE RAMP</p>	<p>Speed reference ramp settings (programming of the acceleration and deceleration rates for the drive). See the control chain diagram.</p>	
	<p>SPEED REF RAMP INPUT (23.01)</p>	<p>Default: Read Only Range: -30000.00 to +30000.00 RPM</p> <p>Displays the used speed reference (in rpm) before it enters the ramping and shaping functions. See the control chain diagram. This parameter is read-only.</p>
	<p>SPEED REF RAMP OUTPUT (23.02)</p>	<p>Default: Read Only Range: -30000.00 to +30000.00 RPM</p> <p>Displays the ramped and shaped speed reference in rpm. See the control chain diagram. This parameter is read-only.</p>

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
SPEED REFERENCE RAMP (Continued)	RAMP SET SELECTION (23.11)	Default: 5 (DI4) Range: 0 - 18
	0 (Acc/Dec time 1)	0
	1 (Acc/Dec time 2)	1
	2 (DI1)	Digital input DI1 (10.02 DI delayed status, bit 0).
	3 (DI2)	Digital input DI2 (10.02 DI delayed status, bit 1).
	4 (DI3)	Digital input DI3 (10.02 DI delayed status, bit 2).
	5 (DI4)	Digital input DI4 (10.02 DI delayed status, bit 3).
	6 (DI5)	Digital input DI5 (10.02 DI delayed status, bit 4).
	7 (DI6)	Digital input DI6 (10.02 DI delayed status, bit 5).
	10 (DIO1)	Digital input/output DIO1 (11.02 DIO delayed status, bit 0).
	11 (DIO2)	Digital input/output DIO2 (11.02 DIO delayed status, bit 1).
	18 (FBA A)	Bit 11 (selection of external control location) of the control word received from fieldbus interface A.
	Other	Source selection Selects the source that switches between the two sets of acceleration/ deceleration ramp times defined by parameters 23.12...23.15.0 = Acceleration time 1 and deceleration time 1 are active 1 = Acceleration time 2 and deceleration time 2 are active
	ACCELERATION TIME 1 (23.12)	Default: s = Motor Nom Spd/10 Range: 5.000 - 1800.000 s Defines acceleration time 1 as the time required for the speed to change from zero to the speed defined by parameter 46.01 Speed scaling (this value is set automatically to 99.09 motor nominal speed). If the speed reference increases faster than the set acceleration rate, the motor speed will follow the acceleration rate. If the speed reference increases slower than the set acceleration rate, the motor speed will follow the reference. If the acceleration time is set too short, the drive will automatically prolong the acceleration in order not to exceed the drive torque limits.
DECELERATION TIME 1 (23.13)	Default: 60s Range: 0.000 - 1800.000 s Defines deceleration time 1 as the time required for the speed to change from the speed defined by parameter 46.01 Speed scaling (set automatically to the value entered in 99.09 motor nominal speed) to zero. If the speed reference decreases slower than the set deceleration rate, the motor speed will follow the reference. If the reference changes faster than the set deceleration rate, the motor speed will follow the deceleration rate. If the deceleration rate is set too short, the drive will automatically prolong the deceleration in order not to exceed drive torque limits (or not to exceed a safe DC link voltage). If there is any doubt about the deceleration time being too short, ensure that DC overvoltage control is on (parameter 30.30 Overvoltage control). Note: If a short deceleration time is needed for a high inertia application, the drive should be equipped with braking equipment such as a brake chopper and brake resistor.	

Table 12-4 Level 1 Parameter Block Definitions


Block Title	Parameter (Number) Selection (Value)	Descriptions
SPEED REFERENCE RAMP (Continued)	ACCELERATION TIME 2 (23.14)	Default: s = Motor Nom Spd/10 Range: 0.000 - 1800.000s Defines acceleration time 2. See parameter 23.12 Acceleration time 1.
	DECELERATION TIME 2 (23.15)	Default: 60s Range: 0.000 - 1800.000s Defines deceleration time 2. See parameter 23.13 Deceleration time 1.
	Speed error calculation; speed error window control configuration; speed error step. See the control chain diagrams.	
	USED SPEED REFERENCE (24.01)	Default: Read Only Range: -30000.00 to +30000.00 RPM Displays the ramped and corrected speed reference (before speed error calculation). See the control chain diagram. This parameter is read-only.
	USED SPEED FEEDBACK (24.02)	Default: Read Only Range: -30000.00 to +30000.00 RPM Displays the speed feedback used for speed error calculation. See the control chain diagram. This parameter is read-only.
	SPEED CONTROL	Speed controller settings. See the control chain diagrams.
USED SPEED FEEDBACK (25.01)		Default: Read Only Range: -1600.0 to +1600.0% Displays the speed controller output that is transferred to the torque controller. See the control chain diagram. This parameter is read-only.
SPEED PROPORTIONAL GAIN (25.02)		Default: 0.50 Range: 0.00 - 250.00 Defines the proportional gain (K_p) of the speed controller. Too high a gain may cause speed oscillation. The figure below shows the speed controller output after an error step when the error remains constant.  If gain is set to 1, a 10% change in error value (reference - actual value) causes the speed controller output to change by 10%, ie. the output value is input \times gain.

Table 12-4 Level 1 Parameter Block Definitions


Block Title	Parameter (Number) Selection (Value)	Descriptions
SPEED CONTROL (Continued)	SPEED INTEGRATION TIME (25.03)	<p>Default: 4.00s Range: 0.00 to 1000.00s</p> <p>Defines the integration time of the speed controller. The integration time defines the rate at which the controller output changes when the error value is constant and the proportional gain of the speed controller is 1. The shorter the integration time, the faster the continuous error value is corrected. This time constant must be set to the same order of magnitude as the time constant (time to respond) of the actual mechanical system being controlled, otherwise instability will result. Setting the integration time to zero disables the I-part of the controller. This is useful to do when tuning the proportional gain; adjust the proportional gain first, then return the integration time. Anti-windup (the integrator just integrates up to 100%) stops the integrator if the controller output is limited. The figure below shows the speed controller output after an error step when the error remains constant.</p> 
	SPEED DERIVATION TIME (25.04)	<p>Default: 0.000s Range: 0.000 to 1000.00s</p> <p>Defines the derivation time of the speed controller. Derivative action boosts the controller output if the error value changes. The longer the derivation time, the more the speed controller output is boosted during the change. If the derivation time is set to zero, the controller works as a PI controller, otherwise as a PID controller. The derivation makes the control more responsive for disturbances. For simple applications (especially those without a pulse encoder), derivative time is not normally required and should be left at zero. The speed error derivative must be filtered with a low pass filter to eliminate disturbances. The figure below shows the speed controller output after an error step when the error remains constant.</p>

Table 12-4 Level 1 Parameter Block Definitions


Block Title	Parameter (Number) Selection (Value)	Descriptions
SPEED CONTROL (Continued)	SPEED ADAPT MIN LIMIT (25.18)	Default: 0 RPM Range: 0 - 30000 RPM
		<p>Minimum actual speed for speed controller adaptation. Speed controller gain and integration time can be adapted according to actual speed (90.01 Motor speed for control). This is done by multiplying the gain (25.02 Speed proportional gain) and integration time (25.03 Speed integration time) by coefficients at certain speeds. The coefficients are defined individually for both gain and integration time.</p> <p>When actual speed is below or equal to 25.18 Speed adapt min limit, the gain and integration time are multiplied by 25.21 Kp adapt coef at min speed and 25.22 Ti adapt coef at min speed respectively. When actual speed is equal to or above 25.19 Speed adapt max limit, no adaptation takes place (the coefficient is 1).</p> <p>When actual speed is between 25.18 Speed adapt min limit and 25.19 Speed adapt max limit, the coefficients for the gain and integration time are calculated linearly on the basis of the breakpoints.</p>  <p style="text-align: center;">Coefficient for K_p or T_i K_p = Proportional gain T_i = Integration time</p> <p style="text-align: center;">1.000</p> <p style="text-align: center;">25.21 Kp adapt coef at min speed or 25.22 Ti adapt coef at min speed</p> <p style="text-align: center;">0 25.18 Speed adapt min limit 25.19 Speed adapt max limit</p> <p style="text-align: right;">Actual speed (90.01) (rpm)</p>
	SPEED ADAPT MAX LIMIT (25.19)	Default: 0 RPM Range: 0 - 30000 RPM
		Maximum actual speed for speed controller adaptation. See parameter 25.18 Speed adapt min limit.
	KP ADAPT COEF AT MIN SPEED (25.21)	Default: 1.000 Range: 0.000 to 10.000
	Proportional gain coefficient at minimum actual speed. See parameter 25.18 Speed adapt min limit.	
TI ADAPT COEF AT MIN SPEED (25.22)	Default: 1.000 Range: 0.000 to 10.000	
	Integration time coefficient at minimum actual speed. See parameter 25.18 Speed adapt min limit.	

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions																																												
LIMITS	Drive operation limits																																													
	LIMIT WORD 1 (30.01)	Default: Read Only Range: 0000h - FFFFh																																												
		<p>Displays limit word 1. This parameter is read-only.</p> <table border="1" data-bbox="769 453 1544 1394"> <thead> <tr> <th data-bbox="769 453 850 485">Bit</th> <th data-bbox="850 453 1040 485">Name</th> <th data-bbox="1040 453 1544 485">Information</th> </tr> </thead> <tbody> <tr> <td data-bbox="769 485 850 579">0</td> <td data-bbox="850 485 1040 579">Torq lim</td> <td data-bbox="1040 485 1544 579">1 = Drive torque is being limited by the motor control (undervoltage control, current control, load angle control or pull-out control), or by the torque limits defined by parameters.</td> </tr> <tr> <td data-bbox="769 579 850 632">1</td> <td data-bbox="850 579 1040 632">Spd ctl tlim min</td> <td data-bbox="1040 579 1544 632">1 = Speed controller output is being limited by 25.11 Speed control min torque</td> </tr> <tr> <td data-bbox="769 632 850 684">2</td> <td data-bbox="850 632 1040 684">Spd ctl tlim max</td> <td data-bbox="1040 632 1544 684">1 = Speed controller output is being limited by 25.12 Speed control max torque</td> </tr> <tr> <td data-bbox="769 684 850 779">3</td> <td data-bbox="850 684 1040 779">Torq ref max</td> <td data-bbox="1040 684 1544 779">1 = Torque reference ramp input is being limited by 26.09 Maximum torque ref, source of 30.25 Maximum torque sel, 30.26 Power motoring limit or 30.27 Power generating limit.</td> </tr> <tr> <td data-bbox="769 779 850 873">4</td> <td data-bbox="850 779 1040 873">Torq ref min</td> <td data-bbox="1040 779 1544 873">1 = Torque reference ramp input is being limited by 26.08 Minimum torque ref, source of 30.18 Minimum torque sel, 30.26 Power motoring limit or 30.27 Power generating limit.</td> </tr> <tr> <td data-bbox="769 873 850 947">5</td> <td data-bbox="850 873 1040 947">Tlim max speed</td> <td data-bbox="1040 873 1544 947">1 = Torque reference is being limited by the rush control because of maximum speed limit (30.12 Maximum speed)</td> </tr> <tr> <td data-bbox="769 947 850 1020">6</td> <td data-bbox="850 947 1040 1020">Tlim min speed</td> <td data-bbox="1040 947 1544 1020">1 = Torque reference is being limited by the rush control because of minimum speed limit (30.11 Minimum speed)</td> </tr> <tr> <td data-bbox="769 1020 850 1073">7</td> <td data-bbox="850 1020 1040 1073">Max speed ref lim</td> <td data-bbox="1040 1020 1544 1073">1 = Speed reference is being limited by 30.12 Maximum speed</td> </tr> <tr> <td data-bbox="769 1073 850 1125">8</td> <td data-bbox="850 1073 1040 1125">Min speed ref lim</td> <td data-bbox="1040 1073 1544 1125">1 = Speed reference is being limited by 30.11 Minimum spe</td> </tr> <tr> <td data-bbox="769 1125 850 1178">9</td> <td data-bbox="850 1125 1040 1178">Max freq ref lim</td> <td data-bbox="1040 1125 1544 1178">1 = Frequency reference is being limited by 30.14 Maximum frequency</td> </tr> <tr> <td data-bbox="769 1178 850 1230">10</td> <td data-bbox="850 1178 1040 1230">Min freq ref lim</td> <td data-bbox="1040 1178 1544 1230">1 = Frequency reference is being limited by 30.13 Minimum frequency</td> </tr> <tr> <td data-bbox="769 1230 850 1262">11</td> <td data-bbox="850 1230 1040 1262">Reserved</td> <td data-bbox="1040 1230 1544 1262"></td> </tr> <tr> <td data-bbox="769 1262 850 1356">12</td> <td data-bbox="850 1262 1040 1356">Sw freq ref lim</td> <td data-bbox="1040 1262 1544 1356">1 = Requested output frequency cannot be reached because of switching frequency limitation (because of eg. output filtering or ATEXrelated protections)</td> </tr> <tr> <td data-bbox="769 1356 850 1394">13-15</td> <td data-bbox="850 1356 1040 1394">Reserved</td> <td data-bbox="1040 1356 1544 1394"></td> </tr> </tbody> </table>	Bit	Name	Information	0	Torq lim	1 = Drive torque is being limited by the motor control (undervoltage control, current control, load angle control or pull-out control), or by the torque limits defined by parameters.	1	Spd ctl tlim min	1 = Speed controller output is being limited by 25.11 Speed control min torque	2	Spd ctl tlim max	1 = Speed controller output is being limited by 25.12 Speed control max torque	3	Torq ref max	1 = Torque reference ramp input is being limited by 26.09 Maximum torque ref, source of 30.25 Maximum torque sel, 30.26 Power motoring limit or 30.27 Power generating limit.	4	Torq ref min	1 = Torque reference ramp input is being limited by 26.08 Minimum torque ref, source of 30.18 Minimum torque sel, 30.26 Power motoring limit or 30.27 Power generating limit.	5	Tlim max speed	1 = Torque reference is being limited by the rush control because of maximum speed limit (30.12 Maximum speed)	6	Tlim min speed	1 = Torque reference is being limited by the rush control because of minimum speed limit (30.11 Minimum speed)	7	Max speed ref lim	1 = Speed reference is being limited by 30.12 Maximum speed	8	Min speed ref lim	1 = Speed reference is being limited by 30.11 Minimum spe	9	Max freq ref lim	1 = Frequency reference is being limited by 30.14 Maximum frequency	10	Min freq ref lim	1 = Frequency reference is being limited by 30.13 Minimum frequency	11	Reserved		12	Sw freq ref lim	1 = Requested output frequency cannot be reached because of switching frequency limitation (because of eg. output filtering or ATEXrelated protections)	13-15	Reserved
Bit	Name	Information																																												
0	Torq lim	1 = Drive torque is being limited by the motor control (undervoltage control, current control, load angle control or pull-out control), or by the torque limits defined by parameters.																																												
1	Spd ctl tlim min	1 = Speed controller output is being limited by 25.11 Speed control min torque																																												
2	Spd ctl tlim max	1 = Speed controller output is being limited by 25.12 Speed control max torque																																												
3	Torq ref max	1 = Torque reference ramp input is being limited by 26.09 Maximum torque ref, source of 30.25 Maximum torque sel, 30.26 Power motoring limit or 30.27 Power generating limit.																																												
4	Torq ref min	1 = Torque reference ramp input is being limited by 26.08 Minimum torque ref, source of 30.18 Minimum torque sel, 30.26 Power motoring limit or 30.27 Power generating limit.																																												
5	Tlim max speed	1 = Torque reference is being limited by the rush control because of maximum speed limit (30.12 Maximum speed)																																												
6	Tlim min speed	1 = Torque reference is being limited by the rush control because of minimum speed limit (30.11 Minimum speed)																																												
7	Max speed ref lim	1 = Speed reference is being limited by 30.12 Maximum speed																																												
8	Min speed ref lim	1 = Speed reference is being limited by 30.11 Minimum spe																																												
9	Max freq ref lim	1 = Frequency reference is being limited by 30.14 Maximum frequency																																												
10	Min freq ref lim	1 = Frequency reference is being limited by 30.13 Minimum frequency																																												
11	Reserved																																													
12	Sw freq ref lim	1 = Requested output frequency cannot be reached because of switching frequency limitation (because of eg. output filtering or ATEXrelated protections)																																												
13-15	Reserved																																													

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions																																																
LIMITS (Continued)	TORQUE LIMIT STATUS (30.02)	Default: Read Only Range: 0000h - FFFFh Displays the torque controller limitation status word. This parameter is read-only. <table border="1" data-bbox="703 436 1479 1396"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Undervoltage</td> <td>*1 = Intermediate DC circuit undervoltage</td> </tr> <tr> <td>1</td> <td>Overvoltage</td> <td>*1 = Intermediate DC circuit overvoltage</td> </tr> <tr> <td>2</td> <td>Minimum torque</td> <td>*1 = Torque is being limited by 30.26 Power motoring limit, 30.27 Power generating limit or the source of 30.18 Minimum torque sel.</td> </tr> <tr> <td>3</td> <td>Maximum torque</td> <td>*1 = Torque is being limited by 30.26 Power motoring limit, 30.27 Power generating limit or the source of 30.25 Maximum torque sel.</td> </tr> <tr> <td>4</td> <td>Internal current</td> <td>1 = An inverter current limit (identified by bits 8 - 11) is active</td> </tr> <tr> <td>5</td> <td>Load angle</td> <td>(With permanent magnet motors and synchronous reluctance motors only) 1 = Load angle limit is active, ie. the motor cannot produce any more torque</td> </tr> <tr> <td>6</td> <td>Motor pullout</td> <td>(With asynchronous motors only) 1 = Motor pull-out limit is active, ie. the motor cannot produce any more torque</td> </tr> <tr> <td>7</td> <td>Reserved</td> <td></td> </tr> <tr> <td>8</td> <td>Thermal</td> <td>1 = Input current is being limited by the main circuit thermal limit</td> </tr> <tr> <td>9</td> <td>Max current</td> <td>*1 = Maximum output current (I_{MAX}) is being limited</td> </tr> <tr> <td>10</td> <td>User current</td> <td>*1 = Output current is being limited by 30.17 Maximum current</td> </tr> <tr> <td>11</td> <td>Thermal IGBT</td> <td>*1 = Output current is being limited by a calculated thermal current value</td> </tr> <tr> <td>12</td> <td>IGBT overtemperature</td> <td>*1 = Output current is being limited because of estimated IGBT temperature</td> </tr> <tr> <td>13</td> <td>IGBT overload</td> <td>*1 = Output current is being limited because of IGBT junction to case temperature</td> </tr> <tr> <td>14-15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> <p>*Only one out of bits 0 - 3, and one out of bits 9 - 13 can be on simultaneously. The bit typically indicates the limit that is exceeded first.</p>	Bit	Name	Information	0	Undervoltage	*1 = Intermediate DC circuit undervoltage	1	Overvoltage	*1 = Intermediate DC circuit overvoltage	2	Minimum torque	*1 = Torque is being limited by 30.26 Power motoring limit, 30.27 Power generating limit or the source of 30.18 Minimum torque sel.	3	Maximum torque	*1 = Torque is being limited by 30.26 Power motoring limit, 30.27 Power generating limit or the source of 30.25 Maximum torque sel.	4	Internal current	1 = An inverter current limit (identified by bits 8 - 11) is active	5	Load angle	(With permanent magnet motors and synchronous reluctance motors only) 1 = Load angle limit is active, ie. the motor cannot produce any more torque	6	Motor pullout	(With asynchronous motors only) 1 = Motor pull-out limit is active, ie. the motor cannot produce any more torque	7	Reserved		8	Thermal	1 = Input current is being limited by the main circuit thermal limit	9	Max current	*1 = Maximum output current (I_{MAX}) is being limited	10	User current	*1 = Output current is being limited by 30.17 Maximum current	11	Thermal IGBT	*1 = Output current is being limited by a calculated thermal current value	12	IGBT overtemperature	*1 = Output current is being limited because of estimated IGBT temperature	13	IGBT overload	*1 = Output current is being limited because of IGBT junction to case temperature	14-15	Reserved	
	Bit	Name	Information																																															
0	Undervoltage	*1 = Intermediate DC circuit undervoltage																																																
1	Overvoltage	*1 = Intermediate DC circuit overvoltage																																																
2	Minimum torque	*1 = Torque is being limited by 30.26 Power motoring limit, 30.27 Power generating limit or the source of 30.18 Minimum torque sel.																																																
3	Maximum torque	*1 = Torque is being limited by 30.26 Power motoring limit, 30.27 Power generating limit or the source of 30.25 Maximum torque sel.																																																
4	Internal current	1 = An inverter current limit (identified by bits 8 - 11) is active																																																
5	Load angle	(With permanent magnet motors and synchronous reluctance motors only) 1 = Load angle limit is active, ie. the motor cannot produce any more torque																																																
6	Motor pullout	(With asynchronous motors only) 1 = Motor pull-out limit is active, ie. the motor cannot produce any more torque																																																
7	Reserved																																																	
8	Thermal	1 = Input current is being limited by the main circuit thermal limit																																																
9	Max current	*1 = Maximum output current (I_{MAX}) is being limited																																																
10	User current	*1 = Output current is being limited by 30.17 Maximum current																																																
11	Thermal IGBT	*1 = Output current is being limited by a calculated thermal current value																																																
12	IGBT overtemperature	*1 = Output current is being limited because of estimated IGBT temperature																																																
13	IGBT overload	*1 = Output current is being limited because of IGBT junction to case temperature																																																
14-15	Reserved																																																	
MAXIMUM SPEED (30.12)	Default: 0.00 RPM Range: -30000.00 to +30000.00 RPM Defines the maximum allowed speed. Value is adjustable from 99.09 motor nominal speed or lower. WARNING: This value must not be lower than 30.11 Minimum speed.																																																	

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
LIMITS (Continued)	MAXIMUM START CURRENT ENABLE (30.15)	Default: 0 (Disable) Range: 0, 1
	0 (Disable)	Start current limit disabled
	1 (Enable)	Start current limit enabled
		A temporary motor current limit specifically for starting can be defined by this parameter and 30.16 Maximum start current. When this parameter is set to Enable, the drive observes the start current limit defined by 30.16 Maximum start current. The limit is in force for 2 seconds after initial magnetization (of an asynchronous induction motor) or autophasing (of a permanent magnet motor), but not more often than once in every 7 seconds. Otherwise, the limit defined by 30.17 Maximum current is in force. Note: The availability of a start current higher than the general limit depends on drive hardware.
	MAXIMUM CURRENT (30.17)	Default: 120% of rated current Range: 0.00 to 30000.00 A
		Sets the maximum allowed motor current; set to 120% of 99.06 motor nominal current.
	MAXIMUM TORQUE (30.31)	Default: 1 (Enable) Range: 0, 1
	0 (Disable)	Undervoltage control disabled
	1 (Enable)	Undervoltage control enabled
		Enables the undervoltage control of the intermediate DC link. If the DC voltage drops due to input power cut off, the undervoltage controller will automatically decrease the motor torque in order to keep the voltage above the lower limit. By decreasing the motor torque, the inertia of the load will cause regeneration back to the drive, keeping the DC link charged and preventing an undervoltage trip until the motor coasts to a stop. This will act as a power-loss ride-through functionality in systems with high inertia, such as a centrifuge or a fan.
FAULT FUNCTIONS	Configuration of external events; selection of behavior of the drive upon fault situations.	
	EXTERNAL EVENT 1 SOURCE (31.01)	Default: Inactive (1) Range: 0 - 8, 11, 12, Other
	0 Active	False
	1 Inactive	True
	2 (DIIL)	DIIL input (10.02 DI delayed status, bit 15)
	3 (DI1)	Digital input DI1 (10.02 DI delayed status, bit 0)
	4 (DI2)	Digital input DI2 (10.02 DI delayed status, bit 1)
	5 (DI3)	Digital input DI3 (10.02 DI delayed status, bit 2)
	6 (DI4)	Digital input DI4 (10.02 DI delayed status, bit 3)
	7 (DI5)	Digital input DI5 (10.02 DI delayed status, bit 4)
	8 (DI6)	Digital input DI6 (10.02 DI delayed status, bit 5)
	11 (DIO1)	Digital input/output DIO1 (11.02 DIO delayed status, bit 0)
	12 (DIO2)	Digital input/output DIO2 (11.02 DIO delayed status, bit 1)
	Other [bit]	Source selection (see Terms and abbreviations)
		Defines the source of external event 1. See also parameter 31.02 External event 1 type. 0 = Trigger event 1 = Normal operation

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
FAULT FUNCTIONS (Continued)	EXTERNAL EVENT 1 TYPE (31.02) 0 (Fault) 1 (Warning) 3 (Warning/Fault)	Default: 0 (Fault) Range: 0, 1, 3 The external event generates a fault. The external event generates a warning. If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning. Selects the type of external event 1.
	FAULT RESET SELECTION (31.11) Not selected Selected 2 (DI1) 3 (DI2) 4 (DI3) 5 (DI4) 6 (DI5) 7 (DI6) 10 (DIO1) 11 (DIO2) 30 (FBA A MCW bit 7) 32 (EFB MCW bit 7) Other [bit]	Default: 4 (DI3) Range: 0 - 7, 10, 11, 30, 32, Other 0 1 Digital input DI1 (10.02 DI delayed status, bit 0) Digital input DI2 (10.02 DI delayed status, bit 1) Digital input DI3 (10.02 DI delayed status, bit 2) Digital input DI4 (10.02 DI delayed status, bit 3) Digital input DI5 (10.02 DI delayed status, bit 4) Digital input DI6 (10.02 DI delayed status, bit 5) Digital input/output DIO1 (11.02 DIO delayed status, bit 0) Digital input/output DIO2 (11.02 DIO delayed status, bit 1) Control word bit 7 received through fieldbus interface A Control word bit 7 received through the embedded fieldbus interface Source selection (see Terms and abbreviations) Selects the source of an external fault reset signal. The signal resets the drive after a fault trip if the cause of the fault no longer exists. 0 -> 1 = Reset Note: A fault reset from the fieldbus interface is always observed regardless of this parameter.
	USER SELECTABLE FAULT (31.13)	Default: 0000h Range: 0000h to FFFFh Defines the fault that can be automatically reset using parameter 31.12 Autoreset selection, bit 10. The faults are listed in chapter Fault tracing.
	NUMBER OF TRIALS (31.14)	Default: 0 Range: 0 - 5 Defines the maximum number of automatic resets that the drive is allowed to attempt within the time specified by 31.15 Total trials time. If the fault persists, subsequent reset attempts will be made at intervals defined by 31.16 Delay time. The faults to be automatically reset are defined by 31.12 Autoreset selection.

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
FAULT FUNCTIONS (Continued)	TOTAL TRIALS TIME (31.15)	Default: 30.0 s Range: 1.0 - 600.0 s
		Defines a time window for automatic fault resets. The maximum number of attempts made during any period of this length is defined by 31.14 Number of trials. Note: If the fault condition remains and cannot be reset, each reset attempt will generate an event and start a new time window. In practice, if the specified number of resets (31.14) at specified intervals (31.16) take longer than the value of 31.15, the drive will continue to attempt resetting the fault until the cause is eventually removed.
	DELAY TIME (31.16)	Default: 0.0 s Range: 0.0 - 120.0 s
		Defines the time that the drive will wait after a fault (or a previous reset attempt) before attempting an automatic reset. See parameter 31.12 Autoreset selection.
	SUPPLY PHASE LOSS (31.21)	Default: 1 (Fault) Range: 0, 1
	0 (No action) 1 (Fault)	No action taken. The drive trips on fault 3130 Input phase loss. Selects how the drive reacts when a supply phase loss is detected.
BRAKE CHOPPER	Settings for the internal brake chopper.	
	BRAKING RESISTOR TEMPERATURE (43.01)	Default: Read Only Range: 0.0 - 120.0%
		Displays the estimated temperature of the brake resistor, or how close the brake resistor is to being too hot. The value is given in percent where 100% is the temperature the resistor would reach if the maximum continuous braking power (43.09 Brake resistor Pmax cont) is applied to the resistor for 100% rated time. The thermal time constant (43.08 Brake resistor thermal tc) defines the rated time to achieve 63% temperature. 100% would be reached when 100% time has elapsed.
	BRAKE CHOPPER ENABLE (43.06)	Default: 0 (Disabled) Range: 0 - 2
	0 (Disabled)	Brake chopper control disabled.
	1 (Enabled with thermal model)	Brake chopper enabled with resistor overload protection.
	2 (Enabled without thermal model)	Brake chopper control enabled without resistor overload protection. This setting can be used, for example, if the resistor is equipped with a thermal circuit breaker that is wired to stop the drive if the resistor overheats.
		Enables brake chopper control. Note: Before enabling brake chopper control, ensure that <ul style="list-style-type: none"> • a brake resistor is connected • overvoltage control is switched off (parameter 30.30 Overvoltage control) • the supply voltage range (parameter 95.01 Supply voltage) has been selected correctly.

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
BRAKE CHOPPER (Continued)	BRAKE CHOPPER RUNTIME ENABLE (43.07) 0 (Off) 1 (On) (Other [bit])	Default: 1 (On) Range: 0, 1
		0
		1
		Source selection
		Selects the source for quick brake chopper on/off control. 0 = Brake chopper IGBT pulses are cut off 1 = Normal brake chopper IGBT modulation. This parameter can be used to program the chopper control to function only when the supply is missing from a drive with a regenerative supply unit.
	BRAKE RESISTOR THERMAL TC (43.08)	Default: 0s Range: 0 to 10000s
		Defines the thermal time constant of the brake resistor for overload protection.
	BRAKE RESISTOR P_{MAX} CONT (43.09)	Default: 0.00 kW Range: 0.00 to 10000.00 kW
		Defines the maximum continuous braking power of the resistor (in kW) which will raise the resistor temperature to the maximum allowed value. The value is used in the overload protection.
	BRAKE RESISTANCE (43.10)	Default: 0.0 ohm Range: 0.0 to 1000.0 ohm
		Defines the resistance value of the brake resistor. The value is used for brake chopper protection.
	BRAKE RESISTOR FAULT LIMIT (43.11)	Default: 105% Range: 0 to 150%
Selects the fault limit for the brake resistor temperature protection function. When the limit is exceeded, the drive trips on fault 7183 BR excess temperature. The value is given in percent of the temperature the resistor reaches when loaded with the power defined by parameter 43.09 Brake resistor P _{max} cont.		
BRAKE RESISTOR WARNING LIMIT (43.12)	Default: 95% Range: 0 to 150%	
	Selects the warning limit for the brake resistor temperature protection function. When the limit is exceeded, the drive generates a A793 BR excess temperature warning. The value is given in percent of the temperature the resistor reaches when loaded with the power defined by parameter 43.09 Brake resistor P _{max} cont.	
ENERGY EFFICIENCY	Settings for the energy saving calculators. See also section Energy saving calculators.	
	SAVED GW HOURS (45.01)	Default: Read Only Range: 0 - 65535 GWh
		Energy saved in GWh compared to direct-on-line motor connection. This parameter is incremented when 45.02 Saved MW hours rolls over. See parameter 45.21 Energy calculations reset.
	SAVED MW HOURS (45.02)	Default: Read Only Range: 0 - 999 MWh
Energy saved in MWh compared to direct-on-line motor connection. This parameter is incremented when 45.03 Saved kW hours rolls over. When this parameter rolls over, parameter 45.01 Saved GW hours is incremented.		

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
ENERGY EFFICIENCY (Continued)	SAVED kW HOURS (45.03)	Default: Read Only Range: 0.0 - 999.9 kWh Energy saved in kWh compared to direct-on-line motor connection. If the internal brake chopper of the drive is enabled, all energy fed by the motor to the drive is assumed to be converted into heat, but the calculation still records savings made by controlling the speed. If the chopper is disabled, then regenerated energy from the motor is also recorded here. When this parameter rolls over, parameter 45.02 Saved MW hours is incremented. Fieldbus Equivalent: 10 = 1 kWh
	SAVED MONEY X1000 (45.05)	Default: Read Only Range: 0 - 294967295 thousands Monetary savings in thousands compared to direct-on-line motor connection. This parameter is incremented when 45.06 Saved money rolls over. The currency is defined by parameter 45.17 Tariff currency unit.
	SAVED MONEY (45.06)	Default: Read Only Range: 0.00 - 999.99 units Monetary savings compared to direct-on-line motor connection. This value is calculated by multiplying the saved energy in kWh by the currently active energy tariff (45.14 Tariff selection). When this parameter rolls over, parameter 45.05 Saved money x1000 is incremented. The currency is defined by parameter 45.17 Tariff currency unit.
	CO2 REDUCTION IN KILOTONS (45.08)	Default: Read Only Range: 0 - 65535 metric kilotons Reduction in CO2 emissions in metric kilotons compared to direct-on-line motor connection. This value is incremented when parameter 45.09 CO2 reduction in tons rolls over.
	CO2 REDUCTION IN TONS (45.09)	Default: Read Only Range: 0.0 - 999.9 metric tons Reduction in CO2 emissions in metric tons compared to direct-on-line motor connection. This value is calculated by multiplying the saved energy in MWh by the value of parameter 45.18 CO2 conversion factor (by default, 0.5 metric tons/MWh). When this parameter rolls over, parameter 45.08 CO2 reduction in kilotons is incremented.
	ENERGY OPTIMIZER (45.11)	Default: 0 (Disable) Range: 0, 1 0 (Disable) Energy optimization disabled 1 (Enable) Energy optimization enabled Enables/disables the energy optimization function. The function optimizes the motor flux so that total energy consumption and motor noise level are reduced when the drive operates below the nominal load. The total efficiency (motor and drive) can be improved by 1 - 20% depending on load torque and speed. Note: With a permanent magnet motor or a synchronous reluctance motor, energy optimization is always enabled regardless of this parameter.

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
ENERGY EFFICIENCY (Continued)	ENERGY TARIFF 1 (45.12)	Default: 1.000 units Range: 0.000 - 4294967.295 units Defines energy tariff 1 (price of energy per kWh). Depending on the setting of parameter 45.14 Tariff selection, either this value or 45.13 Energy tariff 2 is used for reference when monetary savings are calculated. The currency is defined by parameter 45.17 Tariff currency unit. Note: Tariffs are read only at the instant of selection, and are not applied retroactively.
	ENERGY TARIFF 2 (45.13)	Default: 2.000 units Range: 0.000 - 4294967.295 units Defines energy tariff 2 (price of energy per kWh). See parameter 45.12 Energy tariff 1.
	TARIFF SELECTION (45.14)	Default: 0 (Energy tariff 1) Range: 0 - 7, 10, 11, Other Energy tariff 1 0 Energy tariff 2 1 2 (DI1) Digital input DI1 (10.02 DI delayed status, bit 0) 3 (DI2) Digital input DI2 (10.02 DI delayed status, bit 1) 4 (DI3) Digital input DI3 (10.02 DI delayed status, bit 2) 5 (DI4) Digital input DI4 (10.02 DI delayed status, bit 3) 6 (DI5) Digital input DI5 (10.02 DI delayed status, bit 4) 7 (DI6) Digital input DI6 (10.02 DI delayed status, bit 5) 10 (DIO1) Digital input/output DIO1 (11.02 DIO delayed status, bit 0) 11 (DIO2) Digital input/output DIO2 (11.02 DIO delayed status, bit 1) Other [bit] Source selection (see Terms and abbreviations) Selects (or defines a source that selects) which pre-defined energy tariff is used. 0 = 45.12 Energy tariff 1 1 = 45.13 Energy tariff 2
	TARIFF CURRENCY UNIT (45.17)	Default: 101 (EUR) Range: 100, 101, 102 100 (Local currency) Local currency 101 (EUR) Euro 102 (USD) US dollar Specifies the currency used for the savings calculations.
	CO2 CONVERSION FACTOR (45.18)	Default: 0.500 tn/MWh Range: 0.000 - 65.535 tn/MWh Defines a factor for conversion of saved energy into CO ₂ emissions (kg/kWh or tn/MWh).

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
ENERGY EFFICIENCY (Continued)	COMPARISON POWER (45.19)	Default: 0.0 kW Range: 0.0 - 100000.0 kW
		Actual power that the motor absorbs when connected direct-on-line and operating the application. The value is used for reference when energy savings are calculated. Note: The accuracy of the energy savings calculation is directly dependent on the accuracy of this value. If nothing is entered here, then the nominal motor power is used by the calculation, but that may inflate the energy savings reported as many motors do not absorb nameplate power.
	ENERGY CALCULATIONS RESET (45.21)	Default: 0 (Done) Range: 0, 1
		0 (Done) Reset not requested (normal operation), or reset complete.
		1 (Reset) Reset the savings counter parameters. The value reverts automatically to Done. Resets the savings counter parameters 45.01 - 45.09.
MONITORING/ SCALING SETTINGS	Speed supervision settings; actual signal filtering; general scaling settings.	
	SPEED SCALING (46.01)	Default: Max Speed (P 30.12) Range: 0.10 to 30000.00 RPM
		Defines the maximum speed value used to define the acceleration ramp rate and the initial speed value used to define the deceleration ramp rate (see parameter group 23 Speed reference ramp). The speed acceleration and deceleration ramp times are therefore related to this value (not to parameter 30.12 Maximum speed). Also defines the 16-bit scaling of speed-related parameters. The value of this parameter corresponds to 20000 in fieldbus, master/follower etc. communication.
	TORQUE SCALING (46.03)	Default: 100.0% Range: 0.1 to 1000.0%
		Defines the 16-bit scaling of torque parameters. The value of this parameter (in percent of nominal motor torque) corresponds to 10000 in fieldbus, master/follower etc. communication. See also parameter 46.42 Torque decimals.
	FILTER TIME MOTOR SPEED (46.11)	Default: 10 ms Range: 2 - 20000 ms
		Defines a filter time for signals 01.01 Motor speed used, 01.02 Motor speed estimated, 01.04 Encoder 1 speed filtered and 01.05 Encoder 2 speed filtered.
	FILTER TIME OUTPUT FREQUENCY (46.12)	Default: 500 ms Range: 2 - 20000 ms
Defines a filter time for signal 01.06 Output frequency.		
FILTER TIME MOTOR TORQUE (46.13)	Default: 10 ms Range: 2 - 20000 ms	
	Defines a filter time for signal 01.10 Motor torque %.	

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions	
DATA STORAGE		Data storage parameters that can be written to and read from using other parameters' source and target settings. Note that there are different storage parameters for different data types. Integer-type storage parameters cannot be used as the source of other parameters. See also section Data storage parameters.	
		DATA STORAGE 1 REAL32 (47.01)	Default: 0.000 Range: See par. 47.31
			Data storage parameter 1. Parameters 47.01 - 47.08 are real 32-bit numbers that can be used as source values of other parameters. Storage parameters 47.01 - 47.08 can be used as the target of received 16-bit data (parameter group 62 D2D and DDCS receive data) or the source of transmitted 16-bit data (parameter group 61 D2D and DDCS transmit data). The scaling and range are defined by parameters 47.31 - 47.38.
		DATA STORAGE 2 REAL32 (47.02)	Default: 0.000 Range: See par. 47.32
			Data storage parameter 2. See also parameter 47.01 Data storage 1 real32.
		DATA STORAGE 3 REAL32 (47.03)	Default: 0.000 Range: See par. 47.33
			Data storage parameter 3. See also parameter 47.01 Data storage 1 real32.
		DATA STORAGE 1 REAL32 TYPE (47.31)	Default: 0 (Unscaled) Range: 0 - 5
			Data storage parameter 3. See also parameter 47.01 Data storage 1 real32.
		0 (Unscaled)	Data storage only. Range: -2147483.264 to +2147473.264
		1 (Transparent)	Scaling: 1 = 1. Range: -32768 to +32767
		2 (General)	Scaling: 1 = 100. Range: -327.68 to +327.67
		3 (Torque)	The scaling is defined by parameter 46.03 Torque scaling. Range: -1600.0 to +1600.0
		4 (Speed)	The scaling is defined by parameter 46.01 Speed scaling. Range: -30000.00 to +30000.00
		5 (Frequency)	The scaling is defined by parameter 46.02 Frequency scaling. Range: -500.00 to +500.00
	Defines the scaling of parameter 47.01 Data storage 1 real32 to and from 16-bit integer format. This scaling is used when the data storage parameter is the target of received 16-bit data (defined in parameter group 62 D2D and DDCS receive data), or when the data storage parameter is the source of transmitted 16-bit data (defined in parameter group 61 D2D and DDCS transmit data). The setting also defines the visible range of the storage parameter.		
DATA STORAGE 2 REAL32 TYPE (47.32)	Default: 0 (Unscaled) Range: 0 - 5		
	Defines the 16-bit scaling of parameter 47.02 Data storage 2 real32. See parameter 47.31 Data storage 1 real32 type.		
DATA STORAGE 3 REAL32 TYPE (47.33)	Default: 0 (Unscaled) Range: 0 - 5		
	Defines the 16-bit scaling of parameter 47.03 Data storage 3 real32. See parameter 47.31 Data storage 1 real32 type.		

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
FIELD BUS ADAPTER	Parameters 50 - 56 are for FIELD BUS ONLY and are adapter module-specific. For more information, see the documentation of the fieldbus adapter module. Note that not all of these parameters are necessarily in use.	
EMBEDDED FIELD BUS	Configuration of the embedded fieldbus (EFB) interface. See also chapter Fieldbus control through the embedded fieldbus interface (EFB).	
	PROTOCOL ENABLE (58.01)	Default: 0 (None) Range: 0, 1
	0 (None)	None (communication disabled)
	1 (Modbus RTU)	Embedded fieldbus interface is enabled and uses the Modbus RTU protocol Enables/disables the embedded fieldbus interface and selects the protocol to use. Note: When the embedded fieldbus interface is enabled, the drive-to-drive link functionality is automatically disabled.
	PROTOCOL ID (58.02)	Default: Read Only Range: -
	Displays the protocol ID and revision. This parameter is read-only.	
	NODE ADDRESS (58.03)	Default: 1 Range: 0 - 255
	Defines the node address of the drive on the fieldbus link. Values 1 - 247 are allowable. Two devices with the same address are not allowed on-line. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.	
	BAUD ADDRESS (58.04)	Default: 3 (19.2 kbps) Range: 2 - 7
	2 (9.6 kbps)	9.6 kbit/s
	3 (19.2 kbps)	19.2 kbit/s
	4 (38.4 kbps)	38.4 kbit/s
	5 (57.6 kbps)	57.6 kbit/s
	6 (76.8 kbps)	76.8 kbit/s
	7 (115.2 kbps)	115.2 kbit/s
Selects the transfer rate of the fieldbus link. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.		
PARITY (58.05)	Default: 2 (8 EVEN 1) Range: 0 - 3	
0 (8 NONE 1)	Eight data bits, no parity bit, one stop bit	
1 (8 NONE 2)	Eight data bits, no parity bit, two stop bits	
2 (8 EVEN 1)	Eight data bits, even parity bit, one stop bit	
3 (8 ODD 1)	Eight data bits, odd parity bit, one stop bit	
Selects the type of parity bit and the number of stop bits. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.		

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions																																																			
EMBEDDED FIELD BUS (Continued)	COMMUNICATION CONTROL (58.06) 0 (Enabled) 1 (Refresh settings) 2 (Silent mode)	Default: 0 (Enabled) Range: 0 - 2 Normal operation Validates any changed EFB configuration settings. Reverts automatically to Enabled. Activates silent mode (no messages are transmitted). Silent mode can be terminated by activating the Refresh settings selection of this parameter. Validates any changes in the EFB settings, or activates silent mode.																																																			
	COMMUNICATION DIAGNOSTICS (58.07)	Default: Read Only Range: 0000h - FFFFh Displays the status of the EFB communication. This parameter is read-only. <table border="1" data-bbox="701 737 1479 1514"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Init failed</td> <td>1 = EFB initialization failed</td> </tr> <tr> <td>1</td> <td>Addr config err</td> <td>1 = Node address not allowed by protocol</td> </tr> <tr> <td>2</td> <td>Silent mode</td> <td>1 = Drive not allowed to transmit 0 = Drive allowed to transmit</td> </tr> <tr> <td>3</td> <td>Autobauding</td> <td>Reserved</td> </tr> <tr> <td>4</td> <td>Wiring error</td> <td>1 = Errors detected (A/B wires possibly swapped)</td> </tr> <tr> <td>5</td> <td>Parity error</td> <td>1 = Error detected: check parameters 58.04 and 58.05</td> </tr> <tr> <td>6</td> <td>Baud rate error</td> <td>1 = Error detected: check parameters 58.05 and 58.04</td> </tr> <tr> <td>7</td> <td>No bus activity</td> <td>1 = 0 bytes received during last 5 seconds</td> </tr> <tr> <td>8</td> <td>No packets</td> <td>1 = 0 packets (addressed to any device) detected during last 5 seconds</td> </tr> <tr> <td>9</td> <td>Noise or addressing error</td> <td>1 = Errors detected (interference, or another device with the same address on line)</td> </tr> <tr> <td>10</td> <td>Comm loss</td> <td>1 = 0 packets addressed to the drive received within timeout (58.16)</td> </tr> <tr> <td>11</td> <td>CW/Ref loss</td> <td>1 = No control word or references received within timeout (58.16)</td> </tr> <tr> <td>12</td> <td>Not active</td> <td>Reserved</td> </tr> <tr> <td>13</td> <td>Protocol 1</td> <td>Reserved</td> </tr> <tr> <td>14</td> <td>Protocol 2</td> <td>Reserved</td> </tr> <tr> <td>15</td> <td>Internal error</td> <td>Reserved</td> </tr> </tbody> </table>	Bit	Name	Information	0	Init failed	1 = EFB initialization failed	1	Addr config err	1 = Node address not allowed by protocol	2	Silent mode	1 = Drive not allowed to transmit 0 = Drive allowed to transmit	3	Autobauding	Reserved	4	Wiring error	1 = Errors detected (A/B wires possibly swapped)	5	Parity error	1 = Error detected: check parameters 58.04 and 58.05	6	Baud rate error	1 = Error detected: check parameters 58.05 and 58.04	7	No bus activity	1 = 0 bytes received during last 5 seconds	8	No packets	1 = 0 packets (addressed to any device) detected during last 5 seconds	9	Noise or addressing error	1 = Errors detected (interference, or another device with the same address on line)	10	Comm loss	1 = 0 packets addressed to the drive received within timeout (58.16)	11	CW/Ref loss	1 = No control word or references received within timeout (58.16)	12	Not active	Reserved	13	Protocol 1	Reserved	14	Protocol 2	Reserved	15	Internal error	Reserved
	Bit	Name	Information																																																		
	0	Init failed	1 = EFB initialization failed																																																		
	1	Addr config err	1 = Node address not allowed by protocol																																																		
	2	Silent mode	1 = Drive not allowed to transmit 0 = Drive allowed to transmit																																																		
	3	Autobauding	Reserved																																																		
	4	Wiring error	1 = Errors detected (A/B wires possibly swapped)																																																		
	5	Parity error	1 = Error detected: check parameters 58.04 and 58.05																																																		
	6	Baud rate error	1 = Error detected: check parameters 58.05 and 58.04																																																		
7	No bus activity	1 = 0 bytes received during last 5 seconds																																																			
8	No packets	1 = 0 packets (addressed to any device) detected during last 5 seconds																																																			
9	Noise or addressing error	1 = Errors detected (interference, or another device with the same address on line)																																																			
10	Comm loss	1 = 0 packets addressed to the drive received within timeout (58.16)																																																			
11	CW/Ref loss	1 = No control word or references received within timeout (58.16)																																																			
12	Not active	Reserved																																																			
13	Protocol 1	Reserved																																																			
14	Protocol 2	Reserved																																																			
15	Internal error	Reserved																																																			
RECEIVED PACKETS (58.08)	Default: - Range: 0 - 4294967295 Displays a count of valid packets addressed to the drive. During normal operation, this number increases constantly. Can be reset from the control panel by keeping Reset depressed for over 3 seconds.																																																				

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
EMBEDDED FIELDBUS (Continued)	TRANSMITTED PACKETS (58.09)	Default: - Range: 0 - 4294967295 Displays a count of valid packets transmitted by the drive. During normal operation, this number increases constantly. Can be reset from the control panel by keeping Reset depressed for over 3 seconds.
	ALL PACKETS (58.10)	Default: - Range: 0 - 4294967295 Displays a count of valid packets addressed to any device on the bus. During normal operation, this number increases constantly. Can be reset from the control panel by keeping Reset depressed for over 3 seconds.
	UART ERRORS (58.11)	Default: - Range: 0 - 4294967295 Displays a count of character errors received by the drive. An increasing count indicates a configuration problem on the bus. Can be reset from the control panel by keeping Reset depressed for over 3 seconds.
	CRC ERRORS (58.12)	Default: - Range: 0 - 4294967295 Displays a count of packets with a CRC error received by the drive. An increasing count indicates interference on the bus. Can be reset from the control panel by keeping Reset depressed for over 3 seconds.
	COMMUNICATION LOSS ACTION (58.14)	Default: 1 (Fault) Range: 0 - 5
	0 (No)	No action taken (monitoring disabled).
	1 (Fault)	Drive trips on 6681 EFB comm loss. This only occurs if control is expected from the EFB (EFB selected as source of start/stop in the currently active location).
	2 (Last speed)	Drive generates an A7CE EFB comm loss warning and freezes the speed to the level the drive was operating at. This only occurs if control is expected from the EFB. The speed is determined on the basis of actual speed using 850 ms low-pass filtering. WARNING: Make sure that it is safe to continue operation in case of a communication break.
	3 (Speed ref safe)	Drive generates an A7CE EFB comm loss warning and sets the speed to the speed defined by parameter 22.41 Speed ref safe (or 28.41 Frequency ref safe when frequency reference is being used). This only occurs if control is expected from the EFB. WARNING: Make sure that it is safe to continue operation in case of a communication break.
	4 (Fault always)	Drive trips on 6681 EFB comm loss. This occurs even though no control is expected from the EFB.
	5 (Warning)	Drive generates an A7CE EFB comm loss warning. This occurs even though no control is expected from the EFB. WARNING: Make sure that it is safe to continue operation in case of a communication break.
		Selects how the drive reacts to an EFB communication break. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control. See also parameters 58.15 Communication loss mode and 58.16 Communication loss time.

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
EMBEDDED FIELD BUS (Continued)	COMMUNICATION LOSS MODE (58.15)	Default: 2 (Cw / Ref1 / Ref2) Range: 1, 2
	1 (Any message)	Any message addressed to the drive resets the timeout
	2 (Cw / Ref1 / Ref2)	A write of the control word or a reference from the fieldbus resets the timeout.
		Defines which message types reset the timeout counter for detecting an EFB communication loss. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control. See also parameters 58.14 Communication loss action and 58.16 Communication loss time.
		Drive generates an A7CE EFB comm loss warning and sets the speed to the speed defined by parameter 22.41 Speed ref safe (or 28.41 Frequency ref safe when frequency reference is being used). This only occurs if control is expected from the EFB. WARNING: Make sure that it is safe to continue operation in case of a communication break.
	COMMUNICATION LOSS TIME (58.16)	Default: 3.0 s Range: 0.0 - 6000.0 s
		Sets a timeout for EFB communication. If a communication break lasts longer than the timeout, the action specified by parameter 58.14 Communication loss action is taken. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control. See also parameter 58.15 Communication loss mode.
	TRANSMIT DELAY (58.17)	Default: 0 ms Range: 0 - 65535 ms
		Defines a minimum response delay in addition to any fixed delay imposed by the protocol. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.
	EFB CONTROL WORD (58.18)	Default: Read Only Range: 0000h - FFFFh
		Displays the raw (unmodified) control word sent by the Modbus controller to the drive. For debugging purposes. This parameter is read-only.
	EFB STATUS WORD (58.19)	Default: Read Only Range: 0000h - FFFFh
		Displays the raw (unmodified) status word sent by the drive to the Modbus controller. For debugging purposes. This parameter is read-only.
	CONTROL PROFILE (58.25)	Default: 0 (ABB Drives) Range: 0, 2
0 (ABB Drives)	ABB Drives profile (with a 16-bit control word) with registers in the classic format for backward compatibility.	
2 (Transparent)	Transparent profile (16-bit or 32-bit control word) with registers in the classic format.	
	Defines the control profile used by the protocol.	

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
EMBEDDED FIELD BUS (Continued)	EFB REF1 TYPE (58.26)	Default: 0 (Auto) Range: 0 - 5
	0 (ABB Drives)	Type and scaling are chosen automatically according to which reference chain (see settings Torque, Speed, Frequency) the incoming reference is connected to. If the reference is not connected to any chain, no scaling is applied (as with setting Transparent).
	2 (Transparent)	No scaling is applied.
	2 (General)	Generic reference with a scaling of 100 = 1 (ie. integer and two decimals).
	3 (Torque)	The scaling is defined by parameter 46.03 Torque scaling.
	4 (Speed)	The scaling is defined by parameter 46.01 Speed scaling.
	5 (Frequency)	The scaling is defined by parameter 46.02 Frequency scaling.
		Selects the type and scaling of reference 1 received through the embedded fieldbus interface. The scaled reference is displayed by 03.09 EFB reference 1.
	EFB REF2 TYPE (58.27)	Default: 3 (Torque) Range: 0 - 5
		Selects the type and scaling of reference 2 received through the embedded fieldbus interface. The scaled reference is displayed by 03.10 EFB reference 2. For the selections, see parameter 58.26 EFB ref1 type.
	EFB ACT1 TYPE (58.28)	Default: 0 (Auto) Range: 0 - 6
	0 (Auto)	Type/source and scaling follow the type of reference 1 selected by parameter 58.26 EFB ref1 type. See the individual settings below for the sources and scalings.
	1 (Transparent)	The value selected by parameter 58.31 EFB act1 transparent source is sent as actual value 1. No scaling is applied (the 16-bit scaling is 1 = 1 unit).
	2 (General)	The value selected by parameter 58.31 EFB act1 transparent source is sent as actual value 1 with a 16-bit scaling of 100 = 1 unit (ie. integer and two decimals).
	3 (Torque)	01.10 Motor torque is sent as actual value 1. The scaling is defined by parameter 46.03 Torque scaling.
	4 (Speed)	01.01 Motor speed used is sent as actual value 1. The scaling is defined by parameter 46.01 Speed scaling.
	5 (Frequency)	01.06 Output frequency is sent as actual value 1. The scaling is defined by parameter 46.02 Frequency scaling.
	6 (Position)	Motor position is sent as actual value 1. See parameter 90.06 Motor position scaled.
		Selects the type/source and scaling of actual value 1 transmitted to the fieldbus network through the embedded fieldbus interface.

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions	
EMBEDDED FIELD BUS (Continued)	EFB ACT1 TYPE (58.29)	Default: 3 (Torque) Range: 0 - 6	
	0 (Auto)	Type/source and scaling follow the type of reference 2 selected by parameter 58.27 EFB ref2 type. See the individual settings below for the sources and scalings	
	1 (Transparent)	The value selected by parameter 58.32 EFB act2 transparent source is sent as actual value 2. No scaling is applied (the 16-bit scaling is 1 = 1 unit).	
	2 (General)	The value selected by parameter 58.32 EFB act2 transparent source is sent as actual value 2 with a 16-bit scaling of 100 = 1 unit (ie. integer and two decimals).	
	3 (Torque)	01.10 Motor torque is sent as actual value 2. The scaling is defined by parameter 46.03 Torque scaling.	
	4 (Speed)	01.01 Motor speed used is sent as actual value 1. The scaling is defined by parameter 46.01 Speed scaling.	
	5 (Frequency)	01.01 Motor speed used is sent as actual value 2. The scaling is defined by parameter 46.01 Speed scaling.	
	6 (Position)	Motor position is sent as actual value 2. See parameter 90.06 Motor position scaled.	
			Selects the type/source and scaling of actual value 2 transmitted to the fieldbus network through the embedded fieldbus interface.
		EFB STATUS WORD TRANSPARENT SOURCE (58.30)	Default: 0 (Not selected) Range: 0
0 (Not selected)		None	
Other (-)		Source selection (see Terms and abbreviations)	
		Selects the source of the status word when 58.25 Control profile is set to Transparent.	
	EFB STATUS ACT1 TRANSPARENT SOURCE (58.31)	Default: 0 (Not selected) Range: 0	
	0 (Not selected)	None	
	Other (-)	Source selection (see Terms and abbreviations)	
		Selects the source of actual value 1 when 58.28 EFB act1 type is set to Transparent or General.	
	EFB STATUS ACT2 TRANSPARENT SOURCE (58.32)	Default: 0 (Not selected) Range: 0	
	0 (Not selected)	None	
	Other (-)	Source selection (see Terms and abbreviations)	
		Selects the source of actual value 1 when 58.29 EFB act2 type is set to Transparent or General.	

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions															
EMBEDDED FIELD BUS (Continued)	ADDRESSING MODE (58.33)	Default: 0 (Mode 0) Range: 0 - 2															
	0 (Mode 0)	16-bit values (groups 1 - 99, indexes 1 - 99): Register address = 400000 + 100 × parameter group + parameter index. For example, parameter 22.80 would be mapped to register 400000 + 2200 + 80 = 402280. 32-bit values (groups 1 - 99, indexes 1 - 99): Register address = 420000 + 200 × parameter group + 2 × parameter index. For example, parameter 22.80 would be mapped to register 420000 + 4400 + 160 = 424560.															
	1 (Mode 1)	16-bit values (groups 1 - 255, indexes 1 - 255): Register address = 400000 + 256 × parameter group + parameter index. For example, parameter 22.80 would be mapped to register 400000 + 5632 + 80 = 405712.															
	2 (Mode 2)	32-bit values (groups 1 - 127, indexes 1 - 255): Register address = 400000 + 512 × parameter group + 2 × parameter index. For example, parameter 22.80 would be mapped to register 400000 + 11264 + 160 = 411424.															
		Defines the mapping between parameters and holding registers in the 400101 - 465535 Modbus register range. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.															
	WORD ORDER (58.34)	Default: 1 (LO-HI) Range: 0, 1															
	0 (HI-LO)	The first register contains the high order word, the second contains the low order word.															
	1 (LO-HI)	The first register contains the low order word, the second contains the high order word.															
		Selects in which order 16-bit registers of 32-bit parameters are transferred. For each register, the first byte contains the high order byte and the second byte contains the low order byte. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control.															
	EFB COMM SUPERVISION FORCE (58.36)	Default: 0000b Range: 0000b - 0111b Activates fieldbus communication monitoring separately for each control location (see section Local control vs. external control). The parameter is primarily intended for monitoring the communication with EFB when it is connected to the application program and not selected as a control source by drive parameters.															
	<table border="1"> <thead> <tr> <th data-bbox="769 1566 846 1598">Bit</th> <th data-bbox="846 1566 1065 1598">Name</th> <th data-bbox="1065 1566 1544 1598">Information</th> </tr> </thead> <tbody> <tr> <td data-bbox="769 1598 846 1654">0</td> <td data-bbox="846 1598 1065 1654">Ext 1</td> <td data-bbox="1065 1598 1544 1654">1 = Communication monitoring active when Ext 1 is being used</td> </tr> <tr> <td data-bbox="769 1654 846 1711">1</td> <td data-bbox="846 1654 1065 1711">Ext 2</td> <td data-bbox="1065 1654 1544 1711">1 = Communication monitoring active when Ext 2 is being used</td> </tr> <tr> <td data-bbox="769 1711 846 1768">2</td> <td data-bbox="846 1711 1065 1768">Local</td> <td data-bbox="1065 1711 1544 1768">1 = Communication monitoring active when local control is being used</td> </tr> <tr> <td data-bbox="769 1768 846 1801">3-15</td> <td data-bbox="846 1768 1065 1801">Reserved</td> <td data-bbox="1065 1768 1544 1801"></td> </tr> </tbody> </table>		Bit	Name	Information	0	Ext 1	1 = Communication monitoring active when Ext 1 is being used	1	Ext 2	1 = Communication monitoring active when Ext 2 is being used	2	Local	1 = Communication monitoring active when local control is being used	3-15	Reserved	
	Bit	Name	Information														
	0	Ext 1	1 = Communication monitoring active when Ext 1 is being used														
1	Ext 2	1 = Communication monitoring active when Ext 2 is being used															
2	Local	1 = Communication monitoring active when local control is being used															
3-15	Reserved																

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
EMBEDDED FIELD BUS (Continued)	DATA I/O 1 (58.101)	Default: 1 (CW 16bit) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41
	0 (None)	None
	1 (CW 16bit)	Control Word (16 bits)
	2 (Ref1 16bit)	Reference REF1 (16 bits)
	3 (Ref2 16bit)	Reference REF2 (16 bits)
	4 (SW 16bit)	Status Word (16 bits)
	5 (Act1 16bit)	Actual value ACT1 (16 bits)
	6 (Act2 16bit)	Actual value ACT2 (16 bits)
	11 (CW 32bit)	Control Word (32 bits)
	12 (Ref1 32bit)	Reference REF1 (32 bits)
	13 (Ref2 32bit)	Reference REF2 (32 bits)
	14 (SW 32bit)	Status Word (32 bits)
	15 (Act1 32bit)	Actual value ACT1 (32 bits)
	16 (Act2 32bit)	Actual value ACT2 (32 bits)
	21 (CW2 16bit)	Control Word 2 (16 bits) When a 32-bit control word is used, this setting means the most significant 16 bits
	24 (SW2 16bit)	Status Word 2 (16 bits). When a 32-bit control word is used, this setting means the most significant 16 bits
	31 (RO/DIO control word)	Parameter 10.99 RO/DIO control word
	32 (AO1 data storage)	Parameter 13.91 AO1 data storage
	33 (AO2 data storage)	Parameter 13.92 AO2 data storage
	40 (Feedback data storage)	Parameter 40.91 Feedback data storage
	41 (Setpoint data storage)	Parameter 40.92 Setpoint data storage
	Other (-)	Source selection (see Terms and abbreviations)
		Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400001. The master defines the type of the data (input or output). The value is transmitted in a Modbus frame consisting of two 16-bit words. If the value is 16-bit, it is transmitted in the LSW (least significant word). If the value is 32-bit, the subsequent parameter is also reserved for it and must be set to None.
	DATA I/O 2 (58.102)	Default: 2 (Ref1 16bit) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41
		Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400002. For the selections, see parameter 58.101 Data I/O 1.
	DATA I/O 3 (58.103)	Default: 3 (Ref2 16bit) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41
		Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400003. For the selections, see parameter 58.101 Data I/O 1.

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
EMBEDDED FIELD BUS (Continued)	DATA I/O 4 (58.104)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41
		Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400004. For the selections, see parameter 58.101 Data I/O 1.
	DATA I/O 5 (58.105)	Default: 4 (SW 16bit) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41
		Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400005. For the selections, see parameter 58.101 Data I/O 1.
	DATA I/O 6 (58.106)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41
		Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400006. For the selections, see parameter 58.101 Data I/O 1.
	DATA I/O 7 (58.107)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41
		Parameter selector for Modbus register address 400007. For the selections, see parameter 58.101 Data I/O 1.
	DATA I/O 8 (58.108)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41
		Parameter selector for Modbus register address 400008. For the selections, see parameter 58.101 Data I/O 1.
	DATA I/O 9 (58.109)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41
		Parameter selector for Modbus register address 400009. For the selections, see parameter 58.101 Data I/O 1.
	DATA I/O 10 (58.110)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41
		Parameter selector for Modbus register address 400010. For the selections, see parameter 58.101 Data I/O 1.
	DATA I/O 11 (58.111)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41
		Parameter selector for Modbus register address 400011. For the selections, see parameter 58.101 Data I/O 1.
	DATA I/O 12 (58.112)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41
		Parameter selector for Modbus register address 400012. For the selections, see parameter 58.101 Data I/O 1.
	DATA I/O 13 (58.113)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41
		Parameter selector for Modbus register address 400013. For the selections, see parameter 58.101 Data I/O 1.
DATA I/O 14 (58.114)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41	
	Parameter selector for Modbus register address 400014. For the selections, see parameter 58.101 Data I/O 1.	

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
EMBEDDED FIELD BUS (Continued)	DATA I/O 15 (58.115)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41 Parameter selector for Modbus register address 400015. For the selections, see parameter 58.101 Data I/O 1.
	DATA I/O 16 (58.116)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41 Parameter selector for Modbus register address 400016. For the selections, see parameter 58.101 Data I/O 1.
	DATA I/O 17 (58.117)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41 Parameter selector for Modbus register address 400017. For the selections, see parameter 58.101 Data I/O 1.
	DATA I/O 18 (58.118)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41 Parameter selector for Modbus register address 400018. For the selections, see parameter 58.101 Data I/O 1.
	DATA I/O 19 (58.119)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41 Parameter selector for Modbus register address 400019. For the selections, see parameter 58.101 Data I/O 1.
	DATA I/O 20 (58.120)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41 Parameter selector for Modbus register address 400020. For the selections, see parameter 58.101 Data I/O 1.
	DATA I/O 21 (58.121)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41 Parameter selector for Modbus register address 400021. For the selections, see parameter 58.101 Data I/O 1.
	DATA I/O 22 (58.122)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41 Parameter selector for Modbus register address 400022. For the selections, see parameter 58.101 Data I/O 1.
	DATA I/O 23 (58.123)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41 Parameter selector for Modbus register address 400023. For the selections, see parameter 58.101 Data I/O 1.
	DATA I/O 22 (58.122)	Default: 0 (None) Range: 0 - 6, 11 - 16, 21, 24, 31 - 33, 40, 41 Parameter selector for Modbus register address 400024. For the selections, see parameter 58.101 Data I/O 1.

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions							
TRICKLE CURRENT	TRICKLE CURRENT ENABLE (74.01) 0 (Disable) 1 (Enable) 2 (Fieldbus)	Trickle current prevents rotation of fan during standby condition (anti wind mill feature). This can be caused by exterior wind conditions or by adjacent tower airflow that can act on the fan blades. Trickle current will produce a low level dc voltage across the windings of the direct drive motor. The dc voltage when applied to a permanent magnet motor will inhibit rotation of the fan blades. As a secondary benefit the voltage will produce enough heating in the motor windings to inhibit condensation in the motor caused by humidity. Operation will be while the tower is in a power on but standby mode.							
		Default: 0 (Disable) Range: 0 - 2							
		Disable trickle current.							
		Enable trickle current.							
		Fieldbus CTD cmd Word bit 0							
	Software Enable (1) or Disable (0) trickle current parameter setting. A hardware enable on DIO1 is also required to activate trickle current.								
	TRICKLE CURRENT LEVEL (74.02)	Default: 100W Range: 0 - 500W The level of trickle current is determined by frame size of the motor and input to the drive power level, no decimal required. Formula for how current value is determined: <table border="0" style="width: 100%;"> <tr> <td style="text-align: left;">Frame Size Family Motor</td> <td style="text-align: right;"><u>Wattage</u></td> </tr> <tr> <td>FL2800</td> <td style="text-align: right;">72</td> </tr> <tr> <td>FL4400</td> <td style="text-align: right;">119</td> </tr> <tr> <td>FL5800</td> <td style="text-align: right;">500</td> </tr> </table> $\text{Trickle Current} = \sqrt{\frac{* \text{Wattage}}{3 * \text{Stator R}}}$ Setting is entered as a power level.	Frame Size Family Motor	<u>Wattage</u>	FL2800	72	FL4400	119	FL5800
Frame Size Family Motor	<u>Wattage</u>								
FL2800	72								
FL4400	119								
FL5800	500								
TRICKLE DELAY TIME (74.03)	Default: 1 Min Range: 0 - 10 Min The time delay before trickle current starts. This delay ensures the motor has ramped down and stopped prior to trickle current beginning.								
DE-ICE FUNCTION	DE-ICE ENABLE (75.01) 0 (Disable) 1 (Enable) 2 (Fieldbus)	This is a cooling tower function to run at a low speed but in the opposite direction than standard. Primarily this function is to prevent ice buildup in towers for colder climates. De-ice function consists of a setting for the speed and a time value.							
		Default: 0 (Disable) Range: 0 - 1							
		Disable De-ice function							
		Enable De-ice function							
	Fieldbus CTD cmd Word bit1								
	Software Enable (1) or Disable (0) De-ice function. A hardware enable on DIO2 is also required to activate de-ice function.								
	DE-ICE SPEED (75.02)	Default: 30% Range: 0 - 100% The minimum value should not be allowed to be programmed at less than 30% motor base speed.							
DE-ICE RUN TIME (75.03)	Default: 1 Min. Range: 0 - 60 Mins. Value of time to run in de-ice function when Software Enable is active, and a hardware input is present. Drive will run at De-Ice function speed for the set run time and then shut down.								

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions	
CTD MOTOR CONTROL	AUTOPHASING CURRENT (76.01)	Default: 50% Current Range: 0 to 150% Current The Autophasing current is the DC current level the drive puts out to line up the rotor.	
	AUTOPHASING TIME (76.02)	Default: 100 Seconds Range: 0 to 100 Seconds The Autophasing time is how long the rotor can take to settle out before rotation is started. Because of the high inertia of the large fans, it could take 100 seconds to settle out.	
	OPERATING MODE (76.03)	Default: 1 (2-Wire) Range: 0 - 4 1 2-Wire 2 3-Wire 3 PID control 4 Fieldbus Operating Mode sets the method to start the drive for normal operation. Mode 1-4 configures DI1 and DI2 for EXT2 control. Custom mode allows custom programming of EXT1 control. Trickle and De-Ice always use EXT2. In modes 1-4, De-Ice has priority and Trickle will automatically start when drive is in standby. In Custom mode drive must be stopped before De-Ice will start. Trickle must be stopped before normal run. The CTDD application requires a limited set of operating modes. It is envisioned that the selection for this will be through CTDD Setup assistant programmed.	
	CT MINIMUM SPEED (76.04)	Default: 0 RPM Range: 0 to 650 RPM Sets the minimum forward operating speed of the CTDD motor.	
	HW CONFIGURATION	SUPPLY VOLTAGE (95.01)	Default: - Range: 0 - 6
		0 (Not Given)	No voltage range selected. The drive will not start modulating before a range is selected.
1 (208...240V)		208...240V	
2 (380...415V)		380...415V (Default for Demo Unit)	
3 (440...480V)		440...480V	
4 (500V)		500V (Default for normal drive)	
5 (525...600V)		525...600V	
6 (660...690V)		660...690V Selects the supply voltage range. This parameter is used by the drive to determine the nominal voltage of the supply network. The parameter also affects the current ratings and the DC voltage control functions (trip and brake chopper activation limits) of the drive.  WARNING: An incorrect setting may cause the motor to rush uncontrollably, or the brake chopper or resistor to overload. Note: The selections shown depend on the hardware of the drive. If only one voltage range is valid for the drive in question, it is selected by default.	

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
HW CONFIGURATION	CONTROL BOARD SUPPLY (95.04)	Default: 0 (Internal 24V) Range: 0 - 2
	0 (Internal 24V)	The drive control unit is powered from the drive power unit it is connected to.
	1 (External 24V)	The drive control unit is powered from an external power supply.
	2 (Redundant external 24V)	(Type BCU control units only) The drive control unit is powered from two redundant external power supplies. The loss of one of the supplies generates a warning (AFEC External power signal missing).
		Specifies how the control unit of the drive is powered.
SYSTEM	LANGUAGE (96.01)	Default: English Range: -
	Not selected	None
	English	English
	Deutsch	German
	Italiano	Italian
	Español	Spanish
	Portugues	Portuguese
	Nederlands	Dutch
	Français	French
	Dansk	Danish
	Suomi	Finnish
	Svenska	Swedish
	Russki	Russian
	Polski	Polish
	Czech	Czech
	Türkçe	Turkish
		Selects the language of the parameter interface and other displayed information when viewed on the control panel. Notes: <ul style="list-style-type: none"> • Not all languages listed below are necessarily supported. • This parameter does not affect the languages visible in the Drive composer PC tool. (Those are specified under View – Settings.)
	PASS CODE (96.02)	Default: - Range: 0 to 99999999
	14	CTDD User
	13	Fieldbus
	12	Expert Commissioner
		Does not default. Setting access level to 13 (Fieldbus) opens all Fieldbus applicable parameters (groups 50 to 56 and monitoring parameters 3.05, 3.06, 6.01 and 6.11). Expert commissioner enables all parameters in the drive by setting 96.02 = 12.

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
SYSTEM (Continued)	ACCESS LEVELS STATUS (96.03)	Default: Read Only Range: -
	11	Expert Commissioner
	12	Fieldbus
	13	CTDD User
		Shows which access levels have been activated by pass codes entered into parameter 96.02 Pass code. Parameter 96.03 shows the current access level setting, note ABB default will show active with the addition of the set level shown above. Value is offset by one from the password entered.
	MACRO SELECT (96.04)	Default: CTDD Range:
		CTDD
		Done
		Selects the application macro. Only CTDD macro is available. After a selection is made, the parameter reverts automatically to Done. NOTE: Selecting 96.04 will cause a reset to factory default (selecting CTDD).
	MACRO ACTIVE (96.05)	Default: Read Only Range: CTDD
		CTDD
		Defaults to CTDD. To change the macro, use parameter 96.04 Macro select.
	PARAMETER RESTORE (96.06)	Default: 0 (Done) Range: 0, 8, 62
	0 (Done)	Restoring is completed.
	8 (Restore defaults)	All editable parameter values are restored to default values, except <ul style="list-style-type: none"> • motor data and ID run results • control panel/PC communication settings • I/O extension module settings • fieldbus adapter settings • encoder configuration data • parameter 95.20 HW options word 1 and the differentiated defaults implemented by it.
62 (Clear all)	All editable parameter values are restored to default values, except <ul style="list-style-type: none"> • control panel/PC communication settings • fieldbus adapter settings • parameter 95.20 HW options word 1 and the differentiated defaults implemented by it. PC tool communication is interrupted during the restoring.	
	Restores the original settings of the control program (parameter default values). Note: This parameter cannot be changed while the drive is running.	

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions																							
SYSTEM (Continued)	PARAMETER SAVE MANUALLY (96.07) 0 (Done) 1 (Save)	Default: 0 (Done) Range: 0, 1 Save completed. Save in progress. Saves the valid parameter values to permanent memory. This parameter should be used to store values sent from a fieldbus, or when using an external power supply to the control board as the supply might have a very short hold-up time when powered off. Note: A new parameter value is saved automatically when changed from the PC tool or control panel but not when altered through a fieldbus adapter connection.																							
	UNIT SELECTION (96.16)	Default: 0001 0001 Range: 0000h - FFFFh Selects the unit of parameters indicating power, temperature and torque. Default setting is HP, °F and lb-ft. <table border="1" data-bbox="771 764 1313 1142"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td rowspan="2">0</td> <td rowspan="2">Power unit</td> <td>0 = kW</td> </tr> <tr> <td>1 = hp default</td> </tr> <tr> <td>1</td> <td colspan="2">Reserved</td> </tr> <tr> <td rowspan="2">2</td> <td rowspan="2">Temperature unit</td> <td>0 = C (°C) default</td> </tr> <tr> <td>1 = F (°F)</td> </tr> <tr> <td>3</td> <td colspan="2">Reserved</td> </tr> <tr> <td rowspan="2">4</td> <td rowspan="2">Torque unit</td> <td>0 = Nm (N·m)</td> </tr> <tr> <td>1 = lbft (lb·ft) default</td> </tr> <tr> <td>5 - 15</td> <td colspan="2">Reserved</td> </tr> </tbody> </table>	Bit	Name	Information	0	Power unit	0 = kW	1 = hp default	1	Reserved		2	Temperature unit	0 = C (°C) default	1 = F (°F)	3	Reserved		4	Torque unit	0 = Nm (N·m)	1 = lbft (lb·ft) default	5 - 15	Reserved
Bit	Name	Information																							
0	Power unit	0 = kW																							
		1 = hp default																							
1	Reserved																								
2	Temperature unit	0 = C (°C) default																							
		1 = F (°F)																							
3	Reserved																								
4	Torque unit	0 = Nm (N·m)																							
		1 = lbft (lb·ft) default																							
5 - 15	Reserved																								

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
MOTOR DATA	MOTOR TYPE (99.03)	Default: 1 (PMSM) Range: 0, 1
		0 Training Demo
		1 Permanent magnet synchronous motor. Three-phase AC synchronous motor with permanent magnet rotor and sinusoidal Back EMF voltage.
		Selects the motor type. Note: This parameter cannot be changed while the drive is running.
	MOTOR CONTROL MODE (99.04)	Default: 0 (DTC) Range: 0, 1
		0 Direct torque control. This mode is suitable for most applications. Note: Instead of direct torque control, scalar control is also available, and should be used in the following situations: <ul style="list-style-type: none"> • with multimotor applications 1) if the load is not equally shared between the motors, 2) if the motors are of different sizes, or 3) if the motors are going to be changed after the motor identification (ID run) • if the nominal current of the motor is less than 1/6 of the nominal output current of the drive • if the drive is used with no motor connected (for example, for test purposes). See also section Operating modes of the drive.
		1 Scalar control. The outstanding motor control accuracy of DTC cannot be achieved in scalar control. Refer to the DTC selection above for a list of applications where scalar control should definitely be used. Notes: <ul style="list-style-type: none"> • Correct motor operation requires that the magnetizing current of the motor does not exceed 90% of the nominal current of the inverter. • Some standard features are disabled in scalar control mode. See also section Scalar motor control (page 60), and section Operating modes of the drive.
		Selects the motor control mode.
	MOTOR NOMINAL CURRENT (99.06)	Default: 0.0 A Range: 0.0 - 6400.0 A
		Defines the nominal motor current. Must be equal to the value on the motor rating plate. If multiple motors are connected to the drive, enter the total current of the motors. Note: This parameter cannot be changed while the drive is running.
	BACK EMF VOLTAGE (99.07)	Default: Back EMF Range: 0.0 - 800.0
		Defines the motor Back EMF voltage. This setting must match the value on the auxiliary rating plate of the motor. Notes: <ul style="list-style-type: none"> • With permanent magnet motors, the nominal voltage is the Back EMF voltage at nominal speed of the motor. • The stress on the motor insulation is always dependent on the drive supply voltage. This also applies to the case where the motor voltage rating is lower than that of the drive and the supply. • This parameter cannot be changed while the drive is running.
MOTOR NOMINAL FREQUENCY (99.08)	Default: 0.0 Hz Range: 0.0 - 500.0 Hz	
	Defines the nominal motor frequency. This setting must match the value on the rating plate of the motor. Note: This parameter cannot be changed while the drive is running.	

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
MOTOR DATA (Continued)	MOTOR NOMINAL SPEED (99.09)	Default: 0 RPM Range: 0 - 650 RPM Defines the nominal motor speed. The setting must match the value on the rating plate of the motor. Note: This parameter cannot be changed while the drive is running.
	MOTOR NOMINAL POWER (99.10)	Default: 0.00 kW or hp Range: -10000.00 to +10000.00 kW or -13404.83 to +13404.83 hp Defines the nominal motor power. The setting must match the value on the rating plate of the motor. The unit is selected by parameter 96.16 Unit selection. Note: This parameter cannot be changed while the drive is running.
	ID RUN REQUESTED (99.13)	Default: 0 (None) Range: 0 - 6
	0 (None)	See Firmware Manual.
	1 (Normal)	See Firmware Manual.
	2 (Reduced)	See Firmware Manual.
	3 (Standstill)	Preferred ID run mode for cooling tower applications -- Standstill ID run. The motor is injected with DC current. With an AC induction (asynchronous) motor, the motor shaft is not rotated. With a permanent magnet motor, the shaft can rotate up to half a revolution.
	4 (Autophasing)	See Firmware Manual.
	5 (Current Measurement Calibration)	See Firmware Manual.
	6 (Advanced)	See Firmware Manual.
	7 (Advanced Standstill)	See Firmware Manual.
		Selects the type of the motor identification routine (ID run) performed at the next start of the drive. During the ID run, the drive will identify the characteristics of the motor for optimum motor control. If no ID run has been performed yet (or if default parameter values have been restored using parameter 96.06 Parameter restore), this parameter is automatically set to Standstill, signifying that an ID run must be performed. After the ID run, the drive stops and this parameter is automatically set to None. Notes: <ul style="list-style-type: none"> For the Advanced ID run, the machinery must always be de-coupled from the motor. With a permanent magnet or synchronous reluctance motor, a Normal, Reduced or Standstill ID run requires that the motor shaft is NOT locked and the load torque is less than 10%. With scalar control mode (99.04 Motor control mode = Scalar), only the Current measurement calibration ID run mode is possible. Once the ID run is activated, it can be canceled by stopping the drive. The ID run must be performed every time any of the motor parameters (99.04, 99.06 - 99.12) have been changed. Ensure that the Safe torque off and emergency stop circuits (if any) are closed during the ID run. Mechanical brake (if present) is not opened by the logic for the ID run. This parameter cannot be changed while the drive is running.
	LAST ID RUN PERFORMED (99.14)	Default: 0 (None) Range: 0 - 6 Shows the type of ID run that was performed last. <ul style="list-style-type: none"> See parameter 99.13.

Table 12-4 Level 1 Parameter Block Definitions

Block Title	Parameter (Number) Selection (Value)	Descriptions
MOTOR DATA (Continued)	MOTOR POLEPAIRS CALCULATED (99.15)	Default: Read Only Range: 0 - 1000
		Calculated number of pole pairs in the motor.
	MOTOR PHASE ORDER (99.16)	Default: 0 (U V W) Range: 0, 1
	0 (U V W)	Normal
	1 (U W V)	Reversed Rotation Direction
		Switches the rotation direction of motor. This parameter can be used if the motor turns in the wrong direction (i.e. because of the wrong phase order in the motor cable), and correcting the cabling is considered impractical. Note: Changing this parameter does not affect speed reference polarities, so positive speed reference will rotate the motor forward. The phase order selection ensures that “forward” is the correct direction.

Chapter 13

Troubleshooting

The ACS880+N5350 will annunciate events that are abnormal during operation as a warnings or fault. The codes and names of active warnings/faults are displayed on the control panel of the drive. Only the codes of warnings/faults are available over fieldbus.

The chapter lists the warning and fault messages including possible causes and corrective actions. The causes of most warnings and faults can be identified and corrected using the information in this chapter.

13.1 Warnings and Faults

Warnings do not need to be reset; they stop showing when the cause of the warning ceases. Warnings do not latch and the drive will continue to operate the motor.

Faults do latch inside the drive and cause the drive to trip, and the motor stops. After the cause of a fault has been removed, the fault can be reset from a selectable 386 Fault tracing source (see parameter 31.11 Fault reset selection) such as the control panel, Drive composer PC tool, the digital inputs of the drive, or fieldbus. After the fault is reset, the drive can be restarted.

13.1.1 Pure Events

In addition to warnings and faults, there are pure events that are only recorded in the event log of the drive. The codes of these events are included in the Warning messages table.

13.1.2 Editable Messages

For some warnings and faults, the message text can be edited and instructions and contact information added. To edit these messages, choose Menu - Settings - Edit texts on the control panel.

13.2 Warning/Fault History

13.2.1 Event Log

All indications are stored in the event log with a time stamp and other information. The event log can be accessed from the main Menu on the control panel. It can also be accessed (and reset) using the Drive composer PC tool. In Drive composer, some faults are presented with additional data recorded prior to the fault; refer to Drive composer Start-up and maintenance PC tool User's manual (3AUA0000094606).

13.2.2 Auxiliary Codes

Some events generate an auxiliary code that often helps in pinpointing the problem. On the control panel, the auxiliary code is stored as part of the details of the event; in the Drive composer PC tool, the auxiliary code is shown in the event listing.

13.2.3 Parameters that Contain Warning/Fault Information

The drive is able to store a list of the active faults actually causing the drive to trip at the present time. The faults are displayed in parameter group 04 Warnings and faults. The parameter group also displays a list of faults and warnings that have previously occurred.

13.3 Warning Messages

NOTE: This list contains events that only appear in the Event Log.

Warning	Fault #	Cause	What to do
Current Calibration	A2A1	Current offset and gain measurement calibration will occur at next start.	Informative warning. (See parameter 99.13 ID run requested.)
Overcurrent	A2B1	Output current has exceeded internal fault limit.	<p>Check motor load.</p> <p>Check acceleration times in parameter group 23 Speed reference ramp (speed control), 26 Torque reference chain (torque control) or 28 Frequency reference chain (frequency control). Also check parameters 46.01 Speed scaling, 46.02 Frequency scaling and 46.03 Torque scaling.</p> <p>Check motor and motor cable (including phasing and delta/star connection).</p> <p>Check there are no contactors opening and closing in motor cable.</p> <p>Check that the start-up data in parameter group 99 corresponds to the motor rating plate.</p> <p>Check that there are no power factor correction capacitors or surge absorbers in motor cable.</p> <p>Check encoder cable (including phasing).</p>
Earth leakage	A2B3	Drive has detected load unbalance typically due to earth fault in motor or motor cable.	<p>Check there are no power factor correction capacitors or surge absorbers in motor cable.</p> <p>Check for an earth fault in motor or motor cables by measuring the insulation resistances of motor and motor cable.</p> <p>Try running the motor in scalar control mode if allowed. (See parameter 99.04 Motor control mode.)</p> <p>If no earth fault can be detected, contact your local ABB representative.</p>
Short circuit	A2B4	Short-circuit in motor cable(s) or motor.	<p>Check motor and motor cable for cabling errors.</p> <p>Check there are no power factor correction capacitors or surge absorbers in motor cable.</p>
IGBT overload	A2BA	Excessive IGBT junction to case temperature. This warning protects the IGBT(s) and can be activated by a short circuit in the motor cable.	<p>Check motor cable.</p> <p>Check ambient conditions.</p> <p>Check air flow and fan operation.</p> <p>Check heatsink fins for dust pick-up.</p> <p>Check motor power against drive power.</p>
DC link overvoltage	A3A1	Intermediate circuit DC voltage too high (when the drive is stopped).	<p>Check the supply voltage setting (parameter 95.01 Supply voltage). Note that the wrong setting of the parameter may cause the motor to rush uncontrollably, or may overload the brake chopper or resistor.</p> <p>Check the supply voltage. If the problem persists, contact your local ABB representative.</p>
DC link undervoltage	A3A2	Intermediate circuit DC voltage too low (when the drive is stopped).	
DC not charged	A3AA	The voltage of the intermediate DC circuit has not yet risen to operating level.	
DC voltage difference	A3C1	Difference in DC voltages between parallel-connected inverter modules.	Contact your local ABB representative.
Motor cable overload	A480	Calculated motor cable temperature has exceeded warning limit.	<p>Check the settings of parameters 35.61 and 35.62.</p> <p>Check the dimensioning of the motor cable in regard to required load.</p>

Table 13-1 Warning Messages (Alphabetical by Keypad Text)

Warning	Fault #	Cause	What to do
Incorrect temperature sensor setup	A490	Sensor type mismatch	Check the settings of temperature source parameters 35.11 and 35.21 against 91.21 and 91.24.
		Faulty wiring between an encoder interface module and the temperature sensor.	Check the wiring of the sensor. The auxiliary code (see the event log) identifies the interface module. (0 = Module 1, 1 = Module 2).
External temperature 1 <small>(Editable message text)</small>	A491	Measured temperature 1 has exceeded warning limit.	Check the value of parameter 35.02 Measured temperature 1. Check the cooling of the motor (or other equipment whose temperature is being measured). Check the value of 35.13 Temperature 1 warning limit.
External temperature 2 <small>(Editable message text)</small>	A492	Measured temperature 2 has exceeded warning limit.	Check the value of parameter 35.03 Measured temperature 2. Check the cooling of the motor (or other equipment whose temperature is being measured). Check the value of 35.23 Temperature 2 warning limit.
IGBT overtemperature	A4A1	Estimated drive IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
Cooling	A4A9	Drive module temperature is excessive.	Check ambient temperature. If it exceeds 40°C (104°F), ensure that load current does not exceed derated load capacity of drive. See appropriate Hardware Manual. Check drive module cooling air flow and fan operation. Check inside of cabinet and heatsink of drive module for dust pick-up. Clean whenever necessary.
Excess temperature	A4B0	Power unit module temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
Excess temperature difference	A4B1	High temperature difference between the IGBTs of different phases.	Check the motor cabling. Check cooling of drive module(s).
IGBT temperature	A4F6	Drive IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
PU communication	A580	Communication errors detected between the drive control unit and the power unit.	Check the connections between the drive control unit and the power unit.
Safe torque off <small>Programmable warning: 31.22 STO indication run/stop</small>	A5A0	Safe torque off function is active, i.e. safety circuit signal(s) connected to connector XSTO is lost.	Check safety circuit connections. For more information, see appropriate drive hardware manual and description of parameter 31.22 STO indication run/stop.
Measurement circuit temperature	A5EA	Problem with internal temperature measurement of the drive.	Contact your local ABB representative.
PU board powerfail	A5EB	Power unit power supply failure.	Contact your local ABB representative.
PU communication internal	A5EC	Communication errors detected between the drive control unit and the power unit.	Check the connections between the drive control unit and the power unit.
Measurement circuit ADC	A5ED	Measurement circuit fault.	Contact your local ABB representative.

Table 13-1 Warning Messages (Alphabetical by Keypad Text)			
Warning	Fault #	Cause	What to do
Measurement circuit DFF	A5EE	Measurement circuit fault.	Contact your local ABB representative.
PU state feedback	A5EF	State feedback from output phases does not match control signals.	Contact your local ABB representative.
Charging feedback	A5F0	Charging feedback signal missing.	Check the feedback signal coming from the charging system.
Motor nominal value	A6A4	The motor parameters are set incorrectly.	Check the settings of the motor configuration parameters in group 99.
		The drive is not dimensioned correctly.	Check that the drive is sized correctly for the motor.
No motor data	A6A5	Parameters in group 99 have not been set.	Check that all the required parameters in group 99 have been set. Note: It is normal for this warning to appear during the start-up and continue until the motor data is entered.
Supply voltage unselected	A6A6	The supply voltage has not been defined.	Set supply voltage in parameter 95.01 Supply voltage.
FBA A parameter conflict	A6D1	The drive does not have a functionality requested by a PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups 50 Fieldbus adapter (FBA) and 51 FBA A settings.
FBA B parameter conflict	A6D2	The drive does not have a functionality requested by a PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups 50 Fieldbus adapter (FBA) and 54 FBA B settings.
AI parametrization	A6E5	The current/voltage hardware setting of an analog input does not correspond to parameter settings.	Check the event log for an auxiliary code. The code identifies the analog input whose settings are in conflict. Adjust either the hardware setting (on the drive control unit) or parameter 12.15/12.25. Note: Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings.
Motor stall <small>Programmable warning: 31.24 Stall function</small>	A780	Motor is operating in stall region because of e.g. excessive load or insufficient motor power.	Check motor load and drive ratings. Check fault function parameters.
Motor fan <small>Programmable warning: 35.106 DOL starter event type</small>	A781	No feedback received from external fan.	Check external fan (or other equipment controlled) by the logic. Check settings of parameters 35.100...35.106.
FEN temperature	A782	Error in temperature measurement when temperature sensor (KTY or PTC) connected to encoder interface FEN-xx is used.	Check that parameter 35.11 Temperature 1 source / 35.21 Temperature 2 source setting corresponds to actual encoder interface installation.
		Error in temperature measurement when KTY sensor connected to encoder interface FEN-01 is used.	FEN-01 does not support temperature measurement with KTY sensor. Use PTC sensor or other encoder interface module.
Brake resistor	A791	Brake resistor broken or not connected.	Check that a brake resistor has been connected. Check the condition of the brake resistor.

Table 13-1 Warning Messages (Alphabetical by Keypad Text)

Warning	Fault #	Cause	What to do
BR excess temperature	A793	Brake resistor temperature has exceeded warning limit defined by parameter 43.12 Brake resistor warning limit.	Stop drive. Let resistor cool down. Check resistor overload protection function settings (parameter group 43 Brake chopper). Check warning limit setting, parameter 43.12 Brake resistor warning limit. Check that the resistor has been dimensioned correctly. Check that braking cycle meets allowed limits.
BR data	A794	Brake resistor data has not been given.	Check the resistor data settings (parameters 43.08...43.10).
Speed feedback configuration	A797	Speed feedback configuration has changed.	Check the event log for an auxiliary code (format XXYY ZZZZ). "XX" specifies the number of the encoder interface module (01: 91.11/91.12, 02: 91.13/91.14), "YY" specifies the encoder (01: 92 Encoder 1 configuration, 02: 93 Encoder 2 configuration). "ZZZZ" indicates the problem (see actions for each code below).
	0001	Adapter not found in specified slot.	Check module location (91.12 or 91.14).
	0002	Detected type of interface module does not match parameter setting.	Check the module type (91.11 or 91.13) against status (91.02 or 91.03).
	0003	Logic version too old.	Contact your local ABB representative.
	0004	Software version too old.	Contact your local ABB representative.
	0006	Encoder type incompatible with interface module type.	Check module type (91.11 or 91.13) against encoder type (92.01 or 93.01).
	0007	Adapter not configured.	Check module location (91.12 or 91.14).
	0008	Speed feedback configuration has changed.	Use parameter 91.10 Encoder parameter refresh) to validate any changes in the settings.
BC short circuit	A79B	Short circuit in brake chopper IGBT	Replace brake chopper if external. Drives with internal choppers will need to be returned to ABB. Ensure brake resistor is connected and not damaged.
BC IGBT excess temperature	A79C	Brake chopper IGBT temperature has exceeded internal warning limit.	Let chopper cool down. Check for excessive ambient temperature. Check for cooling fan failure. Check for obstructions in the air flow. Check the dimensioning and cooling of the cabinet. Check resistor overload protection function settings (parameters 43.06...43.10). Check minimum allowed resistor value for the chopper being used. Check that braking cycle meets allowed limits. Check that drive supply AC voltage is not excessive.
Mechanical brake closing failed <small>Programmable warning: 44.17 Brake fault function</small>	A7A1	Status of mechanical brake acknowledgement is not as expected during brake close.	Check mechanical brake connection. Check mechanical brake settings in parameter group 44 Mechanical brake control. Check that acknowledgement signal matches actual status of brake.
Mechanical brake opening failed <small>Programmable warning: 44.17 Brake fault function</small>	A7A2	Status of mechanical brake acknowledgement is not as expected during brake open.	Check mechanical brake connection. Check mechanical brake settings in parameter group 44 Mechanical brake control. Check that acknowledgement signal matches actual status of brake.

Table 13-1 Warning Messages (Alphabetical by Keypad Text)			
Warning	Fault #	Cause	What to do
Mechanical brake opening not allowed Programmable warning: 44.17 Brake fault function	A7A5	Open conditions of mechanical brake cannot be fulfilled (for example, brake has been prevented from opening by parameter 44.11 Keep brake closed).	Check mechanical brake settings in parameter group 44 Mechanical brake control (especially 44.11 Keep brake closed). Check that acknowledgement signal (if used) matches actual status of brake.
FIO-11 AI parametrization	A7AA	The hardware current/voltage setting of an analog input (on an I/O extension module) does not correspond to parameter settings.	Check the event log for an auxiliary code (format 0000 XXYY). "XX" specifies the number of the I/O extension module (01: parameter group 14 I/O extension module 1, 02: 15 I/O extension module 2, 03: 16 I/O extension module 3). "YY" specifies the analog input on the module. For example, in case of I/O extension module 1, analog input AI1 (auxiliary code 0000 0101), the hardware current/voltage setting on the module is shown by parameter 14.29. The corresponding parameter setting is 14.30. Adjust either the hardware setting on the module or the parameter to solve the mismatch. Note: Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings.
Extension I/O configuration failure	A7AB	The I/O extension module types and locations specified by parameters do not match the detected configuration.	Check the event log for an auxiliary code. The code indicates which I/O extension module is affected. Check the type and location settings of the modules (parameters 14.01, 14.02, 15.01, 15.02, 16.01 and 16.02). Check that the modules are properly installed.
Motor speed feedback Programmable warning: 90.45 Motor feedback fault	A7B0	No motor speed feedback is received.	Check the event log for an auxiliary code (format XXYY ZZZZ). "XX" specifies the number of the encoder interface module (01: 91.11/91.12, 02: 91.13/91.14), "YY" specifies the encoder (01: 92 Encoder 1 configuration, 02: 93 Encoder 2 configuration). "ZZZZ" indicates the problem (see actions for each code below).
	0001	Motor gear definition invalid or outside limits.	Check motor gear settings (90.43 and 90.44).
	0002	Encoder not configured.	Check encoder settings (92 Encoder 1 configuration or 93 Encoder 2 configuration). Use parameter 91.10 Encoder parameter refresh) to validate any changes in the settings.
	0003	Encoder stopped working.	Check encoder status.
	0004	Encoder drift detected.	Check for slippage between encoder and motor.
FBA A communication Programmable warning: 50.02 FBA A comm loss func	A7C1	Cyclical communication between drive and fieldbus adapter module A or between PLC and fieldbus adapter module A is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter groups 50 Fieldbus adapter (FBA), 51 FBA A settings, 52 FBA A data in and 53 FBA A data out. Check cable connections. Check if communication master is able to communicate.
FBA B communication Programmable warning: 50.32 FBA B comm loss func	A7C2	Cyclical communication between drive and fieldbus adapter module B or between PLC and fieldbus adapter module B is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter group 50 Fieldbus adapter (FBA). Check cable connections. Check if communication master is able to communicate.
DDCS controller comm loss Programmable warning: 60.59 DDCS controller comm loss function	A7CA	DDCS (fiber optic) communication between drive and external controller is lost.	Check status of controller. See user documentation of controller. Check settings of parameter group 60 DDCS communication. Check cable connections. If necessary, replace cables.

Table 13-1 Warning Messages (Alphabetical by Keypad Text)

Warning	Fault #	Cause	What to do
MF comm loss <small>Programmable warning: 60.09 M/F comm loss function</small>	A7CB	Master/follower communication is lost.	Check status of other drives on the master/follower link. Check settings of parameter group 60 DDCS communication. Check cable connections. If necessary, replace cables.
Encoder 1	A7E1	Encoder error.	Check the event log for an auxiliary code (format XXYY ZZZZ). "XX" specifies the number of the encoder interface module (01: 91.11/91.12, 02: 91.13/91.14), "YY" specifies the encoder (01: 92 Encoder 1 configuration, 02: 93 Encoder 2 configuration). "ZZZZ" indicates the problem (see actions for each code below).
	0001	Cable fault	Check the conductor order at both ends of the encoder cable. Check the groundings of the encoder cable. If the encoder was working previously, check the encoder, encoder cable and encoder interface module for damage. See also parameter 92.21 Encoder cable fault mode.
	0002	No encoder signal	Check the condition of the encoder.
	0003	Overspeed	Contact your local ABB representative.
	0004	Overfrequency	Contact your local ABB representative.
	0005	Resolver ID run failed	Contact your local ABB representative.
	0006	Resolver overcurrent fault	Contact your local ABB representative.
	0007	Speed scaling error	Contact your local ABB representative.
Panel loss <small>Programmable warning: 49.05 Communication loss action</small>	A7EE	Control panel or PC tool selected as active control location for drive has ceased communicating.	Check PC tool or control panel connection. Check control panel connector. Check mounting platform if being used. Disconnect and reconnect the control panel.
Motor bearing <small>Programmable warnings: 33.14 On-time 1 warn message 33.24 On-time 2 warn message 33.55 Value counter 1 warn message 33.65 Value counter 2 warn message</small>	A880	Warning generated by an ontime timer or a value counter.	Check the event log for an auxiliary code. Check the source of the warning corresponding to the code: 0: 33.13 On-time 1 source 1: 33.23 On-time 2 source 4: 33.53 Value counter 1 source 5: 33.63 Value counter 2 source.
Output relay	A881	Warning generated by an edge counter. <small>Programmable warnings: 33.35 Edge counter 1 warn message 33.45 Edge counter 2 warn message</small>	Check the event log for an auxiliary code. Check the source of the warning corresponding to the code: 2: 33.33 Edge counter 1 source 3: 33.43 Edge counter 2 source.
Motor starts	A882		
Power ups	A883		
Main contactor	A884		
DC charge	A885		
On-time 1 <small>(Editable message text) Programmable warning: 33.14 On-time 1 warn message</small>	A886	Warning generated by on-time timer 1.	Check the source of the warning (parameter 33.13 On-time 1 source).
On-time 2 <small>(Editable message text) Programmable warning: 33.24 On-time 2 warn message</small>	A887	Warning generated by on-time timer 2.	Check the source of the warning (parameter 33.23 On-time 2 source).
Edge counter 1 <small>(Editable message text) Programmable warning: 33.35 Edge counter 1 warn message</small>	A888	Warning generated by edge counter 1.	Check the source of the warning (parameter 33.33 Edge counter 1 source).

Table 13-1 Warning Messages (Alphabetical by Keypad Text)			
Warning	Fault #	Cause	What to do
Edge counter 2 <small>(Editable message text) Programmable warning: 33.45 Edge counter 2 warn message</small>	A889	Warning generated by edge counter 2.	Check the source of the warning (parameter 33.43 Edge counter 2 source).
Value counter 1 <small>(Editable message text) Programmable warning: 33.55 Value counter 1 warn message</small>	A88A	Warning generated by value counter 1.	Check the source of the warning (parameter 33.53 Value counter 1 source).
Value counter 2 <small>(Editable message text) Programmable warning: 33.65 Value counter 2 warn message</small>	A88B	Warning generated by value counter 2.	Check the source of the warning (parameter 33.63 Value counter 2 source).
Device clean	A88C	Warning generated by an ontime timer. Programmable warnings: 33.14 On-time 1 warn message 33.24 On-time 2 warn message	Check the event log for an auxiliary code. Check the source of the warning corresponding to the code: 0: 33.13 On-time 1 source 1: 33.23 On-time 2 source 10: 05.04 Fan on-time counter.
DC capacitor	A88D		
Cabinet fan	A88E		
Cooling fan	A88F		
Additional cooling	A890		
AI supervision <small>Programmable warning: 12.03 AI supervision function</small>	A8A0	An analog signal is outside the limits specified for the analog input.	Check signal level at the analog input. Check the wiring connected to the input. Check the minimum and maximum limits of the input in parameter group 12 Standard AI.
Signal supervision <small>(Editable message text) Programmable warning: 32.06 Supervision 1 action 32.16 Supervision 2 action 32.26 Supervision 3 action</small>	A8B0	Warning generated by a signal supervision function.	Check the source of the warning (parameter 32.07, 32.17 or 32.28).
External warning 1 <small>(Editable message text) Programmable warning: 31.01 External event 1 source 31.02 External event 1 type</small>	A981	Fault in external device 1.	Check the external device. Check setting of parameter 31.01 External event 1 source.
External warning 2 <small>(Editable message text) Programmable warning: 31.03 External event 2 source 31.04 External event 2 type</small>	A982	Fault in external device 2.	Check the external device. Check setting of parameter 31.03 External event 2 source.
External warning 3 <small>(Editable message text) Programmable warning: 31.05 External event 3 source 31.06 External event 3 type</small>	A983	Fault in external device 3.	Check the external device. Check setting of parameter 31.05 External event 3 source.
External warning 4 <small>(Editable message text) Programmable warning: 31.07 External event 4 source 31.08 External event 4 type</small>	A984	Fault in external device 4.	Check the external device. Check setting of parameter 31.07 External event 4 source.
External warning 5 <small>(Editable message text) Programmable warning: 31.09 External event 5 source 31.10 External event 5 type</small>	A985	Fault in external device 5.	Check the external device. Check setting of parameter 31.09 External event 5 source.
FA2FA DDCS com loss <small>Programmable warning: 60.79 INU-LSU com loss ctrl</small>	AF80	DDCS (fiber optic) communication between converters (for example, the inverter unit and the supply unit) is lost.	Check status of other converter (parameters 06.36 and 06.39). Check settings of parameter group 60 DDCS communication. Check the corresponding settings in the control program of the other converter. Check cable connections. If necessary, replace cables.

Table 13-1 Warning Messages (Alphabetical by Keypad Text)			
Warning	Fault #	Cause	What to do
Line side unit warning	AF85	The supply unit has generated a warning.	If using a control panel or the Drive composer tool, connect to the supply unit to read the warning code. Refer to the firmware manual of the supply unit for instructions related to the code.
Process PID sleep mode	AF8C	The drive is entering sleep mode.	Informative warning. See section Sleep function for process PID control, and parameters 40.41...40.48.
Autoreset	AFAA	A fault is about to be autoreset.	Informative warning. See the settings in parameter group 31 Fault functions.
Emergency stop (off2)	AFE1	Drive has received an emergency stop (mode selection off2) command.	Check that it is safe to continue operation. Then return emergency stop push button to normal position. Restart drive.
Emergency stop (off1 or off3)	AFE2	Drive has received an emergency stop (mode selection off1 or off3) command.	If the emergency stop was unintentional, check the source selected by parameter 21.05 Emergency stop source.
Enable start signal missing (Editable message text)	AFEA	No enable start signal received.	Check the setting of (and the source selected by) parameter 20.19 Enable start command.
Run enable missing	AFEB	No run enable signal is received.	Check setting of parameter 20.12 Run enable 1 source. Switch signal on (e.g. in the fieldbus Control Word) or check wiring of selected source.
External power signal missing	AFEC	95.04 Control board supply is set to External 24V but no voltage is connected to the XPOW connector of the control unit.	Check the external 24 V DC power supply to the control unit, or change the setting of parameter 95.04.
Identification run	AFF6	Motor ID run will occur at next start.	Informative warning.
Autophasing	AFF7	Autophasing will occur at next start.	Informative warning.
STO event Programmable event: 31.22 STO indication run/stop	B5A0	Safe torque off function is active, i.e. safety circuit signal(s) connected to connector XSTO is lost.	Check safety circuit connections. For more information, see appropriate drive hardware manual and description of parameter 31.22 STO indication run/stop.

13.4 Fault Messages

Table 13-2 Fault Messages (Alphabetical by Keypad Text)			
Fault	Fault #	Cause	What to do
Calibration	2281	Measured offset of output phase current measurement or difference between output phase U2 and W2 current measurement is too great (the values are updated during current calibration).	Try performing the current calibration again (select Current measurement calibration at parameter 99.13). If the fault persists, contact your local ABB representative.
Overcurrent	2310	Output current has exceeded internal fault limit.	<p>Check motor load.</p> <p>Check acceleration times in parameter group 23 Speed reference ramp (speed control), 26 Torque reference chain (torque control) or 28 Frequency reference chain (frequency control). Also check parameters 46.01 Speed scaling, 46.02 Frequency scaling and 46.03 Torque scaling.</p> <p>Check motor and motor cable (including phasing and delta/star connection).</p> <p>Check there are no contactors opening and closing in motor cable.</p> <p>Check that the start-up data in parameter group 99 corresponds to the motor rating plate.</p> <p>Check that there are no power factor correction capacitors or surge absorbers in motor cable.</p> <p>Check encoder cable (including phasing).</p>
Earth leakage <small>Programmable fault: 31.20 Earth fault</small>	2330	Drive has detected load unbalance typically due to earth fault in motor or motor cable.	<p>Check there are no power factor correction capacitors or surge absorbers in motor cable.</p> <p>Check for an earth fault in motor or motor cables by measuring the insulation resistances of motor and motor cable.</p> <p>Try running the motor in scalar control mode if allowed. (See parameter 99.04 Motor control mode.)</p> <p>If no earth fault can be detected, contact your local ABB representative.</p>
Short circuit	2340	Short-circuit in motor cable(s) or motor	<p>Check motor and motor cable for cabling errors.</p> <p>Check there are no power factor correction capacitors or surge absorbers in motor cable.</p> <p>After correcting the cause of the fault, reboot the control unit (using parameter 96.08 Control board boot) or by cycling power.</p>
IGBT overload	2381	Excessive IGBT junction to case temperature. This fault protects the IGBT(s) and can be activated by a short circuit in the motor cable.	<p>Check motor cable.</p> <p>Check ambient conditions.</p> <p>Check air flow and fan operation.</p> <p>Check heatsink fins for dust pick-up.</p> <p>Check motor power against drive power.</p>
Input phase loss <small>Programmable fault: 31.21 Supply phase loss</small>	3130	Intermediate circuit DC voltage is oscillating due to missing input power line phase or blown fuse.	<p>Check input power line fuses.</p> <p>Check for loose power cable connections.</p> <p>Check for input power supply imbalance.</p>
Charge relay lost	3180	No acknowledgement received from charge relay.	Contact your local ABB representative.
Cross connection <small>Programmable fault: 31.23 Cross connection</small>	3181	Incorrect input power and motor cable connection (i.e. input power cable is connected to drive motor connection).	Check input power connections.

Table 13-2 Fault Messages (Alphabetical by Keypad Text)

Fault	Fault #	Cause	What to do
DC link overvoltage	3210	Excessive intermediate circuit DC voltage.	<p>Check that overvoltage control is on (parameter 30.30 Overvoltage control).</p> <p>Check that the supply voltage matches the nominal input voltage of the drive.</p> <p>Check the supply line for static or transient overvoltage.</p> <p>Check brake chopper and resistor (if present).</p> <p>Check deceleration time.</p> <p>Use coast-to-stop function (if applicable).</p> <p>Retrofit drive with brake chopper and brake resistor.</p> <p>Check parameter 90.42 Motor speed filter time is programmed to 30m seconds.</p> <p>Check the speed loop tuning parameters in group 25, if the setting are to dynamic this could cause the drive to fault.</p> <p>The drive can trip on this fault if the Autophasing time and level is not high enough for the application, if the Autophasing levels are programmed to low the fan will not come to a full stop before the motor starts and this will could cause the drive to fault.</p>
DC link undervoltage	3220	Intermediate circuit DC voltage is not sufficient because of a missing supply phase, blown fuse or fault in the rectifier bridge.	Check supply cabling, fuses and switchgear.
Standby timeout	3280	Automatic restart failed (see section Automatic restart).	Check the condition of the supply (voltage, cabling, fuses, switchgear).
DC voltage difference	3291	Difference in DC voltages between parallel-connected inverter modules.	Contact your local ABB representative.
Output phase loss Programmable fault: 31.19 Motor phase loss	3381	Motor circuit fault due to missing motor connection (all three phases are not connected).	Connect motor cable.
Autophasing	3385	Autophasing routine (see section Autophasing has failed).	<p>Try other autophasing modes (see parameter 21.13 Autophasing mode) if possible.</p> <p>Check that the motor ID run has been successfully completed.</p> <p>Clear parameter 98.15 Position offset user.</p> <p>Check that the encoder is not slipping on the motor shaft.</p> <p>Check that the motor is not already turning when the autophasing routine starts.</p> <p>Check the setting of parameter 99.03 Motor type.</p>
Motor cable overload	4000	Calculated motor cable temperature has exceeded warning limit.	<p>Check the settings of parameters 35.61 and 35.62.</p> <p>Check the dimensioning of the motor cable in regard to required load.</p>
IGBT overtemperature	4210	Estimated drive IGBT temperature is excessive.	<p>Check ambient conditions.</p> <p>Check air flow and fan operation.</p> <p>Check heatsink fins for dust pick-up.</p> <p>Check motor power against drive power.</p>
Cooling	4290	Drive module temperature is excessive.	<p>Check ambient temperature. If it exceeds 40°C (104°F), ensure that load current does not exceed derated load capacity of drive. See appropriate Hardware Manual.</p> <p>Check drive module cooling air flow and fan operation.</p> <p>Check inside of cabinet and heatsink of drive module for dust pick-up. Clean whenever necessary.</p>
IGBT temperature	42F1	Drive IGBT temperature is excessive.	<p>Check ambient conditions.</p> <p>Check air flow and fan operation.</p> <p>Check heatsink fins for dust pick-up.</p> <p>Check motor power against drive power.</p>

Table 13-2 Fault Messages (Alphabetical by Keypad Text)

Fault	Fault #	Cause	What to do
Excess temperature	4310	Power unit module temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
Excess temperature difference	4380	High temperature difference between the IGBTs of different phases.	Check the motor cabling. Check cooling of drive module(s).
External temperature 1 <small>(Editable message text)</small>	4981	Measured temperature 1 has exceeded fault limit.	Check the value of parameter 35.02 Measured temperature 1. Check the cooling of the motor (or other equipment whose temperature is being measured). Check the value of parameter 35.12 Temperature 1 fault limit.
External temperature 2 <small>(Editable message text)</small>	4982	Measured temperature 2 has exceeded fault limit.	Check the value of parameter 35.03 Measured temperature 2. Check the cooling of the motor (or other equipment whose temperature is being measured). Check the value of parameter 35.22 Temperature 2 fault limit.
Fan	5080	Cooling fan stuck or disconnected.	Check fan operation and connection. Replace fan if faulty.
Auxiliary fan broken	5081	An auxiliary cooling fan (connected to the fan connectors on the control unit) is stuck or disconnected.	Check auxiliary fan(s) and connection(s). Replace fan if faulty. Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power.
STO hardware failure	5090	Safe torque off hardware failure.	Contact your local ABB representative.
Safe torque off <small>Programmable fault: 31.22 STO indication run/stop</small>	5091	Safe torque off function is active, i.e. safety circuit signal(s) connected to connector XSTO is broken during start or run.	Check safe torque off circuit connections. For more information, see appropriate drive hardware manual and description of parameter 31.22 STO indication run/stop.
PU logic error	5092	Power unit memory has cleared.	Cycle the power to the drive. If the control unit is externally powered, also reboot the control unit (using parameter 96.08 Control board boot) or by cycling its power. If the problem persists, contact your local ABB representative.
Rating ID mismatch	5093	The hardware of the drive does not match the information stored in the memory unit. This may occur eg. after a firmware update or memory unit replacement.	Cycle the power to the drive.
PU communication	5681	The way the control unit is powered does not correspond to parameter setting.	Check setting of 95.04 Control board supply.
		Communication errors detected between the drive control unit and the power unit.	Check the connection between the control unit and the power unit.
Power unit lost	5682	Connection between the drive control unit and the power unit is lost.	Check the connection between the control unit and the power unit.
PU communication internal	5690	Internal communication error.	Contact your local ABB representative.

Table 13-2 Fault Messages (Alphabetical by Keypad Text)			
Fault	Fault #	Cause	What to do
Measurement circuit ADC	5691	Measurement circuit fault.	Contact your local ABB representative.
PU board powerfail	5692	Power unit power supply failure.	Contact your local ABB representative.
Measurement circuit DFF	5693	Measurement circuit fault.	Contact your local ABB representative.
PU communication configuration	5694	Version check cannot find a matching power unit FPGA logic.	Contact your local ABB representative.
Reduced run	5695	Number of inverter modules detected does not match the value of parameter 95.13 Reduced run mode.	Check that the value of 95.13 Reduced run mode corresponds to the number of inverter modules present. Check that the modules present are powered from the DC bus and connected by fiber optic cables to the BCU control unit. If all modules of the inverter unit are in fact available (eg. maintenance work has been completed), check that parameter 95.13 is set to 0 (reduced run function disabled).
PU state feedback	5696	State feedback from output phases does not match control signals.	Contact your local ABB representative.
Charging feedback	5697	Charging feedback signal missing.	Check the feedback signal coming from the charging system.
Unknown power unit fault	5698	Unidentified power unit logic fault.	Check power unit logic and firmware compatibility. Contact your local ABB representative.
Internal SW error	6180	Internal error.	Contact your local ABB representative. Quote the auxiliary code (check the event details in the event log).
FPGA version incompatible	6181	Firmware and FPGA file version in the power unit are incompatible.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
FBA A mapping file	6306	Fieldbus adapter A mapping file read error.	Contact your local ABB representative.
FBA B mapping file	6307	Fieldbus adapter B mapping file read error.	Contact your local ABB representative.
Task overload	6481	Internal fault.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
Stack overflow	6487	Internal fault.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
Internal file load	64A1	File read error.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
Internal record load	64A2	Internal record load error.	Contact your local ABB representative.
Application loading	64A3	Application file incompatible or corrupted.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
Memory unit detached	64B0	The memory unit was detached when the control unit was powered.	Switch off the power to the control unit and reinstall the memory unit. In case the memory unit was not actually removed when the fault occurred, check that the memory unit is properly inserted into its connector and its mounting screw is tight. Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.

Table 13-2 Fault Messages (Alphabetical by Keypad Text)

Fault	Fault #	Cause	What to do
Internal SSW fault	64B1	Internal fault.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
User set fault	64B2	Loading of user parameter set failed because <ul style="list-style-type: none"> • requested set does not exist • set is not compatible with control program • drive was switched off during loading. 	Ensure that a valid user parameter set exists. Reload if uncertain.
Kernel overload	64E1	Operating system error.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
Parameter system	6581	Parameter load or save failed.	Try forcing a save using parameter 96.07 Parameter save manually. Retry.
FBA A parameter conflict	65A1	The drive does not have a functionality requested by PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups 50 Fieldbus adapter (FBA) and 51 FBA A settings.
FBA B parameter conflict	65A2	The drive does not have a functionality requested by PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups 50 Fieldbus adapter (FBA) and 54 FBA B settings.
Text data overflow	6881	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.
Text 32-bit table overflow	6882	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.
Text 64-bit table overflow	6883	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.
Text file overflow	6885	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.
Option module comm loss	7080	Communication between drive and an option module is lost.	Check that all option modules are properly seated in their slots. Check that all option modules or slot connectors are not damaged. To pinpoint the problem, try installing the modules into different slots one at a time.
Panel port communication <small>Programmable fault: 49.05 Communication loss action</small>	7081	Control panel or PC tool selected as active control location for drive has ceased communicating.	Check PC tool or control panel connection. Check control panel connector. Disconnect and reconnect the control panel.
Ext I/O comm loss	7082	The I/O extension module types specified by parameters do not match the detected configuration.	Check the event log for an auxiliary code (format XXYY YYYY). "XX" specifies the number of the I/O extension module (01: parameter group 14 I/O extension module 1, 02: 15 I/O extension module 2, 03: 16 I/O extension module 3). "YY YYYY" indicates the problem (see actions for each code below).
	00 0001	Communication with module failed.	Check that the module is properly seated in its slot. Check that the module and the slot connector is not damaged. Try installing the module into another slot.
	00 0002	Module not found.	Check the type and location settings of the modules (parameters 14.01/14.02, 15.01/15.02 or 16.01/16.02).
	00 0003	Configuration of module failed.	Check that the module is properly seated in its slot. Check that the module and the slot connector is not damaged. Try installing the module into another slot.
	00 0004	Configuration of module failed.	

Table 13-2 Fault Messages (Alphabetical by Keypad Text)

Fault	Fault #	Cause	What to do
Motor stall <small>Programmable fault: 31.24 Stall function</small>	7121	Motor is operating in stall region because of e.g. excessive load or insufficient motor power.	Check motor load and drive ratings. Check fault function parameters.
Brake resistor	7181	Brake resistor broken or not connected.	Check that a brake resistor has been connected. Check the condition of the brake resistor. Check the dimensioning of the brake resistor.
BR excess temperature	7183	Brake resistor temperature has exceeded fault limit defined by parameter 43.11 Brake resistor fault limit.	Stop drive. Let resistor cool down. Check resistor overload protection function settings (parameter group 43 Brake chopper). Check fault limit setting, parameter 43.11 Brake resistor fault limit. Check that braking cycle meets allowed limits.
Brake resistor wiring	7184	Brake resistor short circuit or brake chopper control fault.	Check brake chopper and brake resistor connection. Ensure brake resistor is not damaged. After correcting the cause of the fault, reboot the control unit (using parameter 96.08 Control board boot) or by cycling power.
BC short circuit	7191	Short circuit in brake chopper IGBT.	Ensure brake resistor is connected and not damaged. Check the electrical specifications of the brake resistor against the Hardware manual. Replace brake chopper (if replaceable). After correcting the cause of the fault, reboot the control unit (using parameter 96.08 Control board boot) or by cycling power.
BC IGBT excess temperature	7192	Brake chopper IGBT temperature has exceeded internal fault limit.	Let chopper cool down. Check for excessive ambient temperature. Check for cooling fan failure. Check for obstructions in the air flow. Check the dimensioning and cooling of the cabinet. Check resistor overload protection function settings (parameter group 43 Brake chopper). Check that braking cycle meets allowed limits. Check that drive supply AC voltage is not excessive.
Mechanical brake closing failed <small>Programmable fault: 44.17 Brake fault function</small>	71A2	Mechanical brake control fault. Activated eg. if brake acknowledgement is not as expected during brake closing.	Check mechanical brake connection. Check mechanical brake settings in parameter group 44 Mechanical brake control. Check that acknowledgement signal matches actual status of brake.
Mechanical brake opening failed <small>Programmable fault: 44.17 Brake fault function</small>	71A3	Mechanical brake control fault. Activated eg. if brake acknowledgement is not as expected during brake opening.	Check mechanical brake connection. Check mechanical brake settings in parameter group 44 Mechanical brake control. Check that acknowledgement signal matches actual status of brake.
Mechanical brake opening not allowed <small>Programmable fault: 44.17 Brake fault function</small>	71A5	Open conditions of mechanical brake cannot be fulfilled (for example, brake has been prevented from opening by parameter 44.11 Keep brake closed).	Check mechanical brake settings in parameter group 44 Mechanical brake control (especially 44.11 Keep brake closed). Check that acknowledgement signal (if used) matches actual status of brake.
Motor fan <small>Programmable fault: 35.106 DOL starter event type</small>	71B1	No feedback received from external fan.	Check external fan (or other equipment controlled) by the logic. Check settings of parameters 35.100...35.106.
Motor speed feedback <small>Programmable fault: 90.45 Motor feedback fault</small>	7301	No motor speed feedback received.	See A7B0 Motor speed feedback.

Table 13-2 Fault Messages (Alphabetical by Keypad Text)

Fault	Fault #	Cause	What to do
Overspeed	7310	Motor is turning faster than highest allowed speed due to incorrectly set minimum/maximum speed, insufficient braking torque or changes in load when using torque reference.	Check minimum/maximum speed settings, parameters 30.11 Minimum speed and 30.12 Maximum speed. Check adequacy of motor braking torque. Check applicability of torque control. Check need for brake chopper and resistor(s).
Line side converter faulted	7358	The supply unit has tripped on a fault.	If using a control panel or the Drive composer tool, connect to the supply unit to read the fault code. Refer to the firmware manual of the supply unit for instructions related to the code.
Encoder internal	7380	Internal fault.	Contact your local ABB representative.
Encoder 1	7381	Encoder feedback fault.	See A7E1 Encoder 1.
Speed feedback configuration	73A0	Speed feedback configuration incorrect.	See A797 Speed feedback configuration.
Load position feedback	73A1	No load feedback received.	Check the event log for an auxiliary code (format XXYY ZZZZ). "XX" specifies the number of the encoder interface module (01: 91.11/91.12, 02: 91.13/91.14), "YY" specifies the encoder (01: 92 Encoder 1 configuration, 02: 93 Encoder 2 configuration). "ZZZZ" indicates the problem (see actions for each code below).
	0001	Load gear definition invalid or outside limits.	Check load gear settings (90.53 and 90.54).
	0002	Feed constant definition invalid or outside limits.	Check feed constant settings (90.63 and 90.64).
	0003	Motor/load gear definition invalid or outside limits.	Check motor/load gear settings (90.61 and 90.62).
	0004	Encoder not configured.	Check encoder settings (92 Encoder 1 configuration or 93 Encoder 2 configuration). Use parameter 91.10 Encoder parameter refresh) to validate any changes in the settings.
	0005	Encoder stopped working.	Check encoder status.
Emergency ramp failed	73B0	Emergency stop did not finish within expected time.	Check the settings of parameters 31.32 Emergency ramp supervision and 31.33 Emergency ramp supervision delay. Check the predefined ramp times (23.11...23.19 for mode Off1, 23.23 for mode Off3).
FBA A communication <small>Programmable fault: 50.02 FBA A comm loss func</small>	7510	Cyclical communication between drive and fieldbus adapter module A or between PLC and fieldbus adapter module A is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter groups 50 Fieldbus adapter (FBA), 51 FBA A settings, 52 FBA A data in and 53 FBA A data out. Check cable connections. Check if communication master is able to communicate.
FBA B communication <small>Programmable fault: 50.32 FBA B comm loss func</small>	7520	Cyclical communication between drive and fieldbus adapter module B or between PLC and fieldbus adapter module B is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter group 50 Fieldbus adapter (FBA). Check cable connections. Check if communication master is able to communicate.
FA2FA DDCS com loss <small>Programmable fault: 60.79 INU-LSU com loss ctrl</small>	7580	DDCS (fiber optic) communication between converters (for example, the inverter unit and the supply unit) is lost.	Check status of other converter (parameters 06.36 and 06.39). Check settings of parameter group 60 DDCS communication. Check the corresponding settings in the control program of the other converter. Check cable connections. If necessary, replace cables.

Table 13-2 Fault Messages (Alphabetical by Keypad Text)

Fault	Fault #	Cause	What to do
DDCS controller comm loss Programmable fault: 60.59 DDCS controller comm loss function	7581	DDCS (fiber optic) communication between drive and external controller is lost.	Check status of controller. See user documentation of controller. Check settings of parameter group 60 DDCS communication. Check cable connections. If necessary, replace cables.
MF comm loss Programmable fault: 60.09 M/F comm loss function	7582	Master/follower communication is lost.	Check status of other drives on the master/follower link. Check settings of parameter group 60 DDCS communication. Check cable connections. If necessary, replace cables.
Line side unit faulted	7583	The supply unit (or other converter) connected to the inverter unit has generated a fault.	Check fault status of supply unit (or other converter). Refer to the firmware manual of the supply unit.
AI supervision Programmable fault: 12.03 AI supervision function	80A0	An analog signal is outside the limits specified for the analog input.	Check signal level at the analog input. Check the wiring connected to the input. Check the minimum and maximum limits of the input in parameter group 12 Standard AI.
Signal supervision (Editable message text) Programmable fault: 32.06 Supervision 1 action 32.16 Supervision 2 action 32.26 Supervision 3 action	80B0	Fault generated by a signal supervision function.	Check the source of the fault (parameter 32.07, 32.17 or 32.28).
External fault 1 (Editable message text) Programmable fault: 31.01 External event 1 source 31.02 External event 1 type	9081	Fault in external device 1.	Check the external device. Check setting of parameter 31.01 External event 1 source.
External fault 2 (Editable message text) Programmable fault: 31.03 External event 2 source 31.04 External event 2 type	9082	Fault in external device 2.	Check the external device. Check setting of parameter 31.03 External event 2 source.
External fault 3 (Editable message text) Programmable fault: 31.05 External event 3 source 31.06 External event 3 type	9083	Fault in external device 3.	Check the external device. Check setting of parameter 31.05 External event 3 source.
External fault 4 (Editable message text) Programmable fault: 31.07 External event 4 source 31.08 External event 4 type	9084	Fault in external device 4.	Check the external device. Check setting of parameter 31.07 External event 4 source.
External fault 5 (Editable message text) Programmable fault: 31.09 External event 5 source 31.10 External event 5 type	9085	Fault in external device 5.	Check the external device. Check setting of parameter 31.09 External event 5 source.
Safe torque off 1	FA81	Safe torque off function is active, ie. STO circuit 1 is broken.	Check safety circuit connections. For more information, see appropriate drive hardware manual and description of parameter 31.22 STO indication run/stop.
Safe torque off 2	FA82	Safe torque off function is active, ie. STO circuit 2 is broken.	

Table 13-2 Fault Messages (Alphabetical by Keypad Text)

Fault	Fault #	Cause	What to do
ID run	FF61	Motor ID run was not completed successfully.	Check the nominal motor values in parameter group 99 Motor data. Check that no external control system is connected to the drive. Cycle the power to the drive (and its control unit, if powered separately). Check that the motor shaft is not locked. Check the event log for an auxiliary code. The second number of the code indicates the problem (see actions for each code below).
	0001	Maximum current limit too low.	Check settings of parameters 99.06 Motor nominal current and 30.17 Maximum current. Make sure that 30.17 > 99.06. Check that the drive is dimensioned correctly according to the motor.
	0002	Maximum speed limit or calculated field weakening point too low.	Check settings of parameters <ul style="list-style-type: none"> • 30.11 Minimum speed • 30.12 Maximum speed • 99.07 Motor nominal voltage • 99.08 Motor nominal frequency • 99.09 Motor nominal speed. Make sure that <ul style="list-style-type: none"> • 30.12 > (0.55 × 99.09) > (0.50 × synchronous speed) • 30.11 < 0, and • supply voltage > (0.66 × 99.07).
	0003	Maximum torque limit too low.	Check settings of parameter 99.12 Motor nominal torque, and the torque limits in group 30 Limits. Make sure that the maximum torque limit in force is greater than 100%.
	0004	Current measurement calibration did not finish within reasonable time.	Contact your local ABB representative.
	0005 - 0008	Internal error.	Contact your local ABB representative.
	0009	(Asynchronous motors only) Acceleration did not finish within reasonable time.	Contact your local ABB representative.
	000A	(Asynchronous motors only) Deceleration did not finish within reasonable time.	Contact your local ABB representative.
	000B	(Asynchronous motors only) Speed dropped to zero during ID run.	Contact your local ABB representative.
	000C	(Permanent magnet motors only) First acceleration did not finish within reasonable time.	Contact your local ABB representative.
	000D	(Permanent magnet motors only) Second acceleration did not finish within reasonable time.	Contact your local ABB representative.
	000E - 0010	Internal error.	Contact your local ABB representative.

Table 13-2 Fault Messages (Alphabetical by Keypad Text)			
Fault	Fault #	Cause	What to do
FB A force trip	FF81	A fault trip command has been received through fieldbus adapter A.	Check the fault information provided by the PLC.
FB B force trip	FF82	A fault trip command has been received through fieldbus adapter B.	Check the fault information provided by the PLC.

Chapter A

Technical Specifications

A.1 ACS880+N5350 Technical Data

Table A-1 ACS880+N5350 Technical Data

Electrical Power Network Specification	
Voltage (U_1)	ACS880-01-xxxx-2 units: 208 ... 240V AC 3-phase +10%...-15%
	ACS880-01-xxxx-3 units: 380 ... 415V AC 3-phase +10%...-15%
	ACS880-01-xxxx-5 units: 380 ... 500V AC 3-phase +10%...-15%
	ACS880-01-xxxx-7 units: 525 ... 690V AC 3-phase +10%...-15%
Network Type	TN (grounded) and IT (ungrounded) systems
Rated Conditional Short-Circuit Current (IEC 61439-1)	65 kA when protected by fuses given in the fuse tables
Short-Circuit Current Protection (UL 508C, CSA C22.2 No. 14-05)	US and Canada: The drive is suitable for use on a circuit capable of delivering not more than 100kA symmetrical amperes (rms) at 600V maximum when protected by fuses given in the fuse table
Frequency	47 to 63 Hz, maximum rate of change 17%/s
Imbalance	Max. \pm 3% of nominal phase to phase input voltage
Fundamental Power Factor (cos ϕ_1)	0.98 (at nominal load)

Motor Connection Data	
Motor Types	Permanent magnet synchronous cooling tower direct drive motors
Voltage (U_2)	0 to U_1 , 3-phase symmetrical, U_{max} at the field weakening point
Frequency	0...500 Hz
Current	See Chapter 3 Ratings.
Switching Frequency	2.7 kHz (typically)
Maximum Recommended Motor Cable Length	For ACS880-01-xxxx-2, ACS880-01-xxxx-3 and ACS880-01-xxxx-5 frames R1 to R3 and for types ACS880-01-07A3-7, ACS880-01-09A8-7, ACS880-01-14A2-7 and ACS880-01-018A-7: 150m (492 ft)
	For ACS880-01-xxxx-2, ACS880-01-xxxx-3 and ACS880-01-xxxx-5 frames R4 to R9 and for types from ACS880-01-022A-7 to ACS880-01-271A-7: 300m (984 ft)
	Note: With motor cables longer than 150m (492 ft) the EMC Directive requirements may not be fulfilled.

Control Unit (ZCU-12) Connection Data	
Power Supply (XPOW)	24V (\pm 10%) DC, 2A
	Supplied from the power unit of the drive, or from an external power supply through connector XPOW (pitch 5mm, wire size 2.5mm ²)
Relay Outputs RO1...RO3 (XRO1...XRO3)	Connector pitch 5 mm, wire size 2.5mm ²
	250 VAC / 30 VDC, 2A
	Protected by varistors
+24V Output (XD24:2 and XD24:4)	Connector pitch 5 mm, wire size 2.5mm ²
	Total load capacity of these outputs is 4.8W (200mA / 24V) minus the power taken by DIO1 and DIO2

Table A-1 ACS880+N5350 Technical Data Continued


Digital Inputs DI1...DI6 (XDI:1...XDI:6)	Connector pitch 5 mm, wire size 2.5mm ²
	24V logic levels: "0" < 5V, "1" > 15V
	R_{in} : 2.0 kohm
	Input type: NPN/PNP (DI1...DI5), NPN (DI6)
	Hardware filtering: 0.04ms, digital filtering up to 8ms
	DI6 (XDI:6) can alternatively be used as an input for PTC sensors
	"0" > 4kohm, "1" < 1.5kohm
I_{max} : 15mA (for DI6 5mA)	
Start Interlock Input DIIL (XD24:1)	Connector pitch 5mm, wire size 2.5mm ²
	24V logic levels: "0" < 5V, "1" > 15V
	R_{in} : 2.0 kohm
	Input type: NPN/PNP
Digital Inputs/Outputs DIO1 and DIO2 (XDIO:1 and XDIO:2) Input/output selection by parameters. DIO1 can be configured as a frequency input (0...16 kHz with hardware filtering of 4 microseconds) for 24V level square wave signal (sinusoidal or other wave form cannot be used). DIO2 can be configured as a 24V level square wave frequency output. See the firmware manual, parameter group 11.	Connector pitch 5mm, wire size 2.5mm ²
	<u>As inputs:</u> 24V logic levels: "0" < 5V, "1" > 15V
	R_{in} : 2.0 kohm
	Filtering: 0.25ms
	<u>As outputs:</u> Total output current from +24VD is limited to 200mA.
	Figure A-1
	
Reference Voltage for Analog Inputs +VREF and -VREF (XAI:4...XAI:2)	Connector pitch 5mm, wire size 2.5mm ²
	10V ±1% and -10V ±1%, R_{load} 1...10kohm
Analog Inputs AI1 and AI2 (XAI:4...XAI:7) Current/voltage input selection by jumpers.	Connector pitch 5mm, wire size 2.5mm ²
	Current input: -20...20mA, R_{in} : 100ohm
	Voltage input: -10...10V, R_{in} : > 200kohm
	Differential inputs, common range ±30V
	Sampling interval per channel: 0.25ms
	Hardware filtering: 0.25ms, adjustable digital filtering up to 8ms
	Resolution: 11 bit + sign bit
	Inaccuracy: 1% of full scale range

Table A-1 ACS880+N5350 Technical Data Continued

Analog Outputs AO1 and AO2 (XAO)	Connector pitch 5mm, wire size 2.5mm ²
	0...20mA, $R_{load} < 500\text{ohm}$
	Frequency range: 0...300Hz
	Resolution: 11 bit + sign bit
	Inaccuracy: 2% of full scale range
Drive to Drive Link (XD2D)	Connector pitch 5mm, wire size 2.5mm ²
	Physical layer: RS-485
	Termination by switch
Safe Torque Off Connection (XSTO)	Connector pitch 5mm, wire size 2.5mm ²
	Current consumption per channel: 55mA (continuous)
	For the drive to start, both connections must be closed (OUT1 to IN1 and IN2).
Control Panel / PC Connection	Connector: RJ-45
	Cable length < 3m

The terminals on the board fulfil the Protective Extra Low Voltage (PELV) requirements. The PELV requirements of a relay output are not fulfilled if a voltage higher than 48V is connected to the relay output.

Figure A-2 Ground Isolation Diagram

Ground isolation diagram




Table A-1 ACS880+N5350 Technical Data Continued

Efficiency	
	Approximately 98% at nominal power level

Protection Classes	
Degree of Protection (IEC/EN 60529)	IP21, IP55
Enclosure Types (UL508C)	UL Type 1, UL Type 12. For indoor use only
Overvoltage Category (IEC 60664-1)	III
Protective Class (IEC/EN 61800-5-1)	I

Ambient Conditions			
Environmental limits for the drive are given below. The drive is to be used in a heated, indoor, controlled environment.			
	Operation Installed for Stationary Use	Storage in the Protective Package	Transportation in the Protective Package
Installation Site Altitude	1. 0 to 4000m (13123 ft) above sea level 2. 0 to 2000m (6561 ft) above sea level Above 1000m [3281 ft]	-	-
	1. For neutral-grounded TN and TT systems and non-corner grounded IT systems 2. For corner-grounded TN, TT and IT systems		
Air Temperature	-15 to +55°C (5 to 131°F). No frost allowed. See Chapter 3 Ratings.	-40 to +70°C (-40 to +158°F)	-40 to +70°C (-40 to +158°F)
Relative Humidity	5 to 95%	Max. 95%	Max. 95%
	No condensation allowed. Maximum allowed relative humidity is 60% in the presence of corrosive gases.		
Contamination Levels (IEC 60721-3-3, IEC 60721-3-2, IEC 60721-3-1)	No conductive dust allowed.		
	Chemical gases: Class 3C2 Solid particles: Class 3S2	Chemical gases: Class 1C2 Solid particles: Class 1S3	Chemical gases: Class 2C2 Solid particles: Class 2S2
Atmospheric Pressure	70 to 106 kPa 0.7 to 1.05 atmospheres	70 to 106 kPa 0.7 to 1.05 atmospheres	60 to 106 kPa 0.6 to 1.05 atmospheres
Vibration (IEC 60068-2)	Max. 1mm (0.04in.) (5 to 13.2 Hz), max. 7m/s ² (23ft/s ²) (13.2 to 100 Hz) sinusoidal	Max. 1mm (0.04in.) (5 to 13.2 Hz), max. 7m/s ² (23ft/s ²) (13.2 to 100 Hz) sinusoidal	Max. 3.5mm (0.14in.) (2 to 9 Hz), max. 15m/s ² (49ft/s ²) (9 to 200 Hz) sinusoidal
Shock (IEC 60068-2-27)	Not allowed	Max. 100m/s ² (330 ft./s ²), 11ms	Max. 100m/s ² (330 ft./s ²), 11ms
Free Fall	Not allowed	100mm (4 in.) for weight over 100 kg (220 lb)	100mm (4 in.) for weight over 100 kg (220 lb)

Table A-1 ACS880+N5350 Technical Data Continued

Materials	
Drive Enclosure	• PC/ABS 3 mm, color NCS1502-Y (RAL 9002 / PMS 1C Cool Grey) and RAL 9017
	• PC+10%GF 3.0mm, Color RAL 9017 (in frames R1 to R3 only)
	• Hot-dip zinc coated steel sheet 1.5 to 2.5mm, thickness of coating 100 micrometers, color NCS1502-Y
Package	Plywood and cardboard. Foam cushions PP-E, bands PP.
Disposal	The main parts of the drive can be recycled to preserve natural resources and energy. Product parts and materials should be dismantled and separated.
	Generally all metals, such as steel, aluminum, copper and its alloys, and precious metals can be recycled as material. Plastics, rubber, cardboard and other packaging material can be used in energy recovery. Printed circuit boards and DC capacitors (C1-1 to C1-x) need selective treatment according to IEC 62635 guidelines. To aid recycling, plastic parts are marked with an appropriate identification code.
	Contact your local ABB distributor for further information on environmental aspects and recycling instructions for professional recyclers. End of life treatment must follow international and local regulations.


A.2 Derating

A.2.1 Ambient Temperature Derating

IP21 (UL Type 1) drive types and other IP55 (UL Type 12) types than listed in the following subheadings

In the temperature range +40...55°C (+104...131°F), the rated output current is derated by 1% for every added 1°C (1.8°F). The output current can be calculated by multiplying the current given in the rating table by the derating factor (k):

Figure A-3



A.2.2 Altitude Derating

At altitudes from 1000 to 4000m (3300 to 13123 ft) above sea level, the continuous output currents given above must be derated 1% for every 100m (328ft). For a more accurate derating, use the DriveSize PC tool.

A.2.3 Low Noise Control Mode Derating

When low noise drive control mode is used, the motor and braking powers are derated. Contact ABB for more information.

Chapter B

Dimensions

B.1 Dimensions, Weights and Free Space Requirements

Table B-1

Frame	IP21					UL Type 1				
	H1	H2	W	D	Weight	H1	H2	W	D	Weight
	mm	mm	mm	mm	kg	in.	in.	in.	in.	lb
R1	405	370	155	226	6	15.94	14.57	6.10	8.89	13
R2	405	370	155	249	8	15.94	14.57	6.10	9.80	18
R3	471	420	172	261	10	18.54	16.54	6.77	10.28	22
R4	576	490	203	274	18.5	22.70	19.30	7.99	10.80	41
R5	730	596	203	274	23	28.74	23.46	7.99	10.79	51
R6	726	569	251	357	45	28.60	22.40	9.92	14.09	99
R7	880	600	284	365	55	34.70	23.60	11.22	14.37	121
R8	963	681	300	386	70	37.90	26.82	11.81	15.21	154
R9	955	680	380	413	98	37.59	26.77	14.96	16.27	216

H1 Height with cable entry box.

H2 Height without cable entry box.

H3 Height with hood.

W Width with cable entry box.

D Depth with cable entry box.

Note: For more information on dimensions, see Dimension drawings.

200mm (7.87 in.) free space is required at top of the drive.

300mm (11.81 in.) free space (when measured from the drive base without the cable entry box) is required at bottom of the drive.

Figure B-1 Frame R1 (IP21, UL Type 1)

Frame R1 (IP21, UL Type 1)




Figure B-2 Frame R2 (IP21, UL Type 1)

Frame R2 (IP21, UL Type 1)




Figure B-3 Frame R3 (IP21, UL Type 1)

Frame R3 (IP21, UL Type 1)




Figure B-4 Frame R4 (IP21, UL Type 1)

Frame R4 (IP21, UL Type 1)








PLATE HOLE $\phi 22$ [0.87] (3pcs.)
GROMMET UP TO $\phi 15$ [0.59] CABLE DIAMETER


PLATE HOLE $\phi 44$ [1.73] (3pcs.)
GROMMET UP TO $\phi 24$ [0.94] CABLE DIAMETER



3AUA0000098285

Figure B-5 Frame R5 (IP21, UL Type 1)

Frame R5 (IP21, UL Type 1)



3AUA0000097965

PLATE HOLE ϕ 29 [1.12] (2pcs.)
GROMMET UP TO ϕ 22 [0.87] CABLE DIAMETER

PLATE HOLE ϕ 51 [2.01] (3pcs.)
GROMMET UP TO ϕ 32 [1.26] CABLE DIAMETER






Figure B-7 Frame R7 (IP21, UL Type 1)


Frame R7 (IP21, UL Type 1)



3AUA0000073149

Figure B-8 Frame R8 (IP21, UL Type 1)

Frame R8 (IP21, UL Type 1)



Chapter C

CE Guidelines

This section provides general information regarding recommended methods of installation for CE compliance. It is not intended as an exhaustive guide to good practice and wiring techniques. It is assumed that the installer of the ACS880+N5350 is sufficiently qualified to perform the task, and is aware of local regulations and requirements. ABB products that meet the EMC directive requirements are indicated with a “CE” mark. A duly signed CE declaration of conformity is available from ABB.

C.1 Applicable Standards

The drive complies with the following standards. The compliance with the European Low Voltage Directive is verified according to standard EN61800-5-1.

Table C-1

EN 60204-1:2006 + A1 2009	Safety of machinery. Electrical equipment of machines. Part 1: General requirements. Provisions for compliance: The final assembler of the machine is responsible for installing - emergency-stop device - supply disconnecting device.
IEC/EN 60529:1991 + A1 2000	Degrees of protection provided by enclosures (IP code)
IEC 60664-1:2007	Insulation coordination for equipment within low-voltage systems. Part 1: Principles, requirements and tests.
EN 61800-3:2004	Adjustable speed electrical power drive systems. Part 3: EMC requirements and specific test methods
EN 61800-5-1:2007	Adjustable speed electrical power drive systems. Part 5-1: Safety requirements – electrical, thermal and energy
EN 61800-5-2:2007	Adjustable speed electrical power drive systems. Part 5-2: Safety requirements – Functional
UL 508C:2002	UL Standard for Safety, Power Conversion Equipment, third edition
NEMA 250:2008	Enclosures for Electrical Equipment (1000 Volts Maximum)
CSA C22.2 No. 14-10	Industrial control equipment
GOST R 51321-1:2007	Low-voltage switchgear and control gear assemblies. Part 1 - Requirements for type-tested and partially type-tested assemblies - General technical requirements and methods of tests

C.2 CE Marking

A CE mark is attached to the drive to verify that the drive follows the provisions of the European Low Voltage, EMC and RoHS Directives. The CE marking also verifies that the drive, in regard to its safety functions (such as Safe torque off), conforms with the Machinery Directive as a safety component.

C.2.1 Compliance with the European Low Voltage Directive

The compliance with the European Low Voltage Directive has been verified according to standards EN 60204-1 and EN61800-5-1.

C.2.2 Compliance with the European EMC Directive

The EMC Directive defines the requirements for immunity and emissions of electrical equipment used within the European Union. The EMC product standard (EN61800-3:2004) covers requirements stated for drives. See section Compliance with the EN61800-3:2004 below.

C.2.3 Compliance with the European RoHS Directive

The RoHS Directive defines the restriction of the use of certain hazardous substances in electrical and electronic equipment.

C.2.4 Compliance with the European Machinery Directive

The drive is an electronic product which is covered by the European Low Voltage Directive. However, the drive includes the Safe torque off function and can be equipped with other safety functions for machinery which, as safety components, are in the scope of the Machinery Directive. These functions of the drive comply with European harmonized standards such as EN 61800-5-2. The declaration of conformity is shown below.

Figure C-1 Declaration of Conformity

Declaration of Conformity



Declaration of Conformity

(According to Machinery Directive 2006/42/EC)

Manufacturer: ABB Oy, Drives
Address: Hiomotie 13, P.O Box 184, FIN-00381 Helsinki, Finland.

hereby declares that product

ACS880-01

with regard to the following safety functions

Safe torque off

Safe stop 1 (with option code +Q973)

Safe stop emergency (with option code +Q973)

Safely-limited speed (with option code +Q973)

Safe maximum speed (with option code +Q973)

Safe brake control (with option code +Q973)

fulfil all the relevant safety component requirements of EC Machinery Directive 2006/42/EC, when the listed safety functions are used for safety component functionality.

The following harmonized standards below were used:

EN 61800-5-2: 2007	Adjustable speed electrical power drive systems – Part 5-2: Safety requirements - Functional
EN 62061: 2005/ AC: 2010	Safety of machinery – Functional safety of safety-related electrical, electronic and programmable electronic control systems
EN ISO 13849-1: 2008/ AC: 2009	Safety of machinery – Safety-related parts of control systems. Part 1: General requirements
EN ISO 13849-2: 2008	Safety of machinery – Safety-related parts of the control systems. Part 2: Validation
EN 60204-1: 2006/ AC: 2010	Safety of machinery – Electrical equipment of machines – Part 1: General requirements

Other used standards:

IEC 61508 ed. 2: 2010	Functional safety of electrical / electronic / programmable electronic safety-related systems
-----------------------	---

The products referred in this Declaration of Conformity fulfil the relevant provisions of the Low Voltage Directive 2006/95/EC and EMC Directive 2004/108/EC. Declaration of conformity according to these directives is available from the manufacturer.



Declaration of Conformity

(According to Machinery Directive 2006/42/EC)

Person authorized to compile the technical file:

Name: Risto Mynttinen
Address: P.O. Box 184, FIN-00381 Helsinki, Finland

Helsinki, 29 Nov 2012

A handwritten signature in blue ink, appearing to read 'Mika Kulju', is written over a horizontal line.

Mika Kulju
Vice President
ABB Oy

C.3 Compliance with the EN 61800-3:2004

C.3.1 Definitions

EMC stands for Electromagnetic Compatibility. It is the ability of electrical/electronic equipment to operate without problems within an electromagnetic environment. Likewise, the equipment must not disturb or interfere with any other product or system within its locality.

First environment includes establishments connected to a low-voltage network which supplies buildings used for domestic purposes.

Second environment includes establishments connected to a network not supplying domestic premises.

Drive of category C2: drive of rated voltage less than 1000V and intended to be installed and started up only by a professional when used in the first environment.

Note: A professional is a person or organization having necessary skills in installing and/or starting up power drive systems, including their EMC aspects.

Drive of category C3: drive of rated voltage less than 1000V and intended for use in the second environment and not intended for use in the first environment.

Drive of category C4: drive of rated voltage equal to or above 1000V, or rated current equal to or above 400A, or intended for use in complex systems in the second environment.

C.3.2 Category C2

The drive complies with the standard with the following provisions:

1. The drive is equipped with EMC filter +E202.
2. The motor and control cables are selected as specified in the hardware manual.
3. The drive is installed according to the instructions given in the hardware manual.
4. Maximum motor cable length is 150 meters.

WARNING! **The drive may cause radio interference if used in residential or domestic environment. The user is required to take measures to prevent interference, in association to the requirements for the CE compliance listed above, if necessary.**

Note: Do not install a drive equipped with EMC filter +E202 on IT (ungrounded) systems. The supply network becomes connected to ground potential through the EMC filter capacitors which may cause danger or damage to the unit.

C.3.3 Category C3

The drive complies with the standard with the following provisions:

1. The drive is equipped with EMC filter +E200 or +E201.
2. The motor and control cables are selected as specified in the hardware manual.
3. The drive is installed according to the instructions given in the hardware manual.
4. Maximum motor cable length is 150 meters.


WARNING! **A drive of category C3 is not intended to be used on a low-voltage public network which supplies domestic premises. Radio frequency interference is expected if the drive is used on such a network.**

C.3.4 Category C4

If the provisions under Category C3 cannot be met, the requirements of the standard can be met as follows:

1. It is ensured that no excessive emission is propagated to neighboring low-voltage networks. In some cases, the inherent suppression in transformers and cables is sufficient. If in doubt, the supply transformer with static screening between the primary and secondary windings can be used.

Figure C-2



2. An EMC plan for preventing disturbances is drawn up for the installation. A template is available from the local ABB representative.
3. The motor and control cables are selected as specified in the hardware manual.
4. The drive is installed according to the instructions given in the hardware manual.

WARNING!

A drive of category C4 is not intended to be used on a low-voltage public network which supplies domestic premises. Radio frequency interference is expected if the drive is used on such a network.

C.4 UL Marking

cULus Listed UL Type 1 (IP21) drives:

- frames R1 to R3 of voltage range 208...240V
- frames R1 to R9 of voltage ranges 380...415V and 380...500V
- frames R5 to R9 of voltage range 525...600V

cULus Listed UL Type 12 (IP55) drives:

- frames R1 to R3 of voltage range 208...240V
- frames R1 to R5 of voltage ranges 380...415V and 380...500V
- frames R5 of voltage range 525...600V

The listing is pending for the other types. The approval is valid with rated voltages.

C.4.1 UL Checklist

- The drive is to be used in a heated, indoor controlled environment. The drive must be installed in clean air according to enclosure classification. Cooling air must be clean, free from corrosive materials and electrically conductive dust.
- The maximum ambient air temperature is 40°C (104°F) at rated current. The current is derated for 40 to 55°C (104 to 131°F).
- The drive is suitable for use in a circuit capable of delivering not more than 100,000 rms symmetrical amperes, 600 V maximum. The ampere rating is based on tests done according to UL508C.
- The cables located within the motor circuit must be rated for at least 75°C (167°F) in UL-compliant installations.
- The input cable must be protected with fuses. Circuit breakers must not be used without fuses in the USA. See hardware manual for suitable IEC (class aR) fuses and UL (class T) fuses. For suitable circuit breakers, contact your local ABB representative.
- For installation in the United States, branch circuit protection must be provided in accordance with the National Electrical Code (NEC) and any applicable local codes. To fulfill this requirement, use the UL classified fuses.
- For installation in Canada, branch circuit protection must be provided in accordance with the Canadian Electrical Code and any applicable provincial codes. To fulfill this requirement, use the UL classified fuses.
- The drive provides overload protection in accordance with the National Electrical Code (NEC).

C.4.2 CSA Marking

The drives of frame sizes R1 to R3 are CSA marked. The CSA marking is pending for the other frames. The approval is valid with rated voltages.

C.4.3 “C-tick” Marking

“C-tick” marking is required in Australia and New Zealand. A “C-tick” mark is attached to the 380...500V drives to verify compliance with the relevant standard (IEC 61800-3:2004), mandated by the Trans-Tasman Electromagnetic Compatibility Scheme. C-tick marking is pending for drives of voltage ranges 204...240V and 525...690V.

For fulfilling the requirements of the standard, see section Compliance with the EN61800-3:2004 in hardware manual.

C.5 GOST R Certificate of Conformity

The drive has been given a GOST R certificate of conformity.

C.6 Disclaimer

The manufacturer shall have no obligation hereunder with respect to any product which (i) has been improperly repaired or altered; (ii) has been subjected to misuse, negligence or accident; (iii) has been used in a manner contrary to the Manufacturer's instructions; or (iv) has failed as a result of ordinary wear and tear.

Appendix D


Mechanical Installation

This chapter gives a description of the mechanical installation of the drive.

D.1 Safety

WARNING: For frame sizes R6 to R9: Use the lifting eyes of the drive when you lift the drive. Do not tilt the drive. The drive is heavy and its center of gravity is high. An overturning drive can cause physical injury.

Figure D-1




D.2 Examining the Installation Site

The drive must be installed in an upright position with the cooling section against a wall. All IP21 (UL Type 1) and IP55 drives and UL Type 12 drives of frames R1 to R3 can be installed tightly side by side. For UL Type 12 drives of frames R4 to R9, leave 100mm (4 in) between the hoods.

Make sure that the installation site agrees with these requirements:

- The installation site has sufficient ventilation to prevent overheating of the drive. See section Losses, cooling data and noise.
- The operation conditions of the drive agree with the specifications in section Ambient conditions.
- The wall is vertical, not flammable and strong enough to hold the weight of the drive.
- The material below the installation is not flammable.
- There is enough free space above and below the drive for cooling air flow, service and maintenance. There is enough free space in front of the drive for operation, service and maintenance.

Figure D-2



D.3 Necessary Tools

- Drill and drill bits
- Screwdriver and/or wrench with bits. The drive cover has Torx screws.

D.4 Moving the Drive

Move the transport package by pallet truck to the installation site.

D.5 Unpacking and Examining the Delivery (Frames R1 to R5)

This illustration shows the layout of the transport package. Examine that all items are present and there are no signs of damage. Read the data on the type designation label of the drive to make sure that the drive is of the correct type.

Figure D-3




Table D-1

Item	Description	Item	Description
1	Drive with factory installed options. Control cable grounding shelf. Romex connectors in IP21 frames R1 to R3 in a plastic bag inside the cable entry box.	5	Cardboard sleeve
2	Manuals CD	6 - 9	Cushions
3	Printed quick guides and manuals, multilingual residual voltage warning sticker	10	PET straps
4	Cardboard tray	11	Top cardboard cover
-	-	12	Hood included with option +B056


To unpack:

- Cut the straps (10).
- Remove the top cardboard cover (11) and cushions (6 - 9).
- Lift the cardboard sleeve (5).
- Lift the drive.

D.5.1 Frame R5 Cable Entry Box (IP21, UL Type 1)

This illustration shows the contents of the cable entry box package. The package also includes an assembly drawing which shows how to install the cable entry box to the drive module frame.

Figure D-4



D.6 Unpacking and Examining the Delivery (Frames R6 to R9)

This illustration shows the layout of the transport package. Examine that all items are present and there are no signs of damage. Read the data on the type designation label of the drive to make sure that the drive is of the correct type.

Figure D-5




Table D-2

Item	Description	Item	Description
1	Cable entry box. Power and control cable grounding shelves in a plastic bag, assembly drawing. Note: The cable entry box is mounted to a IP55 drive module frame at the factory.	5	Cardboard sleeve
2	Drive with factory installed options	6	Straps
3	Top cardboard cover	7	Printed quick guides and manuals CD and multilingual residual voltage warning sticker
4	Cushion	8	Pallet tray


To unpack:

- Cut the straps (6).
- Remove the top cardboard cover (3) and cushion (4).
- Lift the cardboard sleeve (5).
- Attach lifting hooks to the lifting eyes of the drive. Lift the drive with a hoist.

D.6.1 Frame R6 Cable Entry Box (IP21, UL Type 1)

This illustration shows the contents of the cable entry box package. The package also includes an assembly drawing which shows how to install the cable entry box to the drive module frame.


Figure D-6



D.6.2 Frame R7 Cable Entry Box (IP21, UL Type 1)

This illustration shows the contents of the cable entry box package. The package also includes an assembly drawing which shows how to install the cable entry box to the drive module frame.


Figure D-7



D.6.3 Frame R8 Cable Entry Box (IP21, UL Type 1)

This illustration shows the contents of the cable entry box package. There is also an assembly drawing which shows how to install the cable entry box to the drive module frame.


Figure D-8



D.6.4 Frame R9 Cable Entry Box (IP21, UL Type 1)

This illustration shows the contents of the cable entry box package. The package also includes an assembly drawing which shows how to install the cable entry box to the drive module frame.

Figure D-9




D.7 Installing the Drive

These instructions are for drives without vibration dampers. For drives with vibration dampers (option +C131), see the additional instructions (included with the dampers and on the manuals CD).

D.7.1 Frames R1 to R4

1. See the dimensions in chapter Dimension drawings. Mark the locations for the four mounting holes.
2. Drill the mounting holes.
3. Start the screws or bolts into the mounting holes.
4. Position the drive onto the screws on the wall.
5. Tighten the screws in the wall securely.

Figure D-10




D.7.2 Frames R4 and R7 (UL Type 12)

1. Position the drive onto the screws on the wall as shown in section Frames R5 to R9 without vibration dampers on page 50.
2. Put the hood onto the upper screws.
3. Tighten the upper screws in the wall securely.
4. Tighten the lower screws in the wall securely.

Note: Do not open or remove the cable entry box for easier installation. The gaskets do not fulfill the degree of protection if the box is opened.

Figure D-11




D.7.3 Frames R5 and R9 without Vibration Dampers

1. See the dimensions in chapter Dimension drawings. Mark the locations for the four or six mounting holes.
2. Drill the mounting holes.
3. Start the screws or bolts into the mounting holes.
4. Remove the front cover.
5. For IP21 units: Attach the cable entry box to the drive frame. For instructions, see the assembly drawing in the cable entry box. A view of frame R5 is shown below.
6. Position the drive onto the screws on the wall.
7. Tighten the accessible screws in the wall securely.

Note: If you use the lower mounting screws, you can replace the drive module without unfastening the cable entry box.

Figure D-12



D.8 Cabinet Installation

See ACS880-01 cabinet installation supplement (3AUA0000145446 [English]).

Appendix E

ModbusTCP Setup

E.1 ACS880 Cooling Tower Drive

E.1.1 Modbus TCP Setup

This document will guide you through the process of setting up the ACS880 Cooling Tower Drive for monitoring and control over Modbus TCP using the following data in and out:



This guide assumes that the basic drive setup has already been done. This includes setting the Language & Units, entering Motor Data and performing an ID Run.

Once this basic drive setup has been done, the following parameters will need to be set:

Group 50: Fieldbus Adapter

Program parameter PASS CODE (96.02) to 13 to allow access to fieldbus parameters.

- | | |
|--|--|
| 50.01 FBA A Enable = Option Slot 1 | This is the top option slot on the drive. Adapter can go in any slot |
| 50.02 FBA A Comm Loss Function = Warning | This setting determines what the drive does when comms are lost |
| 50.03 FBA A Comm Loss Timeout = 3sec | This time is added to the time in 51.20 before issuing a fault warning |
| 50.04 FBA A ref1 Type = Speed | |
| 50.08 FBA A Act1 Transparent source = Torque | |
| 50.09 FBA A SW Transparent Source = 6.11[16] | Status Word sent back to the PLC will be par 6.11 Main Status Word |

Group 76: CTD Motor Control

- 76.03 Operating Mode = FIELDBUS

Group 51: FBA A Settings (Ethernet Adapter Setup)

- | | |
|-------------------------------------|--|
| 51.01 FBA A Type = EtherNet | |
| 51.02 Protocol/Profile = MB/TCP T16 | Transparent 16 Profile |
| 51.03 Comm Rate = Auto | Automatically adjusts to 10 or 100Mbit/s network speed |
| 51.04 IP Configuration = STATIC | |
| 51.05 IP Address | ex. 192 |
| 51.06 IP Address | ex. 168 |
| 51.07 IP Address | ex. 0 |

51.08 IP Address	ex. 10
51.09 Subnet CIDR = 24	Shorthand for 255.255.255.0
51.10 GW Address	Leave at default (zero) if not used
51.11 GW Address	Leave at default (zero) if not used
51.12 GW Address	Leave at default (zero) if not used
51.13 GW Address	Leave at default (zero) if not used
51.20 Timeout Time = 30	3 sec (value put here is multiplied times 100ms)
51.21 Timeout Mode = Control RW	Monitors updating of CW and REF1

Group 52 FBA A Data In (PLC Input Data)

(Note: that first three words back to PLC are pre-defined or already mapped for you.)

Status Word (SW)	Register 40051. See status word bit description below
Actual Value 1 =	Register 40052. Speed (1=1rpm)
Actual Value 2 =	Register 40053. Torque (% of motor nominal x 100)
52.01 FBA A Data In1 = Parameter 1.07	Register 40054. Motor Current (1=1Amp)
52.02 FBA A Data In2 = Parameter 1.11	Register 40055. DC Bus Voltage x 10
52.03 FBA A Data In3 = Parameter 1.14	Register 40056. Actual motor power in HP x 10
...	...
52.12 FBA A Data In12	Register 40065. These additional data words could be used to read other parameters from the drive.

Group 53 FBA A Data Out (PLC Output Data)

(Note: the first three words sent to the drive are pre-defined or already mapped for you.)

Control Word (CW)	Register 40001. See control word bit description below
Ref 1	Register 40002. Scaling is 1=1rpm
Ref 2	Register 40003. Not used.
53.01 FBA A Data Out1 = Parameter 23.12	Register 40004. (optional) These additional data words could be used to write to other parameters. For example, writing a value of 300 here would set par 23.12 Accel Time 1 to 30 seconds.
53.02 FBA A Data Out 1...	Register 40015. Up to 12 additional parameters can be mapped here for cyclic updating
53.12 FBA A Data Out12	Register 40015. Up to 12 additional parameters can be mapped here for cyclic updating

Last step after changing any fieldbus related pars in Groups 50-53:

51.27 FBA A Par Refresh = Refresh	Reboots fieldbus card so changes can take effect
-----------------------------------	--

Communication should now be established

PING the drive at the IP address above to verify. Make sure your laptop IP address is on the same subnet as the drive.

Now, let's simulate a ModbusTCP master using the ModbusPoll Software. Some familiarity with this software is assumed.

PLC OUTPUT DATA

PLC INPUT DATA

Mbpoll1
Tx = 1622; Err = 0; ID = 1; F = 03; SR = 1ms

	Alias	4x0000	Alias	4x0010
1	Main Control Word	40001 = 000000	Data Words 8 (Par 53.08)	40011 = 000000
2	Speed Ref 1	40002 = 000500	Data Words 9 (Par 53.09)	40012 = 000000
3	Speed Ref 2 (Not Used)	40003 = 000000	Data Words 10 (Par 53.10)	40013 = 000000
4	Data Words 1 (Par 53.01)	40004 = 000000	Data Words 11 (Par 53.11)	40014 = 000000
5	Data Words 2 (Par 53.02)	40005 = 000000	Data Words 12 (Par 53.12)	40015 = 000000
6	Data Words 3 (Par 53.03)	40006 = 000000		
7	Data Words 4 (Par 53.04)	40007 = 000000		
8	Data Words 5 (Par 53.05)	40008 = 000000		
9	Data Words 6 (Par 53.06)	40009 = 000000		
10	Data Words 7 (Par 53.07)	40010 = 000000		

Mbpoll2
Tx = 932; Err = 0; ID = 1; F = 03; SR = 1ms

	Alias	4x0050	Alias	4x0060
1	Main Status Word	40051 = 000561	Data Words 8 (Par 52.08)	40061 = 000000
2	Act Speed (1 unit = 1 RPM)	40052 = 000000	Data Words 9 (Par 52.09)	40062 = 000000
3	Act Torque (1 unit = 0.01 % Motor Torque)	40053 = 000000	Data Words 10 (Par 52.10)	40063 = 000000
4	Data Words 1 (Par 52.01)	40054 = 000000	Data Words 11 (Par 52.11)	40064 = 000000
5	Data Words 2 (Par 52.02)	40055 = 000000	Data Words 12 (Par 52.12)	40065 = 000000
6	Data Words 3 (Par 52.03)	40056 = 000000		
7	Data Words 4 (Par 52.04)	40057 = 000000		
8	Data Words 5 (Par 52.05)	40058 = 000000		
9	Data Words 6 (Par 52.06)	40059 = 000000		
10	Data Words 7 (Par 52.07)	40060 = 000000		

Read/Write Definition

Slave ID: OK

Function: 03 Read Holding Registers (4x) Cancel

Address: Protocol address. E.g. 40011 -> 10

Quantity:

Scan Rate: [ms] Apply

Disable

Read/Write Definition

Slave ID: OK

Function: 03 Read Holding Registers (4x) Cancel

Address: Protocol address. E.g. 40011 -> 10

Quantity:

Scan Rate: [ms] Apply

Disable

Use Modbus Function Code 03 "Read Holding Registers (4x)" for both output and input data.

PLC Output data starts at register address 40001.

PLC Input data starts at register address 40051.

Check the boxes for "Address in Cell" and "PLC Addresses (Base 1)".

Then click "Connection" from the top menu, and select "Connect".

The window below will appear.

Connection Setup

Connection: OK

Cancel

Serial Settings

Advanced...

Mode: RTU ASCII

Response Timeout: [ms]

Delay Between Polls: [ms]


Remote Modbus Server

IP Address or Node Name:

Server Port: Connect Timeout: [ms] IPv4 IPv6

Connection type is ModbusTCP/IP. For the “Remote Server” IP Address, enter drive’s IP address. Click OK.

You should now see the packet counters at the top of the windows begin to increment. This indicates that data is being sent to, and received from, the drive.



You should also be receiving a “live” bus voltage value now too. Looking at bus voltage (a value that constantly changes) is a good way to verify working communication.

Now we’re ready to begin controlling/monitoring the drive over fieldbus:

The Fieldbus Operating Mode specifies some digital inputs that must be turned on:

XDI	Digital inputs	
1	DI1	Local Stop (0) / Start (1)
2	DI2	Local/Remote Local(0)/FBA(1)+(bit2)*
3	DI3	Run enable
4	DI4	Constant Speed 2 (1 = On)
5	DI5	Reset Fault
6	DI6	External Event, Vibration Switch

- DI2 = ON This puts the drive in Fieldbus Control Mode (EXT2 Control Location)
- DI3 = ON Run Enable
- DI6 = ON Vibration Switch OK

Note: If the drive will ONLY be controlled over fieldbus, then the above inputs must be jumpered to +24V if not used. There is no way to “program them out.” (turn them ON all the time in software)

Now, let's look at the Control Word bit structure. These are the bits we will turn on and off to control the drive:

Control Word Bit #	Function	Decimal number to write into control word to turn this bit "ON"
0	Trickle Heating	1
1	De-Ice Mode	2
2	Start Forward	4



Turning a bit ON will cause that function to start. Only one function should be ON at a time.

So, let's tell the drive to start and run at 100rpm:

Write a value of 100 to REF1 for the speed reference. (100rpm)

Set CW bit 2=1 by writing a decimal value of 4 to the CW. (drive should start)

Note! If you have set par 53.01 = 23.12, then make sure to also write a value into register 40004 for the Accel Time 1. Try "300" for 30 seconds. If left empty, Modbus Poll will write a value of zero into this parameter. An accel time of zero is unreasonable and may cause a drive fault.



For the CTD firmware only, a few additional bits have been added to the Main Status Word (SW) in par 6.11:

Status Word Bit #	Function
10	Trickle Heating Active (on during delay and heating)
11	De-Ice Mode Active
12	CTDD Running (motor actually turning – ***not active in de-ice mode***)
13	CTDD Hold (autophasing in progress)

The rest of the usual SW bits still work, although they should be carefully interpreted. For example, the running bit will come on during motor trickle heating even though the motor isn't actually turning (drive is modulating though!). The most useful bits to the customer will be:

- Bit 1: Drive Ready
- Bit 3: Drive Faulted
- Bit 7: Drive Warning
- Bit 9: Drive Keypad in Remote mode

Bit	Name	Value	STATE/Description
0	Ready to switch on	1	Ready to switch ON
		0	Not ready to switch ON
1	Ready run	1	Ready to operate
		0	OFF1 active
2	Ready ref	1	Operation enabled
		0	Operation inhibited
3	Tripped	1	Fault
		0	No fault
4	OFF2 inactive	1	OFF2 inactive
		0	OFF2 active
5	OFF3 inactive	1	OFF3 inactive
		0	OFF3 active
6	Switch-On inhibited	1	Switch-On inhibited
		0	---
7	Warning	1	Warning active
		0	No warning active
8	At setpoint	1	OPERATING Actual value equals reference = is within tolerance limits (see parameters 46.2146.23)
		0	Actual value differs from reference = is outside tolerance limits
9	Remote	1	Drive control location: REMOTE (EXT1 or EXT2)
		0	Drive control location: LOCAL

The scaling used for other actual value feedback signals is shown above in the ModbusPoll screenshot.

When using the trickle and de-ice feature, pay attention to the settings below. These two features default to "DISABLE" so you will need to set them to FBA control. Note that setting 75.03 Run Time to zero, will cause the function to stay on as long as the CW bit calls for it (no time limit).

74. Trickle Current						
1	Trickle Selection	Disable	NoUnit			Disable
2	Trickle Power	100	watt	0	1000	100
3	Trickle Delay Time	1	min	0	10	1
75. De-ice						
1	De-ice Selection	Disable	NoUnit			Disable
2	De-Ice Speed	30	%	0	100	30
3	Run Time	1	min	0	1500	1

Troubleshooting:

You can verify the *CW being received by the drive* by looking at par 6.03 FBA A Transparent Control Word. This will be the raw value being sent by the PLC.

You can verify the current *speed reference being used by the drive* by looking at par 47.01 Data Storage 1 real32. This parameter will contain the active reference whether it comes from Fieldbus or an analog input.

Appendix F

Modbus RTU Setup

F.1 ACS880 Cooling Tower Drive

F.1.1 Modbus RTU Serial Communication Setup using built-in D2D (drive to drive) port

This document will guide you through the process of setting up the ACS880 Cooling Tower Drive for monitoring and control over Modbus RTU using the following data in and out:

Figure F-1



This guide assumes that the basic drive setup has already been done. This includes setting the Language & Units, entering Motor Data and performing an ID Run.

Once this basic drive setup has been done, the following parameters will need to be set:

Group 76: CTD Motor Control

Program parameter PASS CODE (96.02) to 13 to allow access to fieldbus parameters.

76.03 Operating Mode = EFB

EFB = embedded fieldbus port, aka "D2D" link

Group 74: CTD Motor Control

74.01 Trickle Selection = EFB

Optional: Control could be programmed to the EFB or could set to DIO1 if hardwired control is needed

Group 75: CTD Motor Control

75.01 De-ice Selection = EFB

Optional: Control could be programmed to the EFB or could set to DIO2 if hardwired control is needed

Group 58: Embedded Fieldbus

58.01 Protocol Enable = ModbusRTU	
58.03 Node Address = 1	This is the drive's node address on the Modbus RTU network
58.25 Control Profile = Transparent	
58.26 EFB Ref1 Type = Speed	Speed scaling is 1 unit = 1 rpm
58.30 EFB status word transparent = 6.11[16]	Status Word
58.31 EFB act1 transparent source = 1.1[16]	Actual Speed
58.34 Word order = HI-LO	
58.110 Data I/O 10 = 1.7[16]	Motor Current
58.111 Data I/O 11 = 1.11[16]	DC Bus Voltage
58.112 Data I/O 12 = 1.14[16]	Motor Power

***Last step is to restart the fieldbus interface so the above settings take effect:
Do this any time you make a change to Group 58 parameters!***

58.06 Communication Control = Refresh settings

That should complete the fieldbus setup on the drive.

If this were a startup in the field, next step would be to explain the control word and status word structure and reference/actual value scaling to the PLC technician. The rest of this document is devoted to understanding how that works.

PLC INPUT DATA

Simulating a ModbusRTU Master:

The table below shows the default Modbus holding register addresses for drive data. This profile provides a converted 16-bit access to the data.

Register address	Register data (16-bit words)
400001	Control word. See section Control Word (page 547). The selection can be changed using parameter 58.101 Data I/O 1 .
400002	Reference 1 (REF1). The selection can be changed using parameter 58.102 Data I/O 2 .
400003	Reference 2 (REF2). The selection can be changed using parameter 58.103 Data I/O 3 .
400004	Status Word (SW). See section Status Word (page 549). The selection can be changed using parameter 58.104 Data I/O 4 .
400005	Actual value 1 (ACT1). The selection can be changed using parameter 58.105 Data I/O 5 .
400006	Actual value 2 (ACT2). The selection can be changed using parameter 58.106 Data I/O 6 .
400007 ... 400024	Data in/out 7 ... 24. Selected by parameters 58.107 Data I/O 7 ... 58.124 Data I/O 24 .


We first need to connect our laptop to the drive's D2D port (connector "XD2D" to be specific). Most of us will use a USB to RS-232 serial converter. That will be connected to an RS-232 to RS-485 converter. And that will connect to the drive's D2D port.

USB to RS-485 serial converters are also available.

Pay attention to RS-485 signal polarity. Generally "A" is (-) and "B" is (+). If communication just doesn't work, try swapping these lines. It's also a good practice to terminate the drive end of the bus by turning ON switch J3 (push the red slider to the right).

Once the hardware is setup, we will use a software program called ModbusPoll. Some familiarity with this software is assumed. You can simply open the three ModbusPoll setup files that should accompany this guide, or you can set them up from scratch:

Figure F-2



Use Modbus Function Code 16 “Write Multiple Registers” for PLC output data. PLC Output data starts at register address 40001.


Use Modbus Function Code 03 “Read Holding Registers (4x)” for PLC input data. PLC Input data is broken up into blocks of three words starting at 40004 and 40010.

For both, check the boxes for “Address in Cell” and “PLC Addresses (Base 1)”.

Then click “Connection” from the top menu, and select “Connect”.

The window below will appear.

Figure F-3




Connection is via Serial Port. Select the COM port of interface you are using to connect to the drive. If you are using a USB to Serial adapter, this will be the COM port assigned to that device. The other serial settings with regard to Baud rate, number of data bits, parity, etc. are set to match the drive defaults. Enter them in exactly.

You may also need to go into your Device Manager and edit the properties of the USB to Serial converter to match the above settings.

Click OK to begin communication.

The packet counters at the top of the windows begin to increment. This indicates that data is being sent to, and received from, the drive.

Figure F-4



You should also be receiving a “live” bus voltage value now too. (Looking at a value that constantly changes like bus voltage is a good way to verify working communication.)

Now we're ready to begin controlling/monitoring the drive over fieldbus:

The Fieldbus Operating Mode specifies some digital inputs that must be turned on:

Figure F-5

XDI	Digital inputs	
1	DI1	Local Stop (0) / Start (1)
2	DI2	Local/Remote (0=Local /1=FBA+MCW bit2)
3	DI3	Run enable
4	DI4	Constant Speed 2 (1 = On)
5	DI5	Reset Fault
6	DI6	External Event, Vibration Switch

- DI3 = ON Run Enable
- DI6 = ON Vibration Switch OK
- DIIL= ON Motor Thermostat OK

Note: The above inputs must be jumpered to +24V if not wired to their respective field devices. There is no way to “program them out.” (turn them ON all the time in software)

Finally, we need to tell the drive to respond to fieldbus commands:

- DI2 = ON This puts the drive in Fieldbus Control Mode (EXT2 Control Location)

Now, let's look at the Control Word bit structure. These are the bits we will turn on and off to control the drive:


Control Word Bit #	Function	Decimal number to write into control word to turn this bit “ON”
0	Trickle Heating	1
1	De-Ice Mode	2
2	Start Forward	4

Turning a bit ON will cause that function to start. Only one function should be ON at a time.

So, let's tell the drive to start and run at 100rpm:

Write a value of 100 to REF1 for the speed reference. (which is the speed scaling value in par 46.01)
Set CW bit 2=1 by writing a decimal value of 4 to the CW. (drive should start)

Figure F-6



You should now see a variety of data coming back from the drive. Compare these values to the values you see in the drive parameters.

For the CTD firmware only, a few additional bits have been added to the Main Status Word (SW) in par 6.11:

Status Word Bit #	Function
10	Trickle Heating Active (on during delay and heating)
11	De-Ice Mode Active
12	CTDD Running (motor actually turning – ***not active in de-ice mode***)
13	CTDD Hold (autophasing in progress)

The rest of the usual SW bits still work, although they should be carefully interpreted. For example, the running bit will come on during motor trickle heating even though the motor isn't actually turning (drive is modulating though!). The most useful bits to the customer will be:

- Bit 1: Drive Ready
- Bit 3: Drive Faulted
- Bit 7: Drive Warning
- Bit 9: Drive Keypad in Remote mode

Bit	Name	Value	STATE/Description
0	Ready to switch on	1	Ready to switch ON
		0	Not ready to switch ON
1	Ready run	1	Ready to operate
		0	OFF1 active
2	Ready ref	1	Operation enabled
		0	Operation inhibited
3	Tripped	1	Fault
		0	No fault
4	OFF2 inactive	1	OFF2 inactive
		0	OFF2 active
5	OFF3 inactive	1	OFF3 inactive
		0	OFF3 active
6	Switch-On inhibited	1	Switch-On inhibited
		0	---
7	Warning	1	Warning active
		0	No warning active
8	At setpoint	1	OPERATING Actual value equals reference = is within tolerance limits (see parameters 46.21....46.23)
		0	Actual value differs from reference = is outside tolerance limits
9	Remote	1	Drive control location: REMOTE (EXT1 or EXT2)
		0	Drive control location: LOCAL

The scaling used for other actual value feedback signals is shown above in the ModbusPoll screenshot.

When using the trickle and de-ice feature, pay attention to the settings below. These two features default to “DISABLE” so you will need to set them to EFB control. Note that setting 75.03 Run Time to zero, will cause the function to stay on as long as the CW bit calls for it (no time limit).

Figure F-7

74. Trickle Current						
1	Trickle Selection	EFB	NoUnit			Disable
2	Trickle Power	100	watt	0	1000	100
3	Trickle Delay Time	1	min	0	10	1
75. De-ice						
1	De-ice Selection	EFB	NoUnit			Disable
2	De-Ice Speed	30	%	0	100	30
3	Run Time	1	min	0	1500	1

Troubleshooting:

You can verify the *CW being received by the drive* by looking at par 58.18 EFB Control Word. This will be the raw value being sent by the PLC.

You can verify the *current speed reference in rpm being used by the drive* by looking at par 3.09 EFB Reference 1.

You can verify the *SW being sent by the drive to the PLC* by looking at par 58.19 EFB Status Word. This value is shown in HEX by default, so convert to decimal before comparing it to the number you see in ModbusPoll. In DriveComposer, you can also right click this value and show it as decimal – or any other number format you like.

Appendix G

Ethernet/IP Setup

G.1 ACS880 Cooling Tower Drive

G.1.1 Ethernet/IP Setup

This document will guide you through the process of setting up the ACS880 Cooling Tower Drive for monitoring and control over Ethernet/IP using the following data in and out:



This guide assumes that the basic drive setup has already been done. This includes setting the Language & Units, entering Motor Data and performing an ID Run.

Once this basic drive setup has been done, the following parameters will need to be set:

Group 76: CTD Motor Control

76.03 Operating Mode = FIELDBUS

96.02 Pass Code = 13 Fieldbus

Group 50: Fieldbus Adapter

50.01 FBA A Enable = Option Slot 1

50.02 FBA A Comm Loss Function = Warning

50.03 FBA A Comm Loss Timeout = 3sec

50.04 FBA A ref1 Type = Speed

50.08 FBA A Act1 Transparent source = Torque

50.09 FBA A SW Transparent Source = 6.11[16]

This is the top option slot on the drive. Adapter can go in any slot

This setting determines what the drive does when comms are lost

This time is added to the time in 51.20 before issuing a fault/warning

Status Word sent back to the PLC will be par 6.11 Main Status Word

Group 51: FBA A Settings (Ethernet Adapter Setup)

51.01 FBA A Type = EtherNet

51.02 Protocol/Profile = EIP T16 (102)

51.03 Comm Rate = Auto

51.04 IP Configuration = STATIC

51.05 IP Address

51.06 IP Address

51.07 IP Address

51.08 IP Address

51.09 Subnet CIDR = 24

51.10 GW Address

51.11 GW Address

51.12 GW Address

51.13 GW Address

Automatically adjusts to 10 or 100Mbit/s network speed

ex. 192

ex. 168

ex. 3

ex. 88

Shorthand for 255.255.255.0

Leave at default (zero) if not used

Group 52 FBA A Data In (PLC Input Data)

(Note: that first three words back to PLC are pre-defined or already mapped for you.)

Main Status Word (MSW)	See status word bit description below
Actual Value 1	Speed (1=1rpm)
Actual Value 2	Torque (% of motor nominal x 100)
52.01 FBA A Data In1 = Parameter 1.07[16]	Motor Current (1=1Amp)
52.02 FBA A Data In2 = Parameter 1.11[16]	DC Bus Voltage x 10
52.03 FBA A Data In3 = Parameter 1.14[16]	Actual motor power in HP x 10
52.04 FBA A Data In1...	These additional data words could be used to read other parameters from the drive.
52.10 FBA A Data In10	These additional data words could be used to read other parameters from the drive.

(Note: the first three words sent to the drive are pre-defined or already mapped for you.)


Main Control Word (MCW)	See control word bit description below.
Speed Reference 1	Scaling is 1=1rpm
Reference 2	Not used in ACS880 CTDD
53.01 FBA A Data Out1 = Parameter 23.14[16]	Accel Time 2 (optional) These additional data words could be used to write to other parameters within the drive. For example, writing a value of 300 here would set par 23.12 Accel Time 1 to 30 seconds.
53.04 FBA A Data Out1...	Up to 10 additional parameters can be mapped here for cyclic updating.
53.10 FBA A Data Out10	Up to 10 additional parameters can be mapped here for cyclic updating.

Last step after changing any fieldbus related parameters in Groups 50-53:


51.27 FBA A Par Refresh	Refresh Reboots fieldbus card so changes will take effect (or the drive power can be cycled).
-------------------------	---

ACS880 CTDD Drive on EtherNet/IP FENA-21 or FEIP-21 with Studio 5000 Logix Designer® or RSLogix® 5000


1. Open Studio 5000 Logix Designer® or RSLogix® 5000 and open a new project.
2. Right click on the Ethernet module within the Controller Organizer window.



3. Click on New Module.



4. Select Module Type: ETHERNET-MODULE.



5. Program the following information below. The ACS880 CTDD Drive only supports the 16 Bit Transparent assembly instances displayed below. This example will use 16 Bit transparent Profile Assembly Instances 112 and 162. The following table will display Input and Output Assembly Instances and PLC I/O Memory size.

Input Assembly Instances	Output Assembly Instances	PLC Word Settings
61	11	2
62	12	3
161	111	12
162	112	13

Reference FENA-01/-11/-21 EtherNet Adapter Module User's Manual 3AUA0000093568 section "Communication" for more information on Input/Output Assembly Instances and reference FEIP-21 Ethernet IP User's Manual 3AXD50000158621.

6. Enter the following information. The example shown is using the B16 Bit Transparent Profile Assembly Instances 112 and 162. The PLC will transmit and receive 13 words of information.
- Enter the name that will be given to the Cooling Tower Drive
 - Change Comm Format to Data - INT (16Bits)
 - Enter the IP Address of the Ethernet option card
 - Enter Input and Output Assembly Instances numbers.
 - Enter Input and Output Assembly Instances numbers.
 - Enter configuration instance as 1 and size as 0.

New Module

Type: ETHERNET-MODULE Generic Ethernet Module
 Vendor: Rockwell Automation/Allen-Bradley
 Parent: Local
 Name: ACS880_CTDD
 Description:
 Comm Format: Data - INT
 Address / Host Name:
 IP Address: 192 . 168 . 3 . 88
 Host Name:
 Open Module Properties


Connection Parameters


	Assembly Instance:	Size:	
Input	162	13 (16-bit)	D
Output	112	13 (16-bit)	E
Configuration:	1	0 (8-bit)	F
Status Input:			
Status Output:			

OK Cancel Help

7. Click Finish.

8. The ACS880 CTD Drive is now added to the PLC I/O.





www.abb.com/drives



3AXD5000011888D