



# PARTS MAP

Model: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Notes: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

## Water Distribution

- 1 Slide Out Drift Eliminators
- 2 Removable Spray Distribution Branch
- 3 Spray Nozzles
- 4 hCore™ Heat Transfer Technology
- 5 Water Diverter

## Air Handling

- 6 Hinged EC Fan System Access Panel
- 7 EC Fan System
- 8 Fan Guard

## Water Collection


- 9 Spray Water Basin
- 10 Mechanical Make-up Assembly
- 11 Solenoid Make-up Valve
- 12 Drain Valve
- 13 Overflow
- 14 Spray Pump
- 15 High/Low Level Float Switch

## Controls

- 16 iPilot™ Control System (not pictured)



# NEXUS™ MODULAR HYBRID COOLER



Find my BAC Rep to order parts, get maintenance tips,  
and get a free unit inspection: [www.baltimoreaircoil.com/RepFinder](http://www.baltimoreaircoil.com/RepFinder)

Applicable 2016-Present. Quantities may vary according to the unit.