



**NOTES:**

1. All dimensions are in feet and inches.
2. Supporting steelwork and anchor bolts to be designed and furnished by others.
3. All supporting steelwork must be flush and level at top, and designed in accordance with accepted structural practice.
4. Each support beam should be designed, as a minimum, for 80% of the total unit operating weight applied as a uniformly distributed load. Refer to the Tabulated Unit Print for operating weights.
5. Supporting steelwork shall be greater than or equal to the length of the unit.
6. Do not use this drawing to size point vibration isolators. Contact your local BAC Representative for details.