

Model: ______Serial Number: ______Notes:


Upper Casing Section

- 1 Hot Water Basin
- 2 XF Spray Nozzles
- 3 BACross III® Upper Fill with Integral Drift Eliminators
- 4 Axial Fan Assembly
- 5 Fan Cylinder
- 6 Fan Guard
- 7 Combined Inlet Shields
- 8 Upper Drift Eliminators

Lower Pan Section

- Make-up Valve Assembly
- 10 Float Ball
- 11 Access Door
- 12 BACross III® Lower Fill with Integral Drift Eliminators
- **13** Lower Drift Eliminators
- 14 Pan Strainer
- 15 Pan Strainer Hood
- 16 Internal Walkway

Series 1500 Cooling Tower



Reduce Downtime Spare Parts List (page 2)

Recommended Spare Parts

BAC Factory Authorized Parts are manufactured to meet rigorous specifications and are guaranteed to fit your unit and perform as original equipment.

BAC Factory Authorized Parts can be ordered through your local BAC Representative. Most BAC Representatives maintain a local inventory of commonly used parts. For a free unit inspection and a specific parts list for your serial number, contact your local BAC Representative today.

Even with BAC's fast delivery capability, it is still recommended that certain essential and emergency repair part be maintained in your inventory to minimize any potential downtime.



Find my BAC Rep to order parts, get maintenance tips, and get a free unit inspection: www.baltimoreaircoil.com/RepFinder



Series 1500 Cooling Tower

Basic Recommended Spare Parts

for Critical Applications

Bearings

Bearing Greaser Refill (if equipped)

Belts

Basin Heater & LWCO (if equipped)

Float Valve Kit & Float Ball

Solenoid Valve (if unit is equipped with EWLC option)

Spray Nozzles

Suction Strainer

Inlet Strainer (if equipped)

Sheave and Bushings

Prop Fans with Bushings

Parts to Consider

Fan Shaft

Fan Motor



