PARTS MAP

Model: _____

Serial Number: _____

Notes:

PT2 Cooling Tower

Internal Motor Configuration

Air Handling Section

1 Fan Guard
2 Fan Cowl
3 Axial Fan Assembly (see detailed view)
4 Davit Fan Assembly (optional)
5 Mechanical Access Door

Air Handling Section

6 Spray Branch Heater
7 Spray Branch
7A CF Nozzles
8 BACPak™ Fill

Water Collection Section

9 Inlet Louvers
10 Sump Sweeper Piping (optional)
11 Strainer Assembly
12 Make-up Valve Assembly
13 Float Ball
14 Basin Heater



Find my BAC Rep to order parts, get maintenance tips, and get a free unit inspection: www.baltimoreaircoil.com/RepFinder

Quantities may vary according to the unit. Applicable 2014-Present.

PARTS MAP

Model: _____

Serial Number: _____

Notes: _____

PT2 Cooling Tower

External Motor Configuration

Air Handling Section

1 Fan Guard
2 Fan Cowl
3 Axial Fan Assembly (see detailed view)
4 Davit Arm Assembly (optional)
5 Mechanical Access Door

Heat Transfer Section

6 Spray Branch Heater
7 Spray Branch
7A CF Nozzles
8 BACPak™ Fill

Water Collection Section

9 Inlet Louvers
10 Sump Sweeper Piping (optional)
11 Strainer Assembly
12 Make-up Valve Assembly
13 Float Ball
14 Basin Heater



Find my BAC Rep to order parts, get maintenance tips, and get a free unit inspection: www.baltimoreaircoil.com/RepFinder

Quantities may vary according to the unit. Applicable 2014-Present.