



Notes

- 1) All dimensions are in feet and inches. Weights are in pounds and do not include options and accessories.
- 2) Supporting steelwork and anchor bolts to be designed and furnished by others.
- 3) All supporting steel must be flush and level at top.
- 4) Each beam should be designed, as a minimum, for 65% of the total unit operating weight applied as a uniformly distributed load.
- 5) Beams should be selected in accordance with accepted structural practice, maximum deflection of beam under the unit to be 1/360 of span, not to exceed 1/2 inch.
- 6) If vibration isolation rails are used between unit and supporting steel, be certain to allow for the length of the vibration rails when determining length of supporting steel. Vibration rail length and mounting hole locations may differ from those of the unit. Refer to vibration isolator manufacturer drawings for this data.
- 7) Do not use this drawing to size point vibration isolators.

MODEL NO.	APPROX. SHIPPING WEIGHT	APPROX. OPERATING WEIGHT
VCA-261A	11720	16230
VCA-288A	11800	16310
VCA-308A	11830	16340
VCA-273A	13080	17660
VCA-301A	13160	17740
VCA-322A	13190	17770

ORDER NO: \_\_\_\_\_

DATE: \_\_\_\_\_



**Baltimore Aircoil**

VCA Unit Support  
8'x12'

DRAWING NUMBER: \_\_\_\_\_