



PLAN VIEW

Notes

- 1) All dimensions are in feet and inches. Weights are in pounds and do not include options and accessories.
- 2) Supporting steelwork and anchor bolts to be designed and furnished by others.
- 3) All supporting steel must be flush and level at top.
- 4) Each beam should be designed, as a minimum, for 65% of the total unit operating weight applied as a uniformly distributed load.
- 5) Beams should be selected in accordance with accepted structural practice, maximum deflection of beam under the unit to be 1/360 of span, not to exceed 1/2 inch.
- 6) If vibration isolation rails are used between unit and supporting steel, be certain to allow for the length of the vibration rails when determining length of supporting steel. Vibration rail length and mounting hole locations may differ from those of the unit. Refer to vibration isolator manufacturer drawings for this data.
- 7) Do not use this drawing to size point vibration isolators.

Model Number	Shipping Weight	Operating Weight
PT2-1218A-1x3	32450	60610
PT2-1218A-2x3	34545	62705
PT2-1218A-3x3	36240	64400
PT2-1218A-4x3	37343	65915
PT2-1218A-5x3	42468	71453

ORDER IN "STEEL"

DATE:



BALTIMORE AIRCOIL COMPANY

**Unit Support
PT2 12'x54' Three Cell**

DRAWING NUMBER: